



Snow Chain Installation

This Instruction covers most Snow Chains used with Avant Loaders

AVANT[®]

Luottamuksellinen

Installing Instruction for the Snow Chain



AVANT®

Installing Instruction for the Snow Chain



You can notice the positions of the connecting hook and the tightening hook in the photos.

AVANT[®]

Installing Instruction for the Snow Chain




Set the tyre in the middle of the snow chain so that the air valve remains on the same side as the tightening hook.



AVANT[®]

Installing Instruction for the Snow Chain



The looking behind the tyre, unite both ends of the chain, using the connecting hook.

AVANT[®]

Luottamuksellinen

Installing Instruction for the Snow Chain



Do the same at the air valve side , connect loosely the tightening hook to the other end of the chain.

AVANT[®]

Luottamuksellinen

Installing Instruction for the Snow Chain



Then pull up the chain, to connect the top of the links, using now the loose c-shape chain links

Installing Instruction for the Snow Chain



Connecting both ends of the chain, on the top of the tyre, using the separate c-shape linkage.

AVANT[®]

Luottamuksellinen

Installing Instruction for the Snow Chain



First connect one.....




....and then also the other one

AVANT[®]

Luottamuksellinen

Installing Instruction for the Snow Chain




Both the c-shape top linkages connected.

AVANT[®]

Luottamuksellinen

Installing Instruction for the Snow Chain



Arrange the shackle correctly before tensioning. The threaded hole must remain underneath, so that, in the end it will be easier to close this device.

Installing Instruction for the Snow Chain



Select the third link from the opposite side loose chain and pass the tightening hook trough it.

AVANT[®]

Installing Instruction for the Snow Chain




Then start tensioning the chain pulling the lever so that the opposite chain link slides in, as shown in the photo. This part takes the most hand power, to finish this job..

AVANT[®]

Luottamuksellinen

Installing Instruction for the Snow Chain



Here also the shackle has been closed with its threaded pin.

AVANT[®]

Luottamuksellinen

Installing Instruction for the Snow Chain



Finally do not forget to tie up the remaining loose chain-links with some cable ties etc.

AVANT[®]

Luottamuksellinen

Installing Instruction for the Snow Chain

After the snow-chains have been installed you can insert the air valve and fill up the tyres. After the installation double-check once more, that the wheels can turn freely before starting any actual work.

In some occasions, it is recommendable to use some specific spacers under the rims, to bring the tyres some few millimetres outwards, in order to prevent any rubbing against the covers, or the frame of the loader.

Installing Instruction for the Snow Chain

