

AVANT[®]

Salt Spreader 1000

Varaosakirja
Parts Manual
Dellista
Ersatzteilliste



Product no. A454073

I/2024


15.1.2024

Table Of Contents

A454073	SALT SPREADER 1000	4
A454141	FRAME ASSEMBLY SALT SPREADER 1000	6
A454120	SPREADING SHAFT ASSEMBLY SALT SPREADER	8
A454127	ADJUSTMENT ASSEMBLY SPREADING SHAFT	10
A454285	REAR PLATE ASSEMBLY SPREADING SHAFT	12
A456390	SPRING PLATE ASSEMBLY SALT SPREADER 1000	14
A456312	MIXING SHAFT ASSEMBLY SALT SPREADER 1000	16
A456382	RUBBER BLADE ASSEMBLY SALT SPREADER 1000	18
A461687	ELECTRIC MOTOR 12V ASSEMBLY SALT	20
A461321	PROTECTIVE PLATE MOTOR SALT SPREADER	22
A463593	TRANSMISSION SALT SPREADER 1000	24
A456192	PROTECTIVE COVER ASSEMBLY TRANSMISSION	26
A455512	ELECTRIC COMPONENTS SALT SPREADER	28
A462608	WIRE HARNESS SALT SPREADER	30

15.1.2024

A454073 SALT SPREADER 1000




15.1.2024

A454073 SALT SPREADER 1000

REF	PART NO	QTY	DESCRIPTION	NOTES	PAGE
1	A454141	1	FRAME ASSEMBLY SALT SPREADER 1000		6
2	A454120	1	SPREADING SHAFT ASSEMBLY SALT SPREADER		8
3	A454127	1	ADJUSTMENT ASSEMBLY SPREADING SHAFT		10
4	A456312	1	MIXING SHAFT ASSEMBLY SALT SPREADER 1000		16
5	A456382	1	RUBBER BLADE ASSEMBLY SALT SPREADER 1000		18
6	A461687	1	ELECTRIC MOTOR 12V ASSEMBLY SALT		20
7	A461321	1	PROTECTIVE PLATE MOTOR SALT SPREADER		22
8	A463593	1	TRANSMISSION SALT SPREADER 1000		24
9	A456192	1	PROTECTIVE COVER ASSEMBLY TRANSMISSION		26
10	A455512	1	ELECTRIC COMPONENTS SALT SPREADER		28
11	A417403	2	DECAL "AVANT 1000"		-
12	A46771	1	DECAL PICTOGR. READ OPERATORS MANUAL		-
13	A46798	1	DECAL PICTOGR. DO NOT REMOVE THE COVERS		-
14	A46801	1	DECAL PICTOGR. WARNING ROTATING PARTS		-
15	A458120	1	TYPE PLATE SALT SPREADER 1000		-

15.1.2024

A454141 FRAME ASSEMBLY SALT SPREADER 1000




15.1.2024

A454141 FRAME ASSEMBLY SALT SPREADER 1000

REF	PART NO	QTY	DESCRIPTION	NOTES	PAGE
1	A454077	1	FRAME SALT SPREADER 1000		-
2	A454111	1	SIEVE NET SALT SPREADER 1000		-
3	A454550	1	WEATHER COVER ASSEMBLY SALT SPREADER		-
4	A418927	1	HOLDER FOR MULTI CONNECTOR, ON		-
5	A451054	4	HEXAGONAL SCREW A4 M8*20 DIN 933		-
6	A451117	12	WASHER A4 M8		-
7	A451119	6	HEXAGONAL NUT A4 M8 NYLOC		-
8	A461659	2	HEXAGONAL SCREW A4 M8*25 DIN 933		-
9	A461663	3	WASHER A4 M6 DIN 9021		-
10	A461420	7	WASHER A4 M6 DIN 125		-
11	A461664	5	HEXAGONAL NUT A4 M6 NYLOC		-
12	A461669	5	HEXAGONAL SCREW A4 M6*16 DIN 933		-
13	A463552	1	HEXAGONAL SCREW A4 M8*45 DIN 933		-
14	A463553	1	HEXAGONAL NUT A4 M8		-
15	A461764	8	PADDING, WIRING SALT SPREADER		-

15.1.2024

A454120 SPREADING SHAFT ASSEMBLY SALT SPREADER




15.1.2024

A454120 SPREADING SHAFT ASSEMBLY SALT SPREADER

REF	PART NO	QTY	DESCRIPTION	NOTES	PAGE
1	A454114	1	SPREADING SHAFT SALT SPREADER 1000		-
2	A461527	1	SCRAPER ASSEMBLY SPREADING SHAFT SALT		-
3	A461545	2	MOUNTING PLATE BEARING SALT SPREADER		-
4	A446975	2	BEARING UCFL 204		-
5	A454149	1	PROTECTIVE PLATE BEARING SAND / SALT		-
6	A461676	4	HEXAGONAL SCREW A4 M12*40 DIN 933		-
7	A461677	8	WASHER A4 M12		-
8	A461678	4	HEXAGONAL NUT A4 M12 NYLOC		-
9	A454320	1	KEY 6X6X20 DIN 6885A		-

15.1.2024

A454127 ADJUSTMENT ASSEMBLY SPREADING SHAFT




15.1.2024

A454127 ADJUSTMENT ASSEMBLY SPREADING SHAFT

REF	PART NO	QTY	DESCRIPTION	NOTES	PAGE
1	A454285	1	REAR PLATE ASSEMBLY SPREADING SHAFT		12
2	A456390	1	SPRING PLATE ASSEMBLY SALT SPREADER 1000		14
3	A454136	1	LEVER SPREADING SHAFT SALT SPREADER 1000		-
4	A461684	1	HEXAGONAL HEAD SCREW A4 M6*20 DIN 912		-
5	A461683	1	SPRING LOCK WASHER A4 M6 DIN 127		-
6	A461540	1	WASHER SALT SPREADER		-

15.1.2024

A454285 REAR PLATE ASSEMBLY SPREADING SHAFT




15.1.2024

A454285 REAR PLATE ASSEMBLY SPREADING SHAFT

REF	PART NO	QTY	DESCRIPTION	NOTES	PAGE
1	A454128	1	REAR PLATE SPREADING SHAFT ADJUSTMENT		-
2	A454138	1	MOUNTING STRIP REAR PLATE SPREADING		-
3	A461679	9	HEXAGONAL SCREW A4 M6*50 DIN 933		-
4	A461664	9	HEXAGONAL NUT A4 M6 NYLOC		-
5	A461420	18	WASHER A4 M6 DIN 125		-

15.1.2024

A456390 SPRING PLATE ASSEMBLY SALT SPREADER 1000




15.1.2024

A456390 SPRING PLATE ASSEMBLY SALT SPREADER 1000

REF	PART NO	QTY	DESCRIPTION	NOTES	PAGE
1	A456391	1	MOUNTING BAR SPRING PLATE SAND SPREADER		-
2	A456394	4	SPRING PLATE SALT SPREADER 1000		-
3	A461664	12	HEXAGONAL NUT A4 M6 NYLOC		-
4	A461680	12	HEXAGONAL SCREW A4 M6*40 DIN 933		-
5	A461420	24	WASHER A4 M6 DIN 125		-

15.1.2024

A456312 MIXING SHAFT ASSEMBLY SALT SPREADER 1000




15.1.2024

A456312 MIXING SHAFT ASSEMBLY SALT SPREADER 1000

REF	PART NO	QTY	DESCRIPTION	NOTES	PAGE
1	A456313	1	MIXING SHAFT SALT SPREADER 1000		-
2	A461542	2	MOUNTING PLATE BEARING SALT SPREADER		-
3	A447649	2	BEARING UCF 204		-
4	A454149	1	PROTECTIVE PLATE BEARING SAND / SALT		-
5	A461676	8	HEXAGONAL SCREW A4 M12*40 DIN 933		-
6	A461677	16	WASHER A4 M12		-
7	A461678	8	HEXAGONAL NUT A4 M12 NYLOC		-

15.1.2024

A456382 RUBBER BLADE ASSEMBLY SALT SPREADER 1000




15.1.2024

A456382 RUBBER BLADE ASSEMBLY SALT SPREADER 1000

REF	PART NO	QTY	DESCRIPTION	NOTES	PAGE
1	A454131	1	RUBBER BLADE SALT SPREADER 1000		-
2	A456383	1	MOUNTING BRACKET SCRAPER SPREADING SHAFT		-
3	A461717	5	CARRIAGE BOLT A4 M8*25 DIN 603		-
4	A451117	5	WASHER A4 M8		-
5	A451119	5	HEXAGONAL NUT A4 M8 NYLOC		-

15.1.2024

A461687 ELECTRIC MOTOR 12V ASSEMBLY SALT




15.1.2024

A461687 ELECTRIC MOTOR 12V ASSEMBLY SALT

REF	PART NO	QTY	DESCRIPTION	NOTES	PAGE
1	A455683	1	ELECTRIC MOTOR 12V WITH WORM GEAR SALT		-
2	A456125	1	MOUNTING PLATE OUTER ELECTRIC MOTOR SALT		-
3	A456124	1	MOUNTING PLATE INNER ELECTRIC MOTOR SALT		-
4	65750	1	BALL BEARING UCFL 205		-
5	A456127	1	CONNECTING SHAFT ELECTRIC MOTOR SALT		-
6	A461688	1	HEXAGONAL HEAD SCREW A4 M8*30 DIN 912		-
7	74448	3	WASHER M5 A5,3 DIN 125 ZN		-
8	72315	3	HEXAGONAL NUT M5 NYLOC DIN 985		-
9	A430193	2	WASHER M16 A17 DIN 125		-
10	74657	2	HEXAGONAL HEAD SCREW M16*45 DIN 912 ZN		-
11	A463522	1	KEY 8X7X25 DIN 6885A		-

15.1.2024

A461321 PROTECTIVE PLATE MOTOR SALT SPREADER




15.1.2024

A461321 PROTECTIVE PLATE MOTOR SALT SPREADER

REF	PART NO	QTY	DESCRIPTION	NOTES	PAGE
1	A457863	1	PROTECTIVE PLATE HYDRAULIC MOTOR SALT		-
2	A461372	1	SEAL, PROTECTIVE PLATE HYDRAULIC MOTOR		-
3	A451117	4	WASHER A4 M8		-
4	A461406	4	HEXAGONAL SCREW A4 M8*16 DIN 933		-

A463593 TRANSMISSION SALT SPREADER 1000




15.1.2024

A463593 TRANSMISSION SALT SPREADER 1000

REF	PART NO	QTY	DESCRIPTION	NOTES	PAGE
1	A454557	1	SPROCKET Z=13 SAND / SALT SPREADER		-
2	A454555	2	SPROCKET Z=25 SAND / SALT SPREADER		-
3	A454320	2	KEY 6X6X20 DIN 6885A		-
4	A454565	2	SET SCREW M8*20 DIN 916		-
5	A463657	1	HEXAGONAL SOCKET SET SCREW M8*10 DIN 916		-
6	A463563	1	CHAIN L=851 67 LINKS SALT SPREADER		-
7	A454560	1	CHAIN LINK		-
8	A463602	1	CHAIN LINK		-

15.1.2024

A456192 PROTECTIVE COVER ASSEMBLY TRANSMISSION




15.1.2024

A456192 PROTECTIVE COVER ASSEMBLY TRANSMISSION

REF	PART NO	QTY	DESCRIPTION	NOTES	PAGE
1	A456194	1	PROTECTIVE COVER TRANSMISSION SALT		-
2	A456362	1	SEAL PROTECTIVE COVER TRANSMISSION SALT		-
3	A461408	3	HEXAGONAL SCREW A4 M8*90 DIN 933		-
4	A451117	3	WASHER A4 M8		-

15.1.2024

A455512 ELECTRIC COMPONENTS SALT SPREADER




15.1.2024

A455512 ELECTRIC COMPONENTS SALT SPREADER

REF	PART NO	QTY	DESCRIPTION	NOTES	PAGE
1	A462608	1	WIRE HARNESS SALT SPREADER		30
2	A461302	1	MULTI CONNECTOR WITH ELECTRIC CONNECTOR		-
3	A455535	1	RELAY 25A		-
4	A464045	1	CONTROL RELAY PROGRAMMED		-
5	A461553	1	MOUNTING PLATE ELECTRIC CONNECTOR BOX		-
6	A462124	1	MOUNTING PLATE SPEED INDICATOR PANEL		-
7	A444756	3	HEX. HEAD SCREW M5*12 DIN 7984		-
8	74448	3	WASHER M5 A5,3 DIN 125 ZN		-
9	A464096	4	HEXAGONAL SCREW M6*12 A4 DIN 933		-
10	A461420	4	WASHER A4 M6 DIN 125		-
11	A462255	2	HEXAGONAL HEAD SCREW A4 M4*20 DIN 912		-
12	A462273	6	WASHER A4 M4 DIN 125		-
13	A462277	6	HEXAGONAL NUT A4 M4 NYLOC		-
14	A462269	4	HEXAGONAL HEAD SCREW A4 M4*16 DIN 912		-

15.1.2024

A462608 WIRE HARNESS SALT SPREADER



15.1.2024

A462608 WIRE HARNESS SALT SPREADER

REF	PART NO	QTY	DESCRIPTION	NOTES	PAGE
1	A457608	1	CONNECTION BOX ASSEMBLY SALT SPREADER		-
2	A455514	1	WIRE HARNESS SALT SPREADER		-
3	A461768	1	SPEED INDICATOR PANEL ASSEMBLY SALT		-



Varaosat Spare parts

Manufacturer:

AVANT®
AVANT TECNO OY
e-mail: sales@avanttecho.com

Ylötie 1
33470 Ylöjärvi
FINLAND
Tel. +358 3 347 8800
Fax +358 3 348 5511