Connecting external PS2 keyboard

- Change in xdc file default PS2 pins, to alternative ones, and generate new bitstream

- Connect keyboard according to diagram, Basys 3 USB 5V can be used to power keyboard as headers are only 3.3V