

Nwave Technologies Ltd.



# **NWAVE BASE STATION USER MANUAL**

#### **Table of Contents**

1. Base station connectors description	2
2. Base station setup	
2. 1. Connect Ethernet cable to the network connector (an internet connection is needed), as it	
shown at the pictures below	3
2. 2. Connect Dongle device to the USB connector, as it is shown at the pictures below	
2. 3. Connect Development Kit board to the USB connector, as it is shown at the picture below	
2. 4. Connect Power Supply adapter to the Power connector	4
2. 5. Press Power Button at the top of the base station case	4
3. Revision History	5


## 1. Base station connectors description



# 2. Base station setup

A base station comes with installed and prepared software which is ready to start. User has to complete installation steps described below.

- 2. 1. Connect Ethernet cable to the network connector (an internet connection is needed), as it is shown at the pictures below
- 2. 2. Connect Dongle device to the USB connector, as it is shown at the pictures below
- 2. 3. Connect Development Kit board to the USB connector, as it is shown at the picture below





- 2. 4. Connect Power Supply adapter to the Power connector
- 2. 5. Press Power Button at the top of the base station case
- 3. Revision History

### Here is a revision history for this document.

Author	Description of Changes	Date	Revision Number
Ruslan Gerasimov	Created	01-07-2015	1.1