## STANDARD DEPARTURE CHART - INSTRUMENT

RJCO / SAPPORO SID

## KURIS REVERSAL FOUR DEPARTURE

RWY 14: Turn left,....

RWY 32: ....

....climb direct to SPE VOR/DME, via SPE R325 until passing 3000 FT, turn left to intercept and proceed via SPE R305 to SPE VOR/DME within SPE 10.0DME, via SPE R103 to KURIS.

Cross SPE R103/10.0DME at or above 6000FT,

cross KURIS at or above 7000FT.

