## STANDARD DEPARTURE CHART-INSTRUMENT

RJCJ / CHITOSE SID

## SAVIT ONE DEPARTURE

RWY 36R/36L: Climb via RWY HDG to 500ft or above, turn right to CHE

VOR/DME within CHE 10DME (5NM FM RWY end). Cross 4DME prior to CHE VOR/DME (MKE R-329) at or

above 3,000ft....

RWY 18R/18L: Climb direct to CHE VOR/DME....

....then via CHE R-224 to SAVIT.

## SAVIT ONE DEPARTURE

