#### STANDARD DEPARTURE CHART - INSTRUMENT

RJBE / KOBE **TRANSITION** 

## KIBI TRANSITION

From over MAIKO, proceed via KCE R272 to KAWAT, via OYE R114 to OYE VOR/DME.

Cross KAWAT at or above 8000FT.

# TAMBA TRANSITION

From over MAIKO, proceed via KCE R272 to KAWAT, via TSC R001 to CHIZU via AYAYA, via YME R236 to YME VOR/DME via TAMBA.

Cross KAWAT at or above 8000FT.

## KAGAWA TRANSITION

From over MAIKO, proceed via KCE R272 to KAWAT, via KTE R058 to KTE VOR/DME.

Cross KAWAT at or above 8000FT.

## AYAYA TRANSITION



CHANGE: Radial FM KCE