STANDARD DEPARTURE CHART - INSTRUMENT

RJAH / HYAKURI

SID and TRANSITION

DAPPE ONE DEPARTURE

RWY 03R/03L: Climb via RWY HDG until 1.0NM from RWY end/HUC 1.4DME,

turn right within 5.0NM....

RWY 21R/21L: Turn left within 6.0NM....

....climb via HUC R055 to DAPPE.

Cross HUC R055/31.0DME at or below 10000FT.

Note1: Take off RWY 21R/21L, cross HUC R130 at or below 5000FT.

Note2: This SID for TACAN equipped aircraft only.

CHOSHI TRANSITION

From over DAPPE, via CVT R015 to CVT TACAN via ANKOH.

Cross ANKOH at or above FL170.

HYAKURI TRANSITION

From over DAPPE, via CVT R015 to ANKOH, via HUC R089 to HUC VORTAC. Cross ANKOH at or above FL170.

CHANGE: ANKOH established

STANDARD DEPARTURE CHART - INSTRUMENT

