STANDARD DEPARTURE CHART -INSTRUMENT

RJOE / AKENO SID

KOWA FIVE DEPARTURE

RWY13 : Turn left,... RWY31 : Turn right,...

.... climb via AKT R-060 (057 DEG from AK NDB) to XMT TACAN. Cross XMT TACAN at assigned altitude.

AKENO REVERSAL THREE DEPARTURE

RWY13 : Turn left,... RWY31 : Turn right,...

.... climb via AKT R-320 (320 DEG from AK NDB) until passing 2500FT, then turn right within 10NM of AK NDB (AKT TACAN 10DME) to intercept and proceed via AKT R-320 to AKT (140 DEG to AK NDB).

TRIKE TRANSITION

From over AKT TACAN(AK NDB), via AKT R-068 (068 DEG from AK NDB) to TRIKE.

Cross AKT 14DME (AK 13NM) at or above 4000FT.

Cross TRIKE at assigned alutitude.

ASAMA ONE DEPARTURE

RWY13 : Turn left,.... RWY31 : Turn right,....

>climb via AKT R-105 to ASAMA. Cross ASAMA at or above 2500FT.

Note: Following climb gradient should be maintained until 2500FT.

Speed (Knots)	60	90	120	150	180	210
Rate (Feet/Min)	300	450	600	750	900	1050

HISAI ONE DEPARTURE

RWY13: Turn left,....

RWY31:....

....climb via AKT R-320 to HISAI. Cross HISAI at or above 2500FT.

Note: Following climb gradient should be maintained until 2500FT.

Speed (Knots)	60	90	120	150	180	210
Rate (Feet/Min)	300	450	600	750	900	1050

STANDARD DEPARTURE CHART -INSTRUMENT

