## STANDARD DEPARTURE CHART -INSTRUMENT

## RJGG / CHUBU CENTRAIR

SID

## FOREST TWO DEPARTURE

RWY18: Climb RWY HDG to 500FT, turn right, via CBE R181 to 7.0DME, turn right, via CBE 9.0DME clockwise ARC, via CBE R250 to CBE VOR/DME,...

RWY36 : Climb RWY HDG to 500FT, turn left HDG260° to intercept and proceed via

KCC R214 to 30.7DME(CBE R255), turn left, via CBE 9.0DME counterclockwise ARC, via CBE R198 to CBE VOR/DME,...

...via CBE R067 to MORIZ. Cross CBE VOR/DME at or above 7000FT.

