## STANDARD DEPARTURE CHART-INSTRUMENT

## RJOW / IWAMI

SID and TRANSITION

## SAMBA TWO DEPARTURE

RWY11: Climb RWY HDG to 800FT, turn left HDG351°,... RWY29: Climb RWY HDG to 700FT, turn right HDG081°,... ...to intercept and proceed via IME R036 to SAMBA.

Cross SAMBA at or above 7000FT.

Note RWY11: 5.7% climb gradient required up to 1700FT.

OBST ALT 1177FT located at 4.83NM 093° FM end of RWY11.

## IZUMO TRANSITION

From over SAMBA, via XZE R252 to XZE VOR/DME. Cross CARNY at or below 13000FT, cross BAARU at or below FL230.

