STANDARD DEPARTURE CHART -INSTRUMENT

RJGG / CHUBU CENTRAIR

SID

MORIZ ONE DEPARTURE

RWY18: Climb RWY HDG to 500FT, turn right, via CBE R181 to 13.6DME, turn left,

via CBE 16.0DME counterclockwise ARC, via KCC R180,...

Cross CBE R181/13.6DME at or above 3500FT.

Cross CBE R147 at or above 6000FT.

RWY36: Climb RWY HDG to 500FT, turn left, via CBE R350 to 12.0DME, turn right,

via CBE 14.0DME clockwise ARC,...

...via CBE R067 to MORIZ via ANJYO.

