
STANDARD ARRIVAL CHART - INSTRUMENT



LANCE WEST ARRIVAL

From LANCE at or above 11000FT, to QUAIL, to RIBON at or above 6000FT, to SHIPS at or above 4000FT.

Critical DME	SDE: 5.0NM to QUAIL – 4.0NM to QUAIL 2.0NM to QUAIL – QUAIL HPE: 1.0NM to QUAIL – QUAIL
DME GAP	QUAIL - SHIPS
Inappropriate Navaids	See AD1.1.6.10.3. Inappropriate NAVAIDs for RNAV1.

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation		Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	IF	LANCE	_	_	-7.8	_	_	+11000	_	_	RNAV1
002	TF	QUAIL	_	127 (119.4)	-7.8	5.0	_	_	-250	_	RNAV1
003	TF	RIBON	_	092 (084.5)	-7.8	5.0	_	+6000	_	_	RNAV1
004	TF	SHIPS	_	002 (354.6)	-7.8	7.8	_	+4000	_	_	RNAV1