

RJCB / OBIHIRO SID


EATAK ONE DEPARTURE

RWY 17: Climb RWY HDG to 1000FT, turn left HDG 354° to intercept and proceed...

RWY 35: Climb RWY HDG to 900FT, turn right,...

...via OBE R039 to EATAK.

Cross EATAK at or above 6000FT.



RJCB / OBIHIRO SID


KUSHIRO FOUR DEPARTURE

RWY 17: Climb RWY HDG to 1000FT, turn left HDG 031° to intercept and proceed...

RWY 35 : Climb RWY HDG to 900FT, turn right HDG 121° to intercept and proceed...

...via OBE R076 to KSE VOR/DME.

Cross OBE R076/20.0DME at or above 5000FT.



RJCB / OBIHIRO SID


NOTAK FOUR DEPARTURE

RWY 17: Climb RWY HDG to 1000FT, turn left HDG 300° to intercept and proceed...

RWY 35: Climb...

...via OBE R345 to NOTAK.

Cross NOTAK at or above 6000FT.



RJCB / OBIHIRO SID

OBIHIRO REVERSAL SEVEN DEPARTURE


RWY 17: Climb RWY HDG to 1000FT, turn left, via OBE R130 to 3000FT, turn left,... RWY 35: Climb RWY HDG to 900FT, turn right, via OBE R039 to 3000FT, turn right,...

...direct to OBE VOR/DME.

Cross OBE VOR/DME at or above 6000FT.

Note RWY 35: 5.0% climb gradient required up to 1500FT.

OBIHIRO REVERSAL SEVEN DEPARTURE



RJCB / OBIHIRO SID


RACKO TWO DEPARTURE


RWY 17: Climb...

RWY 35 : Climb RWY HDG to 900FT, turn right HDG 214° to intercept and proceed...

...via OBE R169 to RACKO.

Cross RACKO at or above 10000FT.





OTTER ONE DEPARTURE

RWY17: Climb on HDG168° at or above 1000FT, direct to RACKO at or above 10000FT.

RWY35 : Climb on HDG348° at or above 900FT, turn right direct to RACKO at or above 10000FT.

RJCB / OBIHIRO	RNAV SID


OTTER ONE DEPARTURE


RWY17


Serial	Path	Waypoint	Fly	Course	Magnetic	Distance	Turn	Altitude	Speed	Vertical	Navigation
Number	Descriptor	Identifier	Over	°M(°T)	Variation	(NM)	Direction	(FT)	(KIAS)	Angle	Specification
001	VA	_	_	168 (159.4)	-9.0	_	_	+1000	_	_	Basic RNP1
002	DF	RACKO	_	_	-9.0	_	_	+10000	_	_	Basic RNP1


RWY35


Serial	Path	Waypoint	Fly	Course	Magnetic	Distance	Turn	Altitude	Speed	Vertical	Navigation
Number	Descriptor	Identifier	Over	°M(°T)	Variation	(NM)	Direction	(FT)	(KIAS)	Angle	Specification
001	VA	_	_	348 (339.4)	-9.0	_	_	+900	1	_	Basic RNP1
002	DF	RACKO	_	_	-9.0	_	R	+10000	-	_	Basic RNP1











RJCB / OBIHIRO

RNAV(RNP) RWY17

RNAV(RNP) RWY17

Coding Table

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	VPA/ RDH (°/FT)	RNP Value
001	IF	TAIKI	1	_	-9.0	_	_	+5000	_	1	_
002	TF	CB750	_	337 (327.6)	-9.0	15.8	_	+4000	_	_	1.0
003	TF	HAPPY	-	336 (327.5)	-9.0	3.0	_	3800	-165	_	1.0
004	TF	CB751	_	336 (327.4)	-9.0	1.4	_	3345	_	-3.00	0.3
005	RF Center: CBRF1 r=2.18NM	CB752	-	_	-9.0	7.3	R	1020	_	-3.00	0.3
006	TF	RW17	Υ	168 (159.4)	-9.0	1.6	_	520	_	-3.00/50	0.3
007	TF	TAIKI	_	169 (159.8)	-9.0	18.7	_	5000	_	_	1.0

Waypoint Coordinates

Waypoint Identifier	Coordinates	RF Arc Center Identifier	Coordinates
TAIKI	422706.29N/1432128.22E	CBRF1	424520.85N/1430911.91E
CB750	424026.47N/1430956.82E		
HAPPY	424258.09N/1430745.16E		
CB751	424410.25N/1430642.42E		
CB752	424607.16N/1431158.01E		
RW17	424438.86N/1431243.31E		



※図中に標高を示す数字がある場合、単位はメートル(m)である。The unit of measurement used to express elevation is meter(m).

ARP.	Call sign	BRG / DIST from ARP	Remarks		
from,	幕別 Makubetsu	031°T / 12.2NM	JR駅 JR Station		
BRG/DIST	芽室 Memuro	320°T / 13.6NM	JRの鉄橋(芽室駅から西1.5NM) Bridge		
	茂岩橋 Moiwabashi	071°T / 13.7NM	十勝川の茂岩橋 Bridge		
odated	糠内 Nukanai	056°T / 5.9NM	猿別川と糠内川の合流点 The confluence of the Sarubetsu and Nukanai rivers		
Map updated.	中札内 Nakasatsunai	245°T / 4.9NM	札内川の中札内橋 Bridge		
	駒畠 Komahata	130°T / 5.4NM	五差路 Intersection		
CHANGE	更別 Sarabetsu	195°T / 5.1NM	更別村役場 Sarabetsu Village office		

