




### STANDARD DEPARTURE CHART-INSTRUMENT

RJAZ / KOZUSHIMA RNAV SID



### KOZU ONE DEPARTURE

RWY11 : Climb on HDG112° at or above 1800FT, turn left direct to XAC. RWY29 : Climb on HDG292° at or above 1700FT, turn right direct to XAC.

NOTE RWY11: 5.0% climb gradient required up to 2100FT.

OBST ALT 1903FT located 1.9NM 042° FM end of RWY11.

NOTE RWY29: 5.0% climb gradient required up to 2200FT.

OBST ALT 1969FT located 2.1NM 041° FM end of RWY29.

### STANDARD DEPARTURE CHART-INSTRUMENT

RJAZ / KOZUSHIMA RNAV SID

# KOZU ONE DEPARTURE


## RWY11

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance(NM)		Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	VA	_	_	112 (105.2)	-7.1	_	_	+1800	_	_	Basic RNP1
002	DF	XAC	_	_	-7.1	_	L	_	_	_	Basic RNP1


## RWY29


Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance(NM)		Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	VA	_	_	292 (285.2)	-7.1	_	_	+1700	_	_	Basic RNP1
002	DF	XAC	_	_	-7.1	_	R	_	_	_	Basic RNP1

#### **INSTRUMENT APPROACH CHART**



### **INSTRUMENT APPROACH CHART**





※図中に標高を示す数字がある場合、単位はメートル(m)である。The unit of measurement used to express elevation is meter(m).

אצו	Call sign	BRG / DIST from ARP	Remarks
,all 120	10NM N	360°T / 10.0NM	海上 Over the sea
Note( C	赤崎 Akasaki	003°T / 3.1NM	岬 Cape
	祇苗島 Tadanaejima	069°T / 3.0NM	島 Island
CHAINGE.	10NM SE	135°T / 10.0NM	海上 Over the sea

