

## STANDARD DEPARTURE CHART -INSTRUMENT

RJTO / OSHIMA SID

# HATSU FOUR DEPARTURE

RWY03: Climb RWY HDG to 800FT, turn right, climb...

RWY21: Climb RWY HDG to 1400FT, turn right, direct to OSE VOR/DME,...

...via OSE R037 to HATSU.

Cross OSE 10.0DME at or above 3000FT.


Note RWY03: In case of climbing with 8.7% gradient up to 500FT, another TKOF


WX MINIMA is applicable.

OBST ALT 394FT located at 0.6NM 049°FM end of RWY03.

Note RWY21: 4.2% climb gradient required up to 1400FT.

OBST ALT 1444FT located at 2.2NM 165°FM end of RWY21





## STANDARD DEPARTURE CHART -INSTRUMENT

RJTO / OSHIMA SID

# OSHIMA REVERSAL FOUR DEPARTURE

RWY03: Climb RWY HDG to 1100FT, turn left,... RWY21: Climb RWY HDG to 1400FT, turn right,...

...direct to OSE VOR/DME.

Cross OSE VOR/DME at or above 4000FT.


Note RWY03: In case of climbing with 8.7% gradient up to 500FT, another TKOF

WX MINIMA is applicable.


OBST ALT 394FT located at 0.6NM 049°FM end of RWY03.

Note RWY21: 4.2% climb gradient required up to 1400FT.


OBST ALT 1444FT located at 2.2NM 165°FM end of RWY21




OSHIMA REVERSAL FOUR DEPARTURE




## **INSTRUMENT APPROACH CHART**




## **INSTRUMENT APPROACH CHART**



## **INSTRUMENT APPROACH CHART**





※図中に標高を示す数字がある場合、単位はメートル(m)である。The unit of measurement used to express elevation is meter(m).

RADIO abolished.		TOSHIMA	<u>(</u> Webメルカトル図法(球体補正)/ Web Mercator projection
OSHIMA R	※図中に標高を示す数字がある場合、単位はメートル(m)である。The unit of measurement used to express elevation is meter(m).		
CHANGE : Secondary FREQ of OS	Call sign	BRG / DIST from ARP	Remarks
	10NM N	360°T / 10.0NM	海上 Over the sea
	10NM E	090°T / 10.0NM	海上 Over the sea
	10NM W	270°T / 10.0NM	海上 Over the sea
	千波崎 Senbazaki	181°T / 4.8NM	岬 Cape
	利島 Toshima	194°T / 16.1NM	宮塚山 Mt. Miyatsuka

NOTE: In the SE direction of the airport, A/G COM from Oshima Radio is blinded by Mt Mihara(2,487ft)

