




### STANDARD DEPARTURE CHART -INSTRUMENT



### STANDARD DEPARTURE CHART -INSTRUMENT

# **RORT / TARAMA**

# RNAV SID and TRANSITION

# GAHRA THREE DEPARTURE

### RWY18

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over		Magnetic Variation		Turn Direction		l '		Navigation Specification
001	VA	_	_	178 (172.8)	-4.9	_	_	+500	_	_	Basic RNP1
002	DF	GAHRA	_	_	-4.9	_	L	+3000	_	_	Basic RNP1


# RWY36

Serial Number	Path Descriptor	Waypoint Identifier	1		Magnetic Variation		Turn Direction		•		Navigation Specification
001	VA	_	_	358 (352.8)	-4.9	_	_	+500	_	_	Basic RNP1
002	DF	GAHRA	_	_	-4.9	_	R	+3000	_	_	Basic RNP1


# MIYAKO TRANSITION


Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation		Turn Direction	Altitude (FT)	ı .		Navigation Specification
001	IF	GAHRA	_	_	-4.9	_	_	+3000	_	_	Basic RNP1
002	TF	MJC	_	075 (069.8)	-4.9	11.4	_	_	_	_	Basic RNP1

### **INSTRUMENT APPROACH CHART**



### **INSTRUMENT APPROACH CHART**





※図中に標高を示す数字がある場合、単位はメートル(m)である。The unit of measurement used to express elevation is meter(m).

Call sign	BRG / DIST from ARP	Remarks				
ハナレ崎 Hanarezaki	017°T / 5.8NM	岬 Cape				
10NM E	090°T / 10.0NM	海上 Over the sea				
10NM SW	225°T / 10.0NM	海上 Over the sea				

