

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-1 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-00-01	ENVIRONMENTAL CONTROL SYSTEM MISCELLANEOUS CARDS (ECSMC)				
-00-01-01	PASSENGER C	2	1	(M) (O) One may be inoperative provided:	
				a) Associated ECSMC is deactivated,	
				b) Both ARINC Signal Gateway cards in the	
				opposite card file operate normally,	
				c) Opposite equipment cooling controller	
				operates normally,	
				d) Opposite equipment cooling supply fan	
				operates normally,	
				e) Opposite lavatory/galley fan operates	
				normally,	
				f) One Pack operates normally,	
				g) Appropriate performance adjustments are	
				applied (Refer DDG), and	
				h) For FCAC installed and right ECSMC	
				inoperative, FCAC remains OFF. (-200ER)	
-00-01-02	777F			NOT APPLICABLE	
-24-01	GASPER FAN (PASSENGER)			NOT APPLICABLE	
-25-01	RECIRCULATION FANS				
-25-01-01	PASSENGER C	4	0	(M)(O) May be inoperative provided associated	
				recirculation fan is deactivated.	
-25-01-01-01	RECIRC FANS SWITCH ON LIGHTS	C	2	0	
-25-01-02	777F			NOT APPLICABLE	
-26-01	LAVATORY/GALLEY VENTILATION FANS	C	2	1	(M) One may be inoperative provided;
				a) Inoperative ventilation fan is deactivated ,	
				and	
				b) Opposite ECSMC operates normally.	
-26-02	CHILLER BOOST FAN (PASSENGER)	C	1	0	(M) Chiller boost fan may be inoperative provided it
				is deactivated.	
-26-03	BULK CARGO VENTILATION FAN				
-26-03-01	WITH CHILLER BOOST FAN INSTALLED	C	1	0	(M) May be inoperative provided:
				a) Bulk cargo ventilation fan is deactivated,	
				and	
				b) Chiller boost fan is deactivated.	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-2 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-26-03-02	WITHOUT CHILLER BOOST FAN INSTALLED				NOT APPLICABLE
-26-04	CABIN SMOKING AREA VENTILATION EXHAUST VALVES				NOT APPLICABLE
-26-05	FORWARD CARGO AIR CONDITIONING (FCAC) EXHAUST FAN (-200ER)				
-26-05A		C	1	0	(M) FCAC exhaust fan may be inoperative provided it is deactivated.
-26-05B		D	1	0	(M) May be inoperative provided; a) FCAC exhaust fan is deactivated, and b) FCAC remains OFF.
-26-06	LAVATORY/GALLEY VENTILATION SHUTOFF VALVE (777F)				NOT APPLICABLE
-26-07	ALTERNATE VENTILATION SYSTEM FAN (777F)				NOT APPLICABLE
-26-08	ALTERNATE VENTILATION SYSTEM SHUTOFF VALVE (777F)				NOT APPLICABLE
-26-09	ALTERNATE VENTILATION SYSTEM ALTN VENT SWITCH (777F)				NOT APPLICABLE
-27-01	EQUIPMENT COOLING AIR FILTER	C	1	0	(M) May be operated with filter removed.
-27-02	EQUIPMENT COOLING SUPPLY FANS	C	2	1	(M) One may be inoperative provided: a) Inoperative supply fan is deactivated, b) Opposite ECSMC operates normally, c) Both override valve motors operate normally, d) Both equipment cooling controllers operate normally, and e) Flight is conducted pressurized.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-3 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-27-03	EQUIPMENT COOLING OVERRIDE VALVE MOTORS	C	2	1	(M) One may be inoperative provided: a) Inoperative override valve motor is deactivated, b) Both equipment cooling supply fans operate normally, and c) Both equipment cooling controllers operate normally.
-27-04	EQUIPMENT COOLING LOW FLOW SENSORS				
-27-04-01	PASSENGER	C	2	1	(M) One flow sensor may be inoperative provided it is deactivated.
-27-04-02	777F				NOT APPLICABLE
-27-05	EQUIPMENT COOLING VENT FAN	C	1	0	(M) May be inoperative provided: a) Fan is deactivated, and b) For ground operations with OAT 30 Deg C or higher, both packs are selected ON or airplane is supplied with conditioned air.
-27-06	EQUIPMENT COOLING VENT VALVE				
-27-06-01	PASSENGER	C	1	0	(M) May be inoperative provided: a) Valve is deactivated closed, b) Equipment cooling vent fan is deactivated, c) For ground operations with OAT 30 degrees C or higher, both packs are selected ON or airplane is supplied with conditioned air, and d) For FCAC installed, FCAC exhaust fan is deactivated. (-200ER).
-27-06-02	777F				NOT APPLICABLE
-27-07	FORWARD CARGO HEAT VALVE	C	1	0	(M) Forward cargo heat valve may be inoperative deactivated closed.
-27-08	EQUIPMENT COOLING CONTROLLERS	C	2	1	Left controller may be inoperative provided: a) Right equipment cooling supply fan operates normally, b) Right ECSMC operates normally, c) Both override valve motors operate normally, and d) Flight deck low flow detector operates normally.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-4 (PIA Rev 23a) Jul, 2024
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-27-09	SATCOM BACKUP COOLING FANS (PASSENGER)				
-27-09A	C	1	0	(M) May be inoperative provided: a) Inoperative cooling fan (s) is deactivated, and b) Both lavatory/galley ventilation fans operate normally.	
-27-09B	C	1	0	(M) May be inoperative provided: a) Inoperative SATCOM backup cooling fan(s) is deactivated, and b) Associated SATCOM system is considered inoperative.	
-27-09C	D	1	0	(M)(O) May be inoperative provided: a) Inoperative SATCOM backup cooling fan(s) is deactivated, and b) Route or procedures do not require use of SATCOM.	
-27-10	IN-FLIGHT ENTERTAINMENT SYSTEM (IFES) EQUIPMENT COOLING FAN				
-27-10-01 ALL	D	1	0	(M) May be inoperative provided associated IFES is deactivated. NOTE: Operators should determine and deactivate the equipment cooled by the IFES cooling fan.	
-27-10-02 STC ST02657NY-D				NOT APPLICABLE	
-27-11	IN-FLIGHT ENTERTAINMENT SYSTEM (IFES) EQUIPMENT COOLING SMOKE DETECTOR				
-27-11A				NOT APPLICABLE	
-27-11B	D	1	0	(M) May be inoperative provided associated IFES equipment is deactivated.	
-27-12	EQUIPMENT COOLING DUCT PRESSURE SENSORS	C	4	0	May be inoperative provided both equipment cooling low flow sensors operate normally.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-5 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES
------	-------------------------

-27-13	EQUIPMENT COOLING DIVERT VALVE (-200ER)	C	1	0	(M) May be inoperative provided: a) Valve is deactivated closed, b) Equipment cooling vent fan is deactivated, and c) For ground operations with OAT 30 degrees C or higher, both packs are selected ON or airplane is supplied with conditioned air.
-27-14	EQUIPMENT COOLING INBOARD VALVE (-200ER)				
-27-14-01	PASSENGER	C	1	0	(M) May be inoperative provided: a) Valve is deactivated closed, b) Equipment cooling vent fan is deactivated, and c) For ground operations with OAT 30 degrees C or higher, both packs are selected ON or airplane is supplied with conditioned air.
-27-14-02	777F				NOT APPLICABLE
-27-15	EQUIPMENT COOLING THREE-WAY VALVE (777F)				NOT APPLICABLE
-27-16	FLIGHT DECK EQUIPMENT COOLING SYSTEM (777F)				NOT APPLICABLE
-27-17	EQUIP COOLING SWITCH LIGHTS				
-27-17-01	OVRD LIGHT	C	1	0	
-27-17-02	AUTO LIGHT	C	1	0	
-28-01	FORWARD CARGO AIR CONDITIONING (FCAC) SHUTOFF VALVE (PASSENGER) (-200ER)	D	1	0	(M) May be inoperative provided: a) Valve is deactivated closed, and b) FCAC remains OFF.
-28-02	FCAC FLOW REGULATING VALVE (777F)				NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-6 (PIA Rev 23) Sep, 2023
---	--	--

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES		
-28-03	ACAC FLOW REGULATING VALVE (777F)			NOT APPLICABLE
-28-04	ACAC EXHAUST SHUTOFF VALVE (777F)			NOT APPLICABLE
-29-01	LOWER LOBE ATTENDANT REST (LLAR) SHUTOFF VALVE (IF INSTALLED) (AP-BMG & BMH)	C	1	0 (M) May be inoperative provided: a) Valve is deactivated closed, and b) LLAR is considered inoperative.
-29-02	MAIN DECK CREW REST (MDCR)/MAIN DECK FLIGHT CREW REST (MDFCR) SHUTOFF VALVE			NOT APPLICABLE
-29-03	MAIN DECK CREW REST (MDCR) EXHAUST VALVE			NOT APPLICABLE
-29-04	OVERHEAD FLIGHT CREW/ATTENDANT REST SUPPLY SHUTOFF VALVES (INCLUDES FSI INSTALLATION) (-200LR & BMS)			
-29-04-01	OVERHEAD FLIGHT CREW REST (OFCR)	C	1	0 (M) May be inoperative provided: a) OFCR supply shutoff valve is deactivated closed, and b) OFCR is considered inoperative.
-29-04-02	OVERHEAD FLIGHT ATTENDANT REST (OFAR)	C	1	0 (M) May be inoperative provided: a) OFAR supply shutoff valve is deactivated closed, and b) OFAR is considered inoperative.
-29-05	OVERHEAD FLIGHT CREW/ATTENDANT REST EXHAUST VALVES (INCLUDES FSI INSTALLATION) (-200LR & BMS)			
-29-05-01	OVERHEAD FLIGHT CREW REST (OFCR)	C	1	(M) May be inoperative provided: a) OFCR exhaust valve is deactivated closed, and b) OFCR is considered inoperative

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-7 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-29-05-02	OVERHEAD FLIGHT ATTENDANT REST (OFAR)	C	1	0	(M) May be inoperative provided: a) OFAR exhaust valve(s) is deactivated closed, and b) OFAR is considered inoperative.
-29-06	OVERHEAD FLIGHT CREW REST SUPPLY SHUTOFF VALVES (TAXI, TAKEOFF AND LANDING INSTALLATION)				NOT APPLICABLE
-29-07	OVERHEAD FLIGHT CREW REST (OFCR) PRESSURE SENSOR (TAXI, TAKEOFF & LANDING INSTALLATION)				NOT APPLICABLE
-31-01	AUTO CABIN PRESSURE CONTROLS (L AND R)				
-31-01-01	PASSENGER WITH P/N 3676-GRS-014-00 OR LATER ASCPC SOFTWARE INSTALLED (APPLICABLE TO 777 FLEET)				
-31-01-01A		C	2	1	(M) One may be inoperative provided: a) Manual cabin pressure control is verified to operate normally on both outflow valves before each departure, and b) Left or right AFDC operates normally.
-31-01-01B		C	2	1	(M)(O) One may be inoperative provided: a) One outflow valve is deactivated 7% open, b) Manual cabin pressure control is verified to operate normally on the remaining outflow valve, c) Left or Right AFDC operates normally, d) One pack operates normally, and the other pack operates normally or in standby cooling mode, e) Both CTCs operate normally, f) Both engine bleed systems operate normally, g) For aft outflow valve deactivated 7% open, the OFCR is considered inoperative, (-200LR & APBMS) and h) For aft outflow valve deactivated 7% open, the OFAR is considered inoperative. (-200LR & APBMS)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-8 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES		
-31-01-02 777F				NOT APPLICABLE
-31-01-03 ALL	C	2	0	(M)(O) May be inoperative provided: a) Flight is conducted un-pressurized, b) Loading Supervisor to ensure and verify cargo compartments remain empty or contain only ballast, empty cargo handling equipment (ballast may be loaded in ULDs), or fly away kits, c) For extended overwater flight, manual cabin pressure control is verified to operate normally on both outflow valves, and d) The rest area(s) is considered inoperative. (200LR,BMS,BMG&H(if installed)).
-31-02 MANUAL CABIN PRESSURE OUTFLOW VALVE CONTROLS (FWD AND AFT)				
-31-02-01 PASSENGER	C	2	1	(M)(O) One may be inoperative provided: a) Associated outflow valve is deactivated 7% open, b) Manual cabin pressure control is verified to operate normally on the remaining outflow valve, c) One pack operates normally, and the other pack operates normally or in standby cooling mode, d) Both CTCs operate normally, e) Both engine bleed systems operate normally, and f) For aft outflow valve deactivated 7% open, the OFCR is considered inoperative, (-200LR & APBMS) and g) For aft outflow valve deactivated 7% open, the OFAR is considered inoperative. (-200LR & APBMS)
-31-02-02 777F				NOT APPLICABLE
-31-02-03 ALL	C	2	0	(M)(O) May be inoperative provided: a) Flight is conducted un-pressurized, b) Loading Supervisor to ensure and verify cargo compartments remain empty or contain only ballast, empty cargo handling equipment (ballast may be loaded in ULDs), or fly away kits, c) Extended over water flight is prohibited, and d) The rest area(s) is considered inoperative. (200LR,BMS,BMG&H(if installed)).

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-9 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES	
-31-03	OUTFLOW VALVES (FWD and AFT)		
-31-03-01	PASSENGER WITHOUT P/N 3676-GRS-014-00 OR LATER ASCPC SOFTWARE INSTALLED		NOT APPLICABLE (As Later ASCPC Software Installed) (Refer Sub Item -31-03-02)
-31-03-02	PASSENGER C WITH P/N 3676-GRS-014-00 OR LATER ASCPC SOFTWARE INSTALLED (APPLICABLE TO 777 FLEET)	2	1
			(M)(O) One may be inoperative provided: a) Valve is deactivated 7% open, b) Manual cabin pressure control is verified to operate normally on the remaining outflow valves, c) Left or right auto cabin pressure control operates normally, d) One pack operates normally, and the other pack operates normally or in standby cooling mode, e) Both CTCs operate normally, f) Both engine bleed systems operate normally, and g) For aft outflow valve deactivated 7% open, the OFCR is considered inoperative, (-200LR & APBMS) and h) For aft outflow valve deactivated 7% open, the OFAR is considered inoperative. (-200LR & APBMS)
-31-03	OUTFLOW VALVES (FWD and AFT)		
-31-03-03	777F		NOT APPLICABLE
-31-03-04	ALL C	2	0
			(M)(O) May be inoperative provided: a) Flight is conducted un-pressurized, b) Loading Supervisor to ensure and verify cargo compartments remain empty or contain only ballast, empty cargo handling equipment (ballast may be loaded in ULDs), or fly away kits, c) Extended over water flight is prohibited, and d) The rest area(s) is considered inoperative. (200LR,BMS,BMG&H(if installed)).

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-10 (PIA Rev 23) Sep, 2023
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES
------	-------------------------

-31-03-05	OUTFLOW VALVE SWITCH LIGHTS				
-31-03-05-01	MAN LIGHTS	C	2	0	
-31-03-05-02	AUTO LIGHTS	C	2	0	
-31-04	REMOTE CABIN PRESSURE SENSOR	C	1	0	May be inoperative provided both Auto Cabin Pressure Controls operate normally.
-31-05	CABIN RATE OF CLIMB INDICATION				
-31-05A		C	1	0	May be inoperative provided both Auto Cabin Pressure Controls operate normally.
-31-05B		C	1	0	(M)(O) May be inoperative provided: a) Flight is conducted un-pressurized, b) Loading Supervisor to ensure and verify cargo compartments remain empty or contain only ballast, empty cargo handling equipment (ballast may be loaded in ULDs), or fly away kits, c) For extended over water flights, manual cabin pressure control is verified to operate normally on both outflow valves, and d) The rest area(s) is considered inoperative. (200LR,BMS,BMG&H(if installed)).
-31-06	CABIN DIFFERENTIAL PRESSURE INDICATION				
-31-06A		C	1	0	(O) May be inoperative provided: a) Cabin altitude indication operates normally, and b) A chart is provided to convert cabin altitude to cabin differential pressure. (Ref.DDG)
-31-06B		C	1	0	(M)(O) May be inoperative provided: a) Flight is conducted un-pressurized, b) Loading Supervisor to ensure and verify cargo compartments remain empty or contain only ballast, empty cargo handling equipment (ballast may be loaded in ULDs), or fly away kits, c) For extended over water flight, manual cabin pressure control is verified to operate normally on both out flow valves, and d) The rest area(s) is considered inoperative. (200LR,BMS,BMG&H(if installed)).

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-11 (PIA Rev 23) Sep, 2023
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES	
-31-07	CABIN ALTITUDE INDICATION		
-31-07A	C	1	0
-31-07B	C	1	0
-31-08	OUTFLOW VALVE POSITION INDICATIONS	C	2
-32-01	POSITIVE PRESSURE RELIEF VALVES		
-32-01A	C	2	1
-32-01B	C	2	0

(O) May be inoperative provided:
a) Cabin differential pressure indication operates normally, and
b) A chart is provided to convert cabin differential pressure to cabin altitude. (Ref DDG)

(M)(O) May be inoperative provided:
a) Flight is conducted un-pressurized,
b) Loading Supervisor to ensure and verify cargo compartments remain empty or contain only ballast, empty cargo handling equipment (ballast may be loaded in ULDs), or fly away kits,
c) For extended over water flight, manual cabin pressure control is verified to operate normally on both out flow valves, and
d) The rest area(s) is considered inoperative. (200LR,BMS,BMG&H(if installed)).

(M) One positive pressure relief valve may be inoperative provided it is deactivated closed.

(M)(O) May be inoperative provided:
a) Flight is conducted un-pressurized,
b) Extended over water flight is prohibited,
c) Both outflow valves are deactivated open,
d) Loading Supervisor to ensure and verify cargo compartments remain empty or contain only ballast, empty cargo handling equipment (ballast may be loaded in ULDs), or fly away kits, and
e) The rest area(s) is considered inoperative. (200LR,BMS,BMG&H(if installed)).

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-12 (PIA Rev 23) Sep, 2023
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-32-02	NEGATIVE PRESSURE RELIEF VENTS	C	4	0	(M)(O) May be inoperative provided: a) Flight is conducted unpressurized, b) Extended over water flight is prohibited, c) Both outflow valves are deactivated open, d) Loading Supervisor to ensure and verify cargo compartments remain empty or contain only ballast, empty cargo handling equipment (ballast may be loaded in ULDs), or Fly Away Kits, and e) The rest area(s) is considered inoperative. (200LR,BMS,BMG&H(if installed)).
-40-01	MAIN DECK CARGO SHUTOFF VALVES (777F)				NOT APPLICABLE
-41-01	LOWER LOBE ATTENDANT REST (LLAR) ELECTRIC HEATERS (IF INSTALLED) (AP-BMG & BMH)	C	2	0	
-41-02	FLIGHT CREW REST (FCR) ELECTRIC HEATER SYSTEMS (AP-BMG & BMH)	C	1	0	
-41-03	MAIN DECK CREW REST (MDCR)/MAIN DECK FLIGHT CREW REST (MDFCR) ELECTRIC HEATER SYSTEM				NOT APPLICABLE
-41-04	OVERHEAD FLIGHT CREW/ATTENDANT REST ELECTRIC HEATER SYSTEMS (INCLUDES FSI INSTALLATION) (-200LR & BMS)				
-41-04-01	OVERHEAD FLIGHT CREW REST (OFCR) HEATER SYSTEMS	C	2	0	(M) May be inoperative provided: a) Associated heater system is deactivated, and b) OFCR is considered inoperative.
-41-04-01-01	BUNK HEATER SYSTEMS	C	2	0	(M) May be inoperative provided: a) Associated bunk heater system is deactivated, and b) One common area heater system operates normally.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-13 (PIA Rev 23) Sep, 2023
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-41-04-01-02 COMMON AREA HEATER SYSTEM(S)	C	1	0	(M) May be inoperative provided: a) Associated common area heater system(s) is deactivated, and b) Bunk heater system(s) operate normally.	
-41-04-02 OVERHEAD FLIGHT ATTENDANT REST (OFAR) HEATER SYSTEMS					
-41-04-02A	C	2	1	(M) One may be inoperative provided associated heater system is deactivated.	
-41-04-02B	C	2	0	(M) May be inoperative provided: a) Heater systems are deactivated, and b) OFAR is considered inoperative.	
-44-01 AFT CARGO HEAT VALVES	C	2	0	(M) May be inoperative provided system is deactivated closed.	
-44-02 AFT CARGO COMPARTMENT TEMPERATURE SENSOR	C	1	0	May be inoperative provided system remains OFF.	
-44-03 BULK CARGO HEAT VALVES (PASSENGER)	C	2	0	(M) May be inoperative provided system is deactivated closed.	
-44-04 BULK CARGO COMPARTMENT TEMPERATURE SENSOR (PASSENGER)	C	1	0	May be inoperative provided system remains OFF.	
-45-01 FLIGHT DECK FOOT HEATERS	C	2	0	(M) May be inoperative OFF.	
-45-02 FLIGHT DECK SHOULDER HEATERS	C	2	0	(M) May be inoperative OFF.	
-51-01 AIR CONDITIONING PACKS					
-51-01-01 -200ER (WITHOUT PRR 61980 OR PRODUCTION EQUIVALENT INCORPORATED)				NOT APPLICABLE AS PRR 61980 IS INCORPORATED ON 777 FLEET (Refer Sub item -51-01-03)	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-14 (PIA Rev 23) Sep, 2023
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES		
-51-01	AIR CONDITIONING PACKS (Continued...)			
-51-01-02	-300 (WITHOUT PRR 61980 OR PRODUCTION EQUIVALENT INCORPORATED)			NOT APPLICABLE
-51-01-03	-200ER (WITH PRR 61980 OR PRODUCTION EQUIVALENT INCORPORATED)	C	2	1
				(M)(O) One may be inoperative provided: a) Remaining pack operates normally, b) Both engine bleed systems operate normally, c) Both outflow valves operate normally, d) Flight remains within 60 minutes of landing at a suitable airport, and e) Appropriate performance adjustments are applied. (Ref DDG)
				Note: These provisions are not intended to prohibit attendant rest facility inspections by crewmembers.
-51-01-04	-200LR/300ER	C	2	1
				(O) One may be inoperative provided: a) Remaining pack operates normally, b) Both engine bleed systems operate normally, c) Both outflow valves operate normally, d) Flight remains within 60 minutes of landing at a suitable airport, and e) Appropriate performance adjustments are applied. (Ref DDG)
-51-01-05	777F			NOT APPLICABLE
-51-01-06	ALL			Deleted in MMEL Rev 23
-51-01-07	PACK SWITCH LIGHTS			
-51-01-07-01	OFF LIGHTS	C	2	0
-51-01-07-02	AUTO LIGHTS	C	2	0

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-15 (PIA Rev 23) Sep, 2023
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-51-02	PACK FLOW CONTROL/SHUTOFF VALVES (FCVs)				
-51-02-01	UPPER FCVS	C	2	0	(M) May be inoperative provided: a) Inoperative upper FCV(s) is locked closed, and b) Associated lower FCV operates normally.
-51-02-02	LOWER FCVS	C	2	1	(M) One may be inoperative provided: a) Inoperative lower FCV is locked closed, b) Opposite pack operates normally, and c) Associated upper FCV operates normally.
-51-03	FLIGHT DECK FLOW REGULATING VALVE (777F)				NOT APPLICABLE
-52-01	AIR CYCLE MACHINES (ACM)	C	2	1	(M)(O) One may be inoperative provided: a) Associated second stage turbine bypass valve is locked open, b) Ram air inlet and exit doors operate normally or are secured open, c) Opposite pack operates normally, d) Both engine bleed systems operate normally, and e) Appropriate performance adjustments are applied. (Ref DDG)
-52-02	ECONOMY COOLING VALVES (ECV)				
-52-02A		C	2	1	(O) One may be inoperative provided: a) Opposite pack operates normally, b) Both engine bleed systems operate normally, and c) Appropriate performance adjustments are applied. (Ref DDG)
-52-02B		C	2	0	(M) May be inoperative provided the inoperative valve(s) is locked closed.
-52-03	COMPRESSOR DISCHARGE TEMPERATURE SENSORS	C	6	2	(M) May be inoperative provided one sensor per pack is verified to operate normally.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-16 (PIA Rev 23) Sep, 2023
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-52-04	PACK DISCHARGE TEMPERATURE SENSORS	C	6	2	(M) May be inoperative provided one sensor per pack is verified to operate normally.
-52-05	RAM AIR INLET DOOR SYSTEMS				
-52-05A		C	2	1	(M)(O) May be inoperative provided: a) Associated door is secured full open, and b) Appropriate performance adjustments are applied. (Ref DDG)
-52-05B		C	2	1	(M)(O) May be inoperative provided: a) Associated door is verified closed, and b) Associated pack is not used.
-52-06	RAM AIR EXHAUST DOOR SYSTEMS				
-52-06-01	-200ER/300ER				
-52-06-01A		C	2	0	(M) May be inoperative provided associated door is secured full open.
-52-06-01B		C	2	1	(O) May be inoperative provided associated pack is not used.
-52-06-02	-200LR				
-52-06-02A		C	2	0	(M)(O) May be inoperative provided: a) Associated door is secured full open, and b) Appropriate performance adjustments are applied. (Refer DDG)
-52-06-02B		C	2	1	(O) One may be inoperative provided associated pack is not used.
-52-07	CONDENSER INLET TEMPERATURE CONTROL SYSTEMS	C	2	1	(M)(O) One may be inoperative provided: a) Associated condenser low limit valve is locked open, b) Opposite pack operates normally, c) Both engine bleed system operates normally, and d) Appropriate performance adjustments are applied. (Ref DDG)
-52-08	LOWER LOBE ATTENDANT REST (LLAR) DUCT TEMPERATURE SENSORS (IF INSTALLED) (AP-BMG & BMH)				
-52-08A		D	2	1	
-52-08B		C	2	0	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-17 (PIA Rev 23) Sep, 2023
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES	
-61-01	CABIN TEMPERATURE CONTROLLERS (CTC)		
-61-01-01	-200ER (WITHOUT PRR 61980 OR PRODUCTION EQUIVALENT INCORPORATED)		NOT APPLICABLE AS PRR 61980 IS INCORPORATED ON 777 FLEET (Refer Sub item -61-01-03)
-61-01-02	-300 (WITHOUT PRR 61980 OR PRODUCTION EQUIVALENT INCORPORATED)		NOT APPLICABLE
-61-01-03	-200ER (WITH PRR 61980 OR PRODUCTION EQUIVALENT INCORPORATED)	C 2 1	(M)(O) One may be inoperative provided: a) Associated pack is not used, b) Opposite pack operates normally, c) Both engine bleed system operates normally, d) Both outflow valves operate normally, e) Flight remains within 60 minutes of landing at a suitable airport, f) Appropriate performance adjustments are applied (Ref DDG), g) For the right CTC inoperative, electrical power on the right AC Transfer Bus is verified before each departure, and h) For FCAC installed and right CTC inoperative, FCAC remains OFF.
-61-01-04	-200LR/300ER	C 2 1	(M)(O) One may be inoperative provided: a) Associated pack is not used, b) Opposite pack operates normally, c) Both engine bleed system operates normally, d) Both outflow valves operate normally, e) Flight remains within 60 minutes of landing at a suitable airport, f) Appropriate performance adjustments are applied (Ref DDG), and g) For the right CTC inoperative, electrical power on the right AC Transfer Bus is verified before each departure.
-61-01-05	777F		NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-18 (PIA Rev 23) Sep, 2023
---	--	---

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-61-01-06	ALL				Deleted in MMEL Rev 23
-61-02	FLIGHT DECK ZONE TEMPERATURE CONTROL SYSTEM				
-61-02-01	PASSENGER	C	1	0	May be inoperative provided left trim air switch remains OFF.
-61-02-01-01	AUTO MODE	C	1	0	(M) May be inoperative provided MAN control mode is verified to operate normally.
-61-02-02	777F				NOT APPLICABLE
-61-03	CABIN ZONE TEMPERATURE CONTROL SYSTEMS (PASSENGER)				
-61-03A		C	6	0	(M) May be inoperative provided associated zone trim air modulation valve is deactivated closed.
-61-03B		C	6	0	(O) May be inoperative with the associated zone trim air modulation valve in any position provided: a) Associated trim air switch remains OFF, and b) For FCAC installed and right trim air switch selected OFF, FCAC remains OFF.(-200ER)
-61-04	CABIN TEMPERATURE CONTROL (PASSENGER)	C	1	0	
-61-05	FCAC DUCT TEMPERATURE SENSING SYSTEM (-200ER)				
-61-05-01	PASSENGER	D	1	0	(M) May be inoperative provided: a) Forward cargo zone trim air modulation valve is deactivated closed, and b) FCAC remains OFF.
-61-05-02	777F				NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-19 (PIA Rev 23) Sep, 2023
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-61-06	FCAC CARGO COMPARTMENT TEMPERATURE SENSING SYSTEM (-200ER)				
-61-06-01	PASSENGER	D	1	0	May be inoperative provided FCAC remains OFF.
-61-06-02	777F				NOT APPLICABLE
-61-07	FCAC CARGO ZONE TRIM AIR MODULATION VALVE (-200ER)				
-61-07-01	PASSENGER	D	1	0	(M) May be inoperative provided: a) Valve is deactivated closed, and b) FCAC remains OFF.
-61-07-02	777F				NOT APPLICABLE
-61-08	FCAC CARGO TEMPERATURE CONTROL (-200ER)				
-61-08-01	PASSENGER	D	1	0	(M) May be inoperative provided: a) FCAC shutoff valve is deactivated closed, and b) FCAC remains OFF.
-61-08-02	777F				NOT APPLICABLE
-61-09	ACAC DUCT TEMPERATURE SENSING SYSTEM (777F)				NOT APPLICABLE
-61-10	ACAC CARGO COMPARTMENT TEMPERATURE SENSING SYSTEM (777F)				NOT APPLICABLE
-61-11	ACAC CARGO ZONE TRIM AIR MODULATION VALVE (777F)				NOT APPLICABLE
-61-12	ACAC CARGO TEMPERATURE CONTROL (777F)				NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-20 (PIA Rev 23) Sep, 2023
---	--	---

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES
-------------	--------------------------------

-61-13	MDAC DUCT TEMPERATURE SENSING SYSTEM (777F)				NOT APPLICABLE
-61-14	MDAC CARGO COMPARTMENT TEMPERATURE SENSING SYSTEM (777F)				NOT APPLICABLE
-61-15	MDAC CARGO ZONE TRIM AIR MODULATION VALVES (777F)				NOT APPLICABLE
-61-16	MDAC CARGO TEMPERATURE CONTROLS (777F)				NOT APPLICABLE
-61-17	EQUIPMENT COOLING DUCT TEMPERATURE SENSING SYSTEM (777F)				NOT APPLICABLE
-61-18	EQUIPMENT COOLING TRIM AIR MODULATION VALVE (777F)				NOT APPLICABLE
-61-19	SUPERNUMERARY DUCT TEMPERATURE SENSING SYSTEM (777F)				NOT APPLICABLE
-61-20	SUPERNUMERARY ZONE TRIM AIR MODULATION VALVE (777F)				NOT APPLICABLE
-61-21	SUPERNUMERARY TEMPERATURE CONTROL (777F)				NOT APPLICABLE
-62-01	TRIM AIR CONTROL SYSTEMS				
-62-01-01	PASSENGER				
-62-01-01A		C	2	1	(O) May be inoperative provided: a) Associated trim air switch remains OFF, and b) For FCAC installed and right trim air switch selected OFF, FCAC remains OFF.(-200ER)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 21: AIR CONDITIONING	21-21 (PIA Rev 23) Sep, 2023
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-62-01-01B	C	2	0	(O) May be inoperative provided: a) Both trim air switches remain OFF, b) Both packs operate normally, and c) For FCAC installed, FCAC remains OFF. (-200ER)	
-62-01-02 777F				NOT APPLICABLE	
-62-02 TRIM AIR PRESSURE REGULATING/SHUTOFF VALVES (PRSOVs)					
-62-02-01 PASSENGER					
-62-02-01A	C	2	1	(M)(O) One may be inoperative provided: a) Associated valve is locked closed, and b) For FCAC installed and right trim air PRSOV is locked closed, FCAC remains OFF. (-200ER)	
-62-02-01B	C	2	0	(M)(O) May be inoperative provided: a) Both valves are locked closed, b) Both packs operate normally, and c) For FCAC installed, FCAC remains OFF. (-200ER)	
-62-02-02 777F				NOT APPLICABLE	
-62-03 TRIM AIR SWITCH LIGHTS					
-62-03-01 FAULT LIGHTS	C	2	0		
-62-03-02 ON LIGHTS	C	2	0		
-71-01 FLIGHT DECK HUMIDIFICATION SYSTEM				NOT APPLICABLE	
-73-01 OZONE CONVERTERS					
-73-01-01 PASSENGER	C	2	0		
-73-01-02 777F				NOT APPLICABLE	

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES	
-11-01	AUTOPILOT FLIGHT DIRECTOR COMPUTERS (AFDC)		Note 1: For CAT III B approaches, all three (3) must be serviceable. Note 2: One must be serviceable for RVSM operations.
	-11-01A	C 3 2	(M)(O) One may be inoperative provided: a) Associated AFDC is deactivated, b) Associated AFDC backdrive actuator is deactivated, and c) Approach minimums do not require use of the associated autopilot.
	-11-01B	C 3 1	(M)(O) Centre and one other AFDC may be inoperative provided: a) Associated AFDC is deactivated, b) For left or right AFDC inoperative, the associated AFDC backdrive actuator is deactivated, c) Radio Altimeters associated with the operative AFDC operates normally, d) Both flap/slat control lanes operate normally, e) All warning electronics system channels operate normally, and f) Approach minimums do not require use of the autopilots.
	-11-01C	B 3 0	(M)(O) May be inoperative provided: a) All AFDCs are deactivated, b) Both AFDC backdrive actuator are deactivated, c) Approach minimums do not require use of the autopilots, d) Number of flight segments and segment duration is acceptable to flight crew, and e) Enroute operations do not require use of the autopilots.

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-11-02	AUTOPILOT BACKDRIVE ACTUATOR SYSTEMS				Note : For CAT III B approaches, both must be serviceable.
-11-02A	C	2	1	(M)(O) One may be inoperative provided: a) Associated AFDC backdrive actuator is deactivated, b) Opposite AFDC operates normally, and c) Approach minimums do not require use of the associated autopilot.	
-11-02B	B	2	0	(M)(O) May be inoperative provided: a) Both AFDC backdrive actuators are deactivated, b) Approach minimums do not require use of the autopilots, c) Number of flight segments and segment duration is acceptable to flight crew, and d) Enroute operations do not require use of the autopilots.	
-11-03	AUTOPILOT MODE CONTROL PANEL LANES	C	2	1	Note : For CAT III B approaches, both must be serviceable.
-11-04	MODE CONTROL PANEL WINDOWS				Note : For CAT III B approaches, all must be serviceable.
-11-04-01	AIRSPEED (IAS-MACH)	C	1	0	May be inoperative provided selected airspeed indications on both PFDs operate normally.
-11-04-02	HEADING (HDG-TRK)	C	1	0	May be inoperative provided selected heading indications on both PFDs operate normally.
-11-04-03	VERTICAL SPEED (V/S-FPA)	C	1	0	May be inoperative provided selected vertical speed indications on both PFDs operate normally.
-11-04-04	ALTITUDE (ALTITUDE)	C	1	0	May be inoperative provided selected altitude indications on both PFDs operate normally.
-11-04-05	WINDOW LIGHTING	B	1	0	May be inoperative provided: a) Selected airspeed indications on both PFDs operate normally, b) Selected heading indications on both PFDs operate normally, c) Selected vertical speed indications on both PFDs operate normally, and d) Selected altitude indications on both PFDs operate normally.

PIA 777-240 ER/LR-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 22: AUTOFLIGHT	22-3 (PIA Rev 05) NOVEMBER, 2015
--	--	-------------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES	
-11-05	MODE CONTROL PANEL SELECTORS			Note : For CAT III B approaches, all must be serviceable.
-11-05-01	V/S – FPA SELECTOR (DOWN & UP)	C	1	0
-11-05-02	BANK LIMIT SELECTOR (AUTO 5,10,15,20,25)	C	1	0
-11-05-03	ALTITUDE INCREMENT SELECTOR (AUTO, 1000)	C	1	0
-11-05-04	SELECTOR PUSH FUNCTIONS			(O) May be inoperative provided selector is verified to be in AUTO position.
-11-05-04-01	IAS–MACH	C	1	0
-11-05-04-02	HDG-TRK SEL	C	1	0
-11-05-04-03	ALTITUDE	C	1	0
-11-06	MODE CONTROL PANEL SWITCHES			Note : For CAT III B approaches, all must be serviceable.
-11-06-01	A/P ENGAGE SWITCHES			
-11-06-01A		C	2	1
-11-06-01B		B	2	0
				(O) May be inoperative provided: a) Approach minimums do not require use of the autopilots, b) Number of flight segments and segment duration is acceptable to flight crew, and c) Enroute operations do not require use of the autopilots.

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES			
-11-06 MODE CONTROL PANEL SWITCHES (Continued...)				
-11-06-02 AUTO THROTTLE ARM SWITCHES (A/T ARM L,R)				
-11-06-02-01 PW & RR				NOT APPLICABLE
-11-06-02-02 GE -11-06-02-02A	C	2	1	(M)(O) One may be inoperative provided: a) Associated servo motor is deactivated, b) EEC normal mode operates normally, c) Both Thrust levers are manually set for takeoff and go-around thrust, and d) Flight remains within 180 minutes of landing at a suitable airport.
-11-06-02-02B	C	2	0	May be inoperative provided: a) EEC normal mode operates normally, b) Approach minimums do not require auto throttle use, and c) Flight remains within 180 minutes of landing at a suitable airport.
-11-06-03 A/T ENGAGE SWITCH				
-11-06-03-01 PW & RR				NOT APPLICABLE
-11-06-03-02 GE	C	1	0	May be inoperative provided: a) EEC normal mode operates normally b) Approach minimums do not require auto throttle use, and c) Flight remains within 180 minutes of landing at a suitable airport.
-11-06-04 F/D SWITCHES	C	2	0	May be inoperative provided approach minimums do not require flight director use.
-11-06-05 IAS – MACH REFERENCE SWITCH	C	1	0	May be inoperative provided IAS is displayed in associated window.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 22: AUTOFLIGHT	22-5 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-11-06-06	HDG – TRK REFERENCE SWITCH	C	1	0	May be inoperative provided HDG is displayed in associated window.
-11-06-07	V/S – FPA REFERENCE SWITCH	C	1	0	
-11-06-08	APP SWITCH	C	1	0	May be inoperative provided approach minimums do not require use of the autopilot flight director system approach mode.
-11-06-09	CLB CON, LNAV, VNAV, FLCH, VS/FPA, HEADING/TRACK HOLD ALTITUDE HOLD AND LOC SWITCHES	C	8	0	May be inoperative provided enroute operations do not require their use. Note: Altitude Hold must be serviceable for RVSM operations.
-11-06-10	ARM/ENGAGE LIGHTS	C	11	0	May be inoperative provided the associated mode indications on both PFDs operate normally.
-11-07	AUTOMATIC LANDING SYSTEM (AUTOLAND)	C	1	0	May be inoperative provided approach minimums do not require its use.
-11-07-01	TRIPLE CHANNEL AUTO LAND (LAND 3)	C	1	0	May be inoperative provided approach minimums do not require its use.
-11-08	CONTROL WHEEL AUTOPILOT DISCONNECT SWITCHES				Note : For CAT III B approaches, both must be serviceable.
-11-08A		C	2	1	One may be inoperative provided: a) Autopilot is not used at 1,500 feet AGL, or below, and b) Approach minimums do not require the use of the autopilot.
-11-08B		B	2	0	May be inoperative provided: a) Autopilot is not used, b) Approach minimums do not require use of the autopilot, c) Number of flight segments and segment duration is acceptable to flight crew, and d) Enroute operations do not require use of the autopilot.

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES		
-11-09 TAKEOFF/GO-AROUND (TO/GA) SWITCHES			Note 1 : For CAT III B approaches, both must be serviceable. Note 2: Flight director go-around and windshear guidance are not available with both TO/GA switches inoperative.
-11-09A	C	2	1
-11-09B	C	2	0
-11-10 FLIGHT DIRECTOR SYSTEMS			Note : For CAT III B approaches, both must be serviceable.
	C	2	0
-31-01 AUTO THROTTLE SYSTEM			Note1 : For CAT III B approaches, must be serviceable.
-31-01-01 PW AND RR			Note2: Any autothrottle mode which operates normally may be used.
-31-01-02 GE	C	1	0
-31-02 AUTO THROTTLES SERVO MOTORS			NOT APPLICABLE
-31-02-01 PW AND RR			NOT APPLICABLE
-31-02-02 GE			
-31-02-02A	C	2	1
			(M)(O) One may be inoperative provided:
			a) EEC normal mode operates normally,
			b) Associated servo motor is deactivated,
			c) Both thrust levers are manually set for takeoff and go-around thrust, and
			d) Flight remains within 180 minutes of landing at a suitable airport.


 06 MAY 2019

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 22: AUTOFLIGHT	22-7 (PIA Rev 05) NOVEMBER, 2015
---	--	-------------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-31-02-02B	C	2	0	(M)(O) May be inoperative provided: a) EEC normal mode operates normally, b) Both servo motors are deactivated, c) Approach minimums do not require use of the autothrottles, and d) Flight remains within 180 minutes of landing at a suitable airport
-31-03 AUTO THROTTLE DISCONNECT SWITCHES				Note : For CAT III B approaches, both must be serviceable.
-31-03-01 PW AND RR				NOT APPLICABLE
-31-03-02 GE -31-03-02A	C	2	1	One may be inoperative provided both A/T ARM switches operate normally.
-31-03-02B	C	2	0	May be inoperative provided: a) EEC normal mode operates normally, b) Autothrottles are not armed, c) Approach minimums do not require use of autothrottles, and d) Flight remains within 180 minutes of landing at a suitable airport.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 23: COMMUNICATIONS	23-1 (PIA Rev 23) Sep , 2023
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-11-01	HIGH FREQUENCY (HF) COMMUNICATIONS SYSTEM				
-11-01A	D	2	0	Both may be inoperative if VHF continuous coverage is assured.	
-11-01B	C	2	1	(O) May be inoperative while conducting operations that require two LRCS provided:	
				a) Aircraft SATVOICE system operates normally, b) SATVOICE services are available as a LRCS over the intended route of flight, c) The ICAO Flight Plan is updated (as required) to notify ATC of the communications equipment status of the aircraft, and d) Use SATCOM voice communication procedure.	
-11-01-01	HF DATA LINK (200LR/300ER)				
-11-01-01A	C	1	0	(O) May be inoperative provided VHF DATALINK or SATCOM DATALINK is operative.	
-11-01-01B	D	1	0	May be inoperative provided procedures do not require its use.	
-12-01	VHF COMMUNICATIONS SYSTEMS	D	3	2	a) Except for ER operations one VHF may be inoperative, and b) Left system must be operative. Remaining systems may be inoperative at enroute stations if one HF is operative and continuous HF coverage is assured.
-12-01-01	VHF DATA LINK				
-12-01-01A	C	1	0	(O) May be inoperative provided HF DATA LINK or SATCOM DATA LINK for (200LR & 300ER) and SATCOM DATA LINK for 200ER is operative.	
-12-01-01B	D	1	0	May be inoperative provided procedures do not require its use.	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 23: COMMUNICATIONS	23-2 (PIA Rev 11) MAR , 2019
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES	
-15-01	SATELLITE COMMUNICATIONS (SATCOM) SYSTEMS		
-15-01A			NOT APPLICABLE
-15-01B	C	1	0
			(O) May be inoperative provided:
			a) ARINC or BERNAL radio is used for phone patch facility, and
			b) Flight remains within 180 minutes of landing at a suitable airport.
-15-01C	D	1	0
			May be inoperative provided procedures do not require its use.
-15-01D		1	1
			Must be serviceable for CPDLC operations.
-15-01-01	SATCOM VOICE SYSTEMS		
-15-01-01A	C	1	0
			(O) May be inoperative provided:
			a) ARINC or BERNAL radio is used for phone patch facility, and
			b) Flight remains within 180 minutes of landing at a suitable airport.
-15-01-01B	D	1	0
			May be inoperative provided procedures do not require its use.
-15-01-02	SATCOM DATA LINK		
-15-01-02A	C	1	0
			(O) May be inoperative provided VHF DATA LINK or HF DATA LINK is operative for (-200LR/-300ER) and VHF DATA LINK is operative for (-200ER).
-15-01-02B	D	1	0
			May be inoperative provided procedures do not require its use.
-15-02	AUTOMATED FLIGHT INFORMATION REPORTING SYSTEM (AFIRS) (STC ST03079NY)		
			NOT APPLICABLE
-21-01	SELECTIVE CALL SYSTEM (SELCAL)	C	1
			0
			(O) May be inoperative provided VHF or HF radio is monitored for duration of flight.
-24-01	RADIO TUNING PANELS	C	3
			2
			One may be inoperative provided left radio tuning panel operates normally.
			NOTE: Any function that operates normally may be used.
-24-02	EMERGENCY LOCATOR TRANSMITTER (ELT) (FIXED)	1	1

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 23: COMMUNICATIONS	23-3 (PIA Rev 23) Sep , 2023
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES			
-24-03	LOW FREQUENCY UNDERWATER LOCATING DEVICE (LF-ULD)				Dispatch relief for this equipment moved to item 23-25-01 in MEL Rev 23
-24-04	AIRCRAFT AUTONOMOUS DISTRESS TRACKING (ADT) SYSTEM				NOT APPLICABLE
-25-01	LOW FREQUENCY UNDERWATER LOCATING DEVICE (LF-ULD)				
-25-01A		D	1	0	May be inoperative or missing provided operations do not require its use.
-25-01B		C	1	0	May be inoperative or missing.
-27-01	DATA COMMUNICATION MANAGEMENT SYSTEM				
-27-01A		C	1	0	(O) May be inoperative provided: a) Data mode is not used for radio tuning, and b) Flight remains within 180 minutes of landing at a suitable airport.
-27-01B		C	1	0	(O) May be inoperative provided: a) Data mode is not used for radio tuning, and b) SATCOM voice operates normally.
-27-01-01	AUTOMATIC DEPENDENT SURVEILLANCE CONTRACT (ADS-C) FUNCTION	C	1	0	(O) May be inoperative provided data mode is not used for radio tuning.
-27-01-02	ACPT/CANC /RJCT SWITCH LIGHTS	C	6	0	
-27-02	FLIGHT DECK COMMUNICATIONS SYSTEM (ACARS DATA LINK)				
-27-02A		C	1	0	(O) May be inoperative provided: a) VHF, HF communication is used, and b) Flight remains within 180 minutes of landing at a suitable airport.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 23: COMMUNICATIONS	23-4 (PIA Rev 23) Sep , 2023
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES		
-27-02B	C	1	0	(O) May be inoperative provided: a) VHF, HF Communication is used, and b) SATCOM voice operates normally.
-27-02C	D	1	0	May be inoperative provided procedures do not require its use.
-27-02-01 ATC DATABASE				
-27-02-01A	C	2	0	(O) May be inoperative provided: a) VHF, HF Communication is used, and b) SATCOM voice operates normally.
-27-02-01B	D	2	0	May be inoperative provided procedures do not require its use.
-31-01 PASSENGER ADDRESS SYSTEM (PASSENGER)	B	1	0	(O) May be inoperative provided: a) Megaphones are used by cabin attendant, and b) Flight attendant chime and call lights operate normally. NOTE: Any passenger address function that operates normally may be used.
-31-01-01 PASSENGER ADDRESS CONTROLLER MODES	C	2	1	(M) One may be inoperative provided operating controller mode is selected.
-31-01-02 LAVATORY SPEAKERS	C	12	0	Lavatory to be manned by Cabin Attendant.
-31-01-03 CABIN SPEAKERS				
-31-01-03A	C	63	31	(M) May be inoperative provided inoperative speakers are not adjacent to each other.
-31-01-03B	C	63	31	(M) No passenger seat, cabin crew member seat or crew rest area bunk may be occupied from which passenger address system is not audible and intelligible; seat must be blocked and placarded DO NOT OCCUPY.
-31-01-04 AMBIENT NOISE SENSOR (ANS) SYSTEM				NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 23: COMMUNICATIONS	23-5 (PIA Rev 23) Sep , 2023
---	--	---------------------------------

STANDARD EQUIPMENT	MINIMUM FOR DISPATCH
ITEM	SUPPLEMENTAL PROCEDURES

-31-01-05 PRE-RECORDED PASSENGER ANNOUNCEMENT SYSTEM				
-31-01-05A				
	C	1	0	(O) May be inoperative provided announcements are made by cabin attendant.
-31-01-05B	D	1	0	May be inoperative provided procedures do not require its use.
-31-02 PERSONNEL ADDRESS SYSTEM (777F)				NOT APPLICABLE
-39-01 CABIN AREA CONTROL PANELS (CACP)/CABIN SYSTEM CONTROL PANEL (CSCP) (PASSENGER)	C	2	1	NOTE: Any CACP/CSCP function that operates normally may be used.
-41-01 SERVICE INTERPHONE SYSTEM				
-41-01-01 NOSE GEAR JACK				
-41-01-01A	C	1	0	(O) Service interphone flight deck to ground/ground to flight deck function may be inoperative provided: a) Nose gear flight interphone jack operates normally, and b) Flight Interphone System is used.
-41-01-01B	B	1	0	(O) Other than nose gear jacks, are used.
-41-01-02 OTHER THAN NOSE GEAR JACKS (200ER/200LR&300ER)	D	13/ 14	0	May be inoperative provided procedures do not require its use.
-42-01 CABIN INTERPHONE SYSTEMS (PASSENGER)				
-42-01-01 FLIGHT DECK TO CABIN, CABIN TO FLIGHT DECK, FUNCTIONS				
-42-01-01 A	B	8/ 11/ 10/ 13	4/ 6/ 5/ 7	(O) May be inoperative provided: a) Flight deck to cabin and cabin to flight deck interphone functions operate normally on at least fifty percent of the cabin handsets,
200ER=8/ AP-BMG & H =11/ 200LR & 300ER= 10/ AP-BMS=13				(Continued...)

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH
ITEM
SUPPLEMENTAL PROCEDURES

				b) Flight deck to cabin and cabin to flight deck interphone functions operate normally on at least one handset per exit door pair, and c) PA system is used for communication, between affected flight attendants station(s) and flight deck. NOTE: Any cabin interphone function that operates normally may be used.
-42-01-01 B	C	1	0	(O) May be inoperative provided: a) Crewmember interphone system is not required. b) PA system is used for communication, between affected flight attendants station(s) and flight deck. NOTE: Any cabin interphone function that operates normally may be used.
-42-01-02 CABIN TO CABIN FUNCTIONS	B	10	0	(O) May be inoperative provided: a) Cabin to cabin interphone functions operate normally on at least fifty percent of the cabin handsets, b) Cabin to cabin interphone functions operate normally on at least one handset per exit door pair, and c) PA system is used for communications with affected flight attendants station(s). NOTE: Any cabin interphone function that operates normally may be used.
-42-01-03 FLIGHT DECK/CABIN TO CREW REST, CREW REST TO FLIGHT DECK/CABIN, FUNCTIONS APBMG&BMH (IF INSTALLED) =(2/10)/ -200LR=(2/9)/ BMS=(2/11)	B	(2/10) (2/9) (2/11)	0	(O) May be inoperative provided communication can be established via other cabin crew station. NOTE: Any cabin interphone function that operates normally may be used.
-42-01-04 CABIN INTERPHONE CONTROLLER MODES	C	2	1	(M) One may be inoperative provided operating controller mode is selected.
-42-02 CABIN INTERPHONE ALERTING SYSTEMS (PASSENGER) -42-02-01 FLIGHT DECK CALL SYSTEM				

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 23: COMMUNICATIONS	23-7 (PIA Rev 23) Sep , 2023
---	--	---------------------------------

STANDARD EQUIPMENT				MINIMUM FOR DISPATCH	
ITEM		SUPPLEMENTAL PROCEDURES			
-42-02-01-01 LIGHTS AND EICAS MESSAGES	B	1	0	(O) May be inoperative provided: a) Flight deck chime operates normally, and b) Alternate procedures are discussed before the flight and used to differentiate between normal and emergency calls.	
-42-02-01-02 FLIGHT DECK CHIME	B	1	0	May be inoperative provided flight deck call lights and EICAS messages operate normally.	
-42-02-02 FLIGHT ATTENDANT CALL LIGHTS (BMS/EXCEPT BMS) -42-02-02A	B	13/11	0	(O) May be inoperative provided: a) PA system operates normally, and b) PA system is used for contacting flight attendants. NOTE 1: Passenger to attendant call system is considered a Non-Essential Equipment and Furnishings (NEF) item. NOTE 2: Any visual alerting system function(s) that operates normally may be used.	
-42-02-02B	B	13/11	0	(O) May be inoperative provided: a) Flight attendant chime operates normally, and b) PA system is used for contacting flight attendants. NOTE 1: Passenger to attendant call system is considered a Non-Essential Equipment and Furnishings (NEF) item. NOTE 2: Any visual alerting system function(s) that operates normally may be used.	
-42-02-03 FLIGHT ATTENDANT CHIME -42-02-03A	B	1	0	(O) May be inoperative provided: a) PA system operates normally, and b) PA system is used for contacting flight attendants. NOTE 1: Passenger to attendant call system is considered a Non-Essential Equipment and Furnishings (NEF) item. NOTE 2: Any audio alerting system function(s) that operates normally may be used.	
-42-02-03B	B	1	0	(O) May be inoperative provided: a) Flight attendant call lights operate normally, and b) PA system is used for contacting flight attendants.	

(Continued)

(Continued...)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 23: COMMUNICATIONS	23-8 (PIA Rev 23) Sep , 2023
---	--	---------------------------------

STANDARD EQUIPMENT	MINIMUM FOR DISPATCH
ITEM	SUPPLEMENTAL PROCEDURES

					NOTE 1: Passenger to attendant call system is considered a Non-Essential Equipment and Furnishings (NEF) item. NOTE 2: Any audio alerting system function(s) that operates normally may be used.
-42-02-04	CREW REST CALL LIGHTS / CHIMES SYSTEM (APBMG & BMH (IF INSTALLED), BMS & 200LR)	B	2	0	(O) May be inoperative: a) Associated crew rest cabin interphone handset system operates normally, and b) PA system is used for contacting flight attendants.
42-03	CABIN INTERPHONE HANDSET SYSTEMS (PASSENGER)				NOTE: Any alerting system function that operates normally may be used.
-42-03-01	FLIGHT DECK				
-42-03-01A		C	1	0	(O) May be inoperative provided: a) Flight deck to cabin communication operates normally, and b) PA system is used for communication.
-42-03-01B		D	1	0	Maybe inoperative provided procedures do not require its use.
-42-03-02	CABIN 200ER & LR=9/ 300ER=11	B	9/ 11	5/ 6	(O) May be inoperative provided: a) Fifty percent of cabin handsets operate normally, b) One handset must operate normally at each pair of exit doors, and c) PA system is used for communications with the affected flight attendant station(s).
					NOTE 1: An operative handset at an inoperative flight attendant seat shall not be counted to satisfy the fifty percent requirement.
					NOTE 2: Any handset function that operates normally may be used.
-42-03-03	CREW RESTS AP-BMG & BMH (IF INSTALLED)=1/ BMS &200LR=2	C	1/2	0	(O) PA system is used for communicating with the effected Crew Rests.
-43-01	GROUND CREW CALL SYSTEM	C	1	0	(O) May be inoperative provided, use of landing/Taxi lights or visual contact to be established and used with ground engineer.
-45-01	CREW COMMUNICATION SYSTEM (777F)				NOT APPLICABLE
-45-02	CREW COMMUNICATION ALERTING SYSTEMS(777F)				NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 23: COMMUNICATIONS	23-9 (PIA Rev 11A) SEP , 2019
---	--	----------------------------------

STANDARD EQUIPMENT	MINIMUM FOR DISPATCH
ITEM	SUPPLEMENTAL PROCEDURES

-46-01	CARGO INTERPHONE/ INTERCOM SYSTEM (777F)					NOT APPLICABLE
-51-01	FLIGHT INTERPHONE SYSTEM					
-51-01-01	NOSE GEAR JACK					
-51-01-01A		C	1	0		(O) Flight interphone flight deck to ground/ground to flight deck function may be inoperative provided: a) Nose gear service interphone jack operates normally, and b) Use of landing/Taxi lights or visual contact to be established and used with ground engineer.
-51-01-01B		B	1	0		(O) May be inoperative provided; a) Nose gear service interphone jack operates normally, and b) Use of landing/Taxi lights or visual contact to be established and used with ground engineer.
-51-01-02	MAIN EQUIPMENT CENTER (MEC) JACKS	D	1	0		May be inoperative provided procedures do not require it use.
51-02	FLIGHT DECK SPEAKERS	C	2	0		May be inoperative provided: a) Procedures do not require their use, and b) Associated headset earphones or headphones are installed and operate normally.
-51-03	FLIGHT DECK HAND MICROPHONES					
-51-03A	(AP-BMG & BMH / ALL OTHER)	C	2/3	0		May be inoperative or missing provided associated boom microphone operates normally,
-51-03B	(AP-BMG & BMH / ALL OTHER)	D	2/3	0		May be inoperative or missing provided boom mike is used.
-51-04	FLIGHT DECK HEADSETS/ HEADPHONES	D	3	2		Any in excess of those required for each person on flight deck duty may be inoperative.
-51-04-01	HEADSET BOOM MICROPHONE					
-51-04-01A		A	3	0		May be inoperative provided: a) Associated hand microphone is installed and operates normally, and b) Repairs are made within three flight days.
-51-04-01B		D	3	2		Any in excess of those required for each person on flight deck duty may be inoperative.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 23: COMMUNICATIONS	23-10 (PIA Rev11A) SEP , 2019
---	--	-----------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-51-04	FLIGHT DECK HEADSETS/ HEADPHONES (Continued...)				
-51-04-02	HEADSET EARPHONES/ HEADPHONES (EXCEPT BMS/BMS)	C	3/5	1	Either Captain's or First Officer's earphone/ headphones may be inoperative provided associated flight deck speaker operates normally. NOT APPLICABLE
-51-04-02-01	ACTIVE NOISE CANCELLING /REDUCTION FUNCTION				
-51-05	AUDIO CONTROL PANELS				
-51-05-01	CAPTAIN'S AUDIO CONTROL PANEL	C	1	0	(O) May be inoperative provided first observer's audio control panel operates normally. NOTE: Any function that operates normally may be used.
-51-05-02	FIRST OBSERVER'S AUDIO CONTROL PANEL	A	1	0	May be inoperative provided: a) Captain's audio control panel operates normally, and b) Repairs are made within two flight days. NOTE: Any function that operates normally may be used. NOT APPLICABLE
-51-05-03	SECOND OBSERVER'S AUDIO CONTROL PANEL				
-51-05-04	MIC, CALL, Receiver Lights	C	30, 27, 39	0	Audio control panel lights may be inoperative provided procedures do not require its use.
-51-06	MICROPHONE (MIC) INTERPHONE SWITCHES				
-51-06-01	CONTROL WHEEL MIC/INTERPHONE SWITCHES	C	2	1	(M) One may be inoperative provided: a) Associated audio control panel MIC/Interphone switch operates normally, and b) Affected switch is deactivated open.
-51-06-02	FLIGHT CREW AUDIO CONTROL PANEL MIC/INTERPHONE SWITCHES	C	2	1	(M) One may be inoperative provided: a) Associated control wheel MIC/Interphone switch operates normally, and b) Affected switch is verified inoperative open.
-51-06-03	GLARESHIELD MIC/INTERPHONE SWITCHES	C	2	0	(M) May be inoperative provided the affected switch is deactivated open.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 23: COMMUNICATIONS	23-11 (PIA Rev 23) Sep , 2023
---	--	----------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES	
-70-01	FLIGHT DECK DOOR VISUAL SURVEILLANCE SYSTEMS (PASSENGER)		
-70-01A			NOT APPLICABLE
-70-02B	C	1	0
-70-01C			(O) May be inoperative provided: a) A flight deck door viewing port is installed and operates normally, and b) Cabin interphone operates normally and used. NOTE: Any Visual Surveillance System function that operates normally may be used. NOT APPLICABLE
-70-02	DIRECT VIEW CAMERA SYSTEM		NOT APPLICABLE
-70-03	CABIN VIDEO MONITORING SYSTEM (CVMS)		NOT APPLICABLE
-71-01	COCKPIT VOICE RECORDER (CVR) SYSTEM	1	1
-71-01-01	BACKUP BATTERY POWER		NOT APPLICABLE
-93-01	OVERHEAD PANEL BUS CONTROLLERS (OPBC)		
-93-01-01	PASSENGER		
-93-01-01-01	LEFT OPBC	B	1
-93-01-01-01			0
-93-01-01-02	RIGHT OPBC	B	1
-93-01-01-02			0
			(M)(O) May be inoperative provided: a) The right overhead panel ARINC 629 system (OPAS) is verified to operate normally before each departure, b) One air conditioning pack operates normally, c) Both auto cabin pressure controls operate normally, d) One center system hydraulic demand pump is selected ON for takeoff and landing, e) Left and right pitot and static air data modules operate normally, and f) Passenger information signs are considered inoperative. (M)(O) May be inoperative provided: a) The left overhead panel ARINC 629 system (OPAS) is verified to operate normally before each departure, b) One air conditioning pack operates normally, c) Both auto cabin pressure controls operate normally, and d) One center system hydraulic demand pump is selected ON for takeoff and landing.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 23: COMMUNICATIONS	23-12 (PIA Rev 23) Sep , 2023
---	--	----------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-93-01-02 777F				NOT APPLICABLE
-93-02 OVERHEAD PANEL INTERFACE CARDS (OPIC)				
-93-02A	C	4	3	One may be inoperative provided: a) One air conditioning pack operates normally, and b) Both centre system hydraulic demand pumps operate normally.
-93-02B	C	4	3	One may be inoperative provided: a) One air conditioning pack operates normally, and b) One centre system hydraulic demand pump is selected ON for takeoff and landing.
-93-03 PANEL DATA CONCENTRATOR UNITS (PDCU)	C	2	1	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 24: ELECTRICAL POWER	24-1 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-00-01	ELECTRICAL SYNOPTIC DISPLAY	C	1	0	
-00-02	IFE/PASS SEATS POWER SWITCH LIGHTS (PASSENGER)				
-00-02-01	OFF LIGHT	C	1	0	
-00-02-02	ON LIGHT	C	1	0	
-00-03	CABIN/UTILITY POWER SWITCH LIGHTS				
-00-03-01	OFF LIGHT	C	1	0	
-00-03-02	ON LIGHT	C	1	0	
-09-01	ELECTRICAL LOAD MANAGEMENT SYSTEM (ELMS) POWER MANAGEMENT CHANNELS				
-09-01-01	P110 CHANNELS	C	2	1	(M)(O) One channel may be inoperative provided: a) Remaining channel is verified to operate normally before the first flight of each day, and b) Forward centre-of-gravity remains within limits with the weight of center tank fuel added to airplane zero fuel weight.
-09-01-02	P210 CHANNELS	C	2	1	(M)(O) One channel may be inoperative provided: a) Remaining channel is verified to operate normally before the first flight of each day, and b) Forward centre-of-gravity remains within limits with the weight of center tank fuel added to airplane zero fuel weight.
-09-01-03	P310 CHANNELS	C	2	1	(M) One channel may be inoperative provided the remaining channel is verified to operate normally before the first flight of each day.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 24: ELECTRICAL POWER	24-2 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES
------	-------------------------

-11-01	ENGINE DRIVEN GENERATOR SYSTEMS (IDG, GCB)	B	2	1	(M)(O) One may be inoperative provided: a) Associated IDG is disconnected, b) APU driven generator operates normally and is used to supply buses of the inoperative channel throughout the flight, c) All generator control units, including the APU, are verified to operate normally, d) Backup AC power system is verified to operate normally before each departure, and e) Flight remains within 180 minutes of landing at a suitable airport.
-11-01-01	GEN CTRL SWITCH LIGHTS				
-11-01-01-01	OFF LIGHTS	C	2	0	
-11-01-01-02	ON LIGHTS	C	2	0	
-11-01-02	DRIVE DISC SWITCH DRIVE LIGHTS	C	2	0	
-11-02	INTEGRATED DRIVE GENERATOR (IDG) OIL PRESSURE INDICATION SYSTEMS	C	2	0	
-21-01	APU DRIVEN GENERATOR SYSTEM (GENERATOR, AGCU, APB)	C	1	0	(M)(O) May be inoperative provided: a) Procedures do not require use of the APU for electrical power, b) Auxiliary Power Breaker (APB) remains open, c) Both Engine driven generator systems operate normally, d) Backup AC power system is verified to operate normally before each departure, and e) Flight remains within 180 minutes of landing at a suitable airport. NOTE: APU may be used as a pneumatic source.
-21-01-01	APU GEN SWITCH LIGHTS				
-21-01-01-01	OFF LIGHT	C	1	0	
-21-01-01-02	ON LIGHT	C	1	0	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 24: ELECTRICAL POWER	24-3 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES
------	-------------------------

-22-01	RELAYS – AC				
-22-01-01	GROUND HANDLING	C	1	0	(M) May be inoperative provided the equipment on the Ground Handling Bus is deactivated before each departure.
-22-01-02	GROUND SERVICE SELECT	C	1	0	(M) Control of the relay may be inoperative provided the relay remains in the engine running position.
-22-01-03	GROUND SERVICE TRANSFER	C	1	0	(M) Control of the relay may be inoperative provided the relay remains in the engine running position.
-25-01	BACKUP ELECTRICAL POWER SYSTEM (BACKUP GENERATORS, CONVERTOR AND CCBS)				
-25-01A		C	1	0	May be inoperative provided: a) Both engine driven generators operate normally, and b) APU generator operates normally.
-25-01B		C	1	0	(M) May be inoperative provided: a) One backup generator is removed and an appropriate dispatch kit is installed, b) Both engine driven generators operate normally, and c) APU generator operates normally.
-25-01-01	BACKUP GEN SWITCH LIGHTS				Dispatch relief for this item moved to 24-11-01-01
-25-01-01-01	OFF LIGHTS	C	2	0	
-25-01-01-02	ON LIGHTS	C	2	0	
-28-01	BUS TIE SWITCH LIGHTS				
-28-01-01	ISLN LIGHTS	C	2	0	
-28-01-02	AUTO LIGHTS	C	2	0	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 24: ELECTRICAL POWER	24-4 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES
------	-------------------------

-31-01	APU BATTERY				
-31-01A	C	1	0	(O) May be inoperative provided APU is started before departure and is operated for the entire flight.	
-31-01B	C	1	0	(O) May be inoperative provided: a) Other procedures do not require use of the APU, b) Backup AC power system is verified to operate normally before each departure, and c) Flight remains within 180 minutes of landing at a suitable airport.	
-31-01C	C	1	0	(M)(O) May be inoperative removed provided: a) APU battery charger is deactivated, b) Other procedures do not require use of the APU, c) Backup AC power system is verified to operate normally before each departure, and d) Flight remains within 180 minutes of landing at suitable airport.	
-31-02	APU BATTERY CHARGER				
-31-02A	C	1	0	(M)(O) May be inoperative provided: a) APU battery charger is deactivated, and b) APU is started before departure and is operated for the entire flight.	
-31-02B	C	1	0	(M)(O) May be inoperative provided: a) Other procedures do not require use of the APU, b) Backup AC power system is verified to operate normally before each departure, c) APU Battery charger is deactivated, and d) Flight remains within 180 minutes of landing at a suitable airport.	
-31-03	BATTERY SWITCH LIGHTS				
-31-03-01 OFF LIGHT	C	1	0		
-31-03-02 ON LIGHT	C	1	0		

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 24: ELECTRICAL POWER	24-5 (PIA Rev 23) Sep, 2023
---	--	--

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES
-------------	--------------------------------

-41-01	EXTERNAL POWER SYSTEMS	C	2	0	
-41-01-01	AVAIL LIGHTS (FLIGHT DECK)	C	2	0	(O) May be inoperative provided, Cockpit crew to confirm from ground crew that on external power panel, the corresponding power (Primary/Secondary) "NOT IN USE" lights are OFF and "CONNECTED" lights are ON.
-41-01-02	ON LIGHTS (FLIGHT DECK)	C	2	0	(O) May be inoperative provided, Cockpit crew to confirm from ground crew that on external power panel, the corresponding power (Primary/Secondary) "NOT IN USE" lights are OFF and "CONNECTED" lights are ON.
-41-01-03	EXTERNAL POWER CONNECTED LIGHTS (EXTERNAL POWER PANEL)	C	2	0	(O) May be inoperative provided, Cockpit crew to confirm from ground crew that on external power panel, the corresponding power (Primary/Secondary) "NOT IN USE" lights are OFF and "CONNECTED" lights are ON.
-41-01-04	EXTERNAL POWER NOT IN USE LIGHTS (EXTERNAL POWER PANEL)	C	2	0	(O) May be inoperative provided, Cockpit crew to confirm from ground crew that on external power panel, the corresponding power (Primary/Secondary) "NOT IN USE" lights are OFF and "CONNECTED" lights are ON.
-41-02	BUS POWER CONTROL UNIT	C	1	0	
-61-01	GROUND HANDLING TRANSFORMER RECTIFIER UNIT	C	1	0	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 25: EQUIPMENT/FURNISHINGS	25-1 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES
------	-------------------------

-11-01	FLIGHT CREW SEATS				
-11-01-01	POWER ADJUSTMENT SYSTEMS	D	2	0	(M) May be inoperative provided inoperative powered adjustment system(s) is deactivated.
-11-01-01-01	POWERED LUMBAR				NOT APPLICABLE
-11-01-02	MANUAL ADJUSTMENT SYSTEMS				
-11-01-02-01	RECLINE SYSTEMS	A	2	0	(M) May be inoperative provided: a) Seat is secured in an upright position acceptable to the affected crew member, and b) Repairs are made within two flight days.
-11-01-02-02	VERTICAL ADJUSTMENTS				
-11-01-02-02A		A	2	0	May be inoperative provided: a) Seat is acceptable to the affected crewmember, and b) Repairs are made within two flight days.
-11-01-02-02B		C	2	0	May be inoperative provided associated vertical powered adjustment system operates normally.
-11-01-02-03	ARMRESTS	B	4	0	(M) May be inoperative provided: a) Affected armrest is stowed in the retracted position or removed, and b) Seat is acceptable to affected crewmember.
-11-01-02-04	LUMBAR / THIGH SUPPORTS	C	4	0	May be inoperative provided seat is acceptable to the affected crewmember.
-11-01-02-05	HEADRESTS	C	2	0	May be inoperative provided seat is acceptable to the affected crewmember.
-11-01-02-06	SEAT PAN TILT				NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 25: EQUIPMENT/FURNISHINGS	25-2 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-11-01-02-07 ARMREST EXTENSIONS				NOT APPLICABLE
-11-01-02-08 THAIGH SUPPORT EXTENSIONS				NOT APPLICABLE
-11-02 OBSERVER SEAT(S)				
-11-02-01 FIRST OBSERVER SEAT (INCLUDING ASSOCIATED EQUIPMENT)				
-11-02-01A	A	1	0	May be inoperative provided: a) A passenger seat in the passenger cabin is made available to a PCAA inspector for the performance of official duties, and b) Repairs are made within two flight days.
-11-02-01B	A	1	0	May be inoperative provided: a) Second Observer seat is available, and acceptable to a PCAA inspector for the performance of official duties, and b) Repairs are made within two flight days.
-11-02-01C	A	1	0	May be inoperative provided: a) First Observer seat is acceptable to the PCAA inspector for the performance of official duties, b) Required minimum safety equipment (safety belt and oxygen) is available, and c) Repairs are made within two flight days. NOTE 1: These provisos are intended to provide for occupancy of the above seats by a PCAA inspector when the minimum safety equipment (oxygen and safety belt) is functional and the inspector determines the conditions to be acceptable. NOTE 2: The Pilot in command will determine if the minimum safety equipment is functional for the other persons authorized to occupy an observer seat(s).
-11-02-02 SECOND OBSERVER SEAT (INCLUDING ASSOCIATED EQUIPMENT)	D	1	0	NOTE: The Pilot in command will determine if the minimum safety equipment is functional for the other persons authorized to occupy an observer seat(s).

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 25: EQUIPMENT/FURNISHINGS	25-3 (PIA Rev 23) Sep , 2023
---	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-18-01	FLOTATION EQUIPMENT				
	LIFE VEST(S)	D	329/ 310/ 393/ 307/ 442	-	For extended over-water operations life vest(s) may be inoperative or missing for those seats, which are not occupied by any occupant.
	200ER=329 200LR=310/ 300ER=393/ AP-BMG/H=307/ AP-BMS=442				
	SLIDE RAFT(S)	D	8	-	Slide raft(s) may be inoperative or missing provided required distribution is maintained with respect to number of occupants. (Refer 777 Weight & Balance Booklet)
-20-01	NON-ESSENTIAL EQUIPMENT AND FURNISHINGS (NEF) (REFER ANNEXURE-3)				May be inoperative, damaged or missing provided that the item(s) is deferred in accordance with attached Annexure-3 . NOTE: Exterior lavatory door ash trays are not considered NEF items.
-25-01	FLIGHT ATTENDANT SEAT ASSEMBLY (SINGLE OR DUAL POSITION)				
	-25-01-01 REQUIRED FLIGHT ATTENDANT SEATS (PASSENGER) -200ER&LR=7/ -300ER= 8/ BMS=9				
-25-01-01A		B	7/8/ 9	5/6/ 7	(M)(O) One seat position or assembly (dual position) may be inoperative provided: a) Affected seat position or seat assembly is not occupied, b) Flight attendant(s) displaced by inoperative seat(s) occupies either an adjacent flight attendant seat or the passenger seat which is most accessible to the inoperative seat(s), so as to most effectively perform assigned duties, c) Closest passenger seat should be allocated for the flight attendant, d) Folding type seat stows automatically or is secured in the retracted position, and e) Passenger seat assigned to flight attendant is placarded. "FOR FLIGHT ATTENDANT USE ONLY". NOTE 1: An automatic folding seat that will not stow automatically is considered . inoperative. (Continued.....)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 25: EQUIPMENT/FURNISHINGS	25-4 (PIA Rev 23) Sep , 2023
---	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES			
(Continued....)				NOTE 2: A seat position with an inoperative or missing restraint system is considered inoperative. NOTE 3: When operating with inoperative seats, it will be ensured that the Flight Attendant(s) assigned to the affected seat(s) must occupy the passenger seat(s) as close to, or closer than, the nearest seated passengers to the associated exit. NOTE 4: If one side of a dual seat assembly is inoperative and a flight attendant is displaced to the adjacent seat, the adjacent seat must operate normally.
-25-01-01B	C	7/8/ 9	0	(M)(O) May be inoperative provided: - No passengers are carried, - A maximum of 19 authorized persons including crewmembers, company employees or PCAA inspectors for non-passenger carrying operations are carried, - Folding type seat stows automatically or is secured in the retracted position, - Affected seat position or seat assembly is not occupied, and - The Flight Attendant(s) assigned to the affected seat(s) must occupy the passenger seat(s) as close to, or closer than, the nearest seated authorized persons to the associated exit. NOTE 1: An automatic folding seat that will not stow automatically is considered inoperative. NOTE 2: A seat position with an inoperative or missing restraint system is considered inoperative.
-25-01-02 EXCESS FLIGHT ATTENDANT SEATS (PASSENGER) APBMG & BMH =7/ -200ER & -300ER=8/ 200LR=9/ APBMS=10	C	7/ 8/ 9/10	0	(M) May be inoperative provided: - Affected seat position or seat assembly is not occupied, and - Folding type seat stows automatically or is secured in the retracted position. NOTE 1: An automatic folding seat that will not stow automatically is considered inoperative. NOTE 2: A seat position with an inoperative or missing restraint system is considered inoperative.

PIA 777-240 ER/LR-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 25: EQUIPMENT/FURNISHINGS	25-5 (PIA Rev 23) Sep , 2023
--	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES
------	-------------------------

-25-01-03 777F				NOT APPLICABLE
-25-02 PASSENGER SEATS (PASSENGER)				
-25-02-01 PASSENGER SEATS (INCLUDING ALL CONFIGURATIONS AND LOCATIONS) APBMG& BMH=307/ 200ER=329/ 200LR=310/ APBMS=442/ 300ER=393	D	307/ 329/ 310/ 442/ 393	0	Maybe inoperative provided: a) Seat does not restrict access to any emergency exit, egressroute, or main aisle, and b) The affected seat(s) is blocked and placarded“DO NOT OCCUPY”. NOTE 1: A seat with an inoperative seat belt or shoulder harness is considered inoperative. NOTE 2: Affected seat(s) may include the seat(s) behind and/or adjacent outboard seats. NOTE 3: Inoperative seats do not affect the required number of flight attendants.
-25-02-02 POSITION CONTROLS FOR TAXI, TAKEOFF, AND LANDING (TTL) (MECHENICAL AND/OR ELECTRICAL) APBMG& BMH=307/ 200ER=329/ 200LR=310/ APBMS=442/ 300ER=393				
-25-02-02A	D	307/ 329/ 310/ 442/ 393	0	(M) May be inoperative and seat occupied provided seat is secured in the taxi, takeoff, and landing (TTL) position.
-25-02-02B	D	307/ 329/ 310/ 442/ 393	0	May be inoperative and seat occupied provided seat is immovable in the taxi, takeoff, and landing (TTL) position.
-25-02-03 UNDER SEAT BAGGAGE RESTRAINING SYSTEM APBMG& BMH=307/ 200ER=329/ 200LR=310/ APBMS=442/ 300ER=393	C	307/ 329/ 310/ 442/ 393	0	(O) May be inoperative provided: a) Baggage is not stowed under seat with inoperative restraining system, b) Associated seat is placarded “DO NOT STOW BAGGAGE UNDER THIS SEAT”, and c) Cabin crew is briefed by Maintenance.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 25: EQUIPMENT/FURNISHINGS	25-6 (PIA Rev 23) Sep , 2023
---	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES
------	-------------------------

-25-02-04 ARMRESTS				
-25-02-04-01 WITH SEAT POSITIONING CONTROLS FOR TAXI, TAKEOFF, AND LANDING (TTL) AND/OR OTHER CONTROLS APBMG& BMH=307/ 200ER=329/ 200LR=310/ APBMS=442/ 300ER=393	D	307/ 329/ 310/ 442/ 393	0	(M) May be inoperative or missing and seat occupied provided: a) Armrest does not restrict access to any emergency exit, egress route, or main aisle, and b) If armrest with seat control is missing or removed, seat is secured in taxi, takeoff, and landing (TTL) position.
-25-02-04-02 WITHOUT SEAT POSITIONING CONTROLS FOR TAXI, TAKEOFF, AND LANDING (TTL) AND/OR OTHER CONTROLS APBMG& BMH=307/ 200ER=329/ 200LR=310/ APBMS=442/ 300ER=393	D	307/ 329/ 310/ 442/ 393	0	May be inoperative or missing and seat occupied provided it does not restrict access to any emergency exit, egress route, or main aisle.
-25-02-05 SEAT BELT AIR BAG RESTRAINT SYSTEM				NOT APPLICABLE
-25-02-06 DELETHALIZATION PAD				NOT APPLICABLE
-25-03 SUPERNUMERARY SEATS (777F)				NOT APPLICABLE
-25-04 CREW / ATTENDANT REST SEATS 200LR, BMG/H& BMS=2	D	2	0	(M) May be inoperative provided: a) Seat is not occupied, and b) Affected seat(s) is blocked and placarded "DO NOT OCCUPY". NOTE: A seat with an inoperative seat belt is considered inoperative.
-25-04-01 RECLINE MECHANISM				
-25-04-01A	D	2	0	(M) May be inoperative and seat occupied provided seat is secured in the full upright position.
-25-04-01B	D	2	0	May be inoperative and seat occupied provided seat back is immovable in the full up-right position.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 25: EQUIPMENT/FURNISHINGS	25-7 (PIA Rev 23) Sep , 2023
---	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES
------	-------------------------

-25-04-02 ARMRESTS	D	2	0	(M) May be inoperative provided armrest is stowed in retracted position or removed.
-25-04-03 LEG RESTS	D	2	0	(M)May be inoperative and seat occupied provided: a) legrest is stowed in the retracted position, and b) Seat is acceptable to the affected crew member.
-25-05 FIRST CLASS SUITES				NOT APPLICABLE
-25-06 PASSENGER MINI-SUITES				NOT APPLICABLE
-28-01 STORAGE BIN(S)/CABIN, GALLEY AND LAVATORY STORAGE COMPARTMENTS/ CLOSETS -28-01A (BMS/EXCEPT BMS)	C	186/ 161	0	(M) May be inoperative provided: a) Affected bin, compartment or closet is secured closed with strong adhesive tape, b) Associated bin, compartment or closet is prominently placarded DO NOT USE, c) Any emergency equipment located in affected bin, compartment or closet is considered inoperative, and d) Affected bin, compartment or closet is not used for storage of any items except for those permanently affixed. NOTE 1: For overhead bins, if no partitions are installed, the entire overhead bin is considered inoperative. NOTE 2: Proviso is not intended to preclude crewmember inspections.
-28-01B (BMS/EXCEPT BMS)	C	186/ 161	0	(M)(O) May be inoperative provided: a) For non-retractable doors, affected door is removed, b) For retractable doors, affected door is removed or secured in the retracted(fully open)position, c) Affected bin, compartment or closet is not used for storage of any items, except those permanently affixed, d) Affected bin, compartment or closet is prominently placarded DO NOT USE (Continued.....)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 25: EQUIPMENT/FURNISHINGS	25-8 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES
------	-------------------------

(Continued.....)				e) Procedures are established and used to alert crew members and passengers of inoperative bins, compartments or closets, and f) Passengers are briefed that affected bin, compartment or closet is not to be used. NOTE 1: For overhead bins, if no partitions are installed, the entire overhead bin is considered inoperative. NOTE 2: Any emergency equipment located in the Affected bin, compartment or closet (permanently affixed) is available for use.
-28-01C (BMS/EXCEPT BMS)	C	186/ 161	0	May be inoperative provided: a) Affected bin, compartment, or closet is prominently placarded "DO NOT USE", b) Any emergency equipment located in affected bin, compartment, or closet is considered inoperative, and c) Location placarding for any emergency equipment stored in affected bin, compartment or closet is removed or obscured. NOTE: Use of this proviso may be dependent upon an operator's aircraft security program, as appropriate.
-28-01-01 MULTI LATCH / QUARTER TURN LUG INSTALLATIONS				NOT APPLICABLE
-28-01-02 STORAGE COMPARTMENT KEY LOCKS				NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 25: EQUIPMENT/FURNISHINGS	25-9 (PIA Rev 23) Sep , 2023
---	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-28-02	OVERHEAD CROSS AISLE STOWAGE (OCAS) SYSTEM (AP-BMS ONLY)	D	2	0	(M) May be inoperative provided affected OCAS is deactivated closed.
-28-02-01	ELECTRIC EXTEND/RETRACT FUNCTION (AP-BMS ONLY)	D	2	0	(M) May be inoperative provided associated electric motor is deactivated.
-29-01	FLIGHT CREW REST (FCR) DOOR (AP-BMG & BMH)				
-29-01A		C	1	0	May be inoperative provided associated FCR is considered inoperative.
-29-01B		C	1	0	(M) May be inoperative provided FCR door is removed.
-29-01-01	DOOR LOCK	C	1	0	(M) May be inoperative provided: a) FCR door lock is deactivated in the unlocked position, and b) FCR door opens and closes normally.
-29-02	MAIN DECK CREW REST (MDCR)/MAIN DECK FLIGHT CREW REST (MDFCR) DOOR (AP-BMG & BMH)				
-29-02A		C	1	0	May be inoperative provided MDCR/MDFCR is considered inoperative.
-29-02B		C	1	0	(M) May be inoperative provided MDCR/MDFCR door is removed.
-29-02-01	DOOR LOCK	C	1	0	(M) May be inoperative provided: a) Associated MDCR/MDFCR door lock is deactivated in the unlocked position, and b) Associated MDCR/MDFCR door opens and closes normally.
-29-03	OVERHEAD FLIGHT CREW /ATTENDANT REST DOOR (INCLUDES FSI INSTALLATION) (-200LR& BMS)	C	1	0	May be inoperative provided associated flight crew/attendant rest facility is considered inoperative.
-29-03-01	DOOR LOCK	C	1	0	(M) May be inoperative provided: a) Associated OFCR/OFAR door lock is deactivated in the unlocked position, and b) Associated OFCR/OFAR door opens and closes normally.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 25: EQUIPMENT/FURNISHINGS	25-10 (PIA Rev 23) Sep , 2023
---	---	----------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES			
-29-04	FLIGHTCREW/ATTENANT REST FACILITIES (OFCR,OFAR,FCR MDCR,MDFCR,LLAR) (APBMG & BMH (IF INSTALLED),-200LR&BMS) -29-04A	C	2	0	(M) (O) May be inoperative provided: a) Associated crew/attendant rest is deactivated closed, and For Flight Crew Rest (OFCR, FCR,MDFCR) inoperative: b) Appropriate adjustments to flight crew FDP times are applied. NOTE: This provision is not intended to prohibit flightcrew/attendant rest facility inspections by crewmembers.
	-29-04B	C	2	0	May be inoperative provided procedures do not require their use.
	-29-04-01 BUNKS BMGH=2; BGY&BGZ=8 BMS=10	C	2/8/ 10	0	May be inoperative provided Bunk is not occupied. NOTE: A bunk with an inoperative or missing restraint system is considered inoperative.
-29-05	LOWER LOBE ATTENDANT REST (LLAR) ENTRANCE ENCLOSURE DOOR (IF INSTALLED) (AP-BMG & BMH)	C	1	0	May be inoperative provided LLAR is considered inoperative.
	-29-05-01 DOOR LOCK	C	1	0	(M) May be inoperative provided: a) LLAR entrance enclosure door lock is deactivated in the unlocked position, and b) LLAR entrance enclosure door opens and closes normally.
-30-01	GALLEY/CABIN WASTE CONTAINER ACCESS DOORS/COVERS	C	3	0	(M)(O) May be inoperative provided: a) Associated waste container is empty and access is secured to prevent waste introduction into the waste container, and b) Cabin attendants to physically ensure that sufficient galley/cabin waste containers are available to accommodate all waste that may be generated on a flight.
-41-01	EXTERIOR LAVATORY DOOR ASHTRAYS -41-01-01 PASSENGER (AP-BGJ, BGK, BGL,BHV, BHW, BID=12)/ (AP-BMG,BMH=8)/ (AP-BHX,BMS=11)/ (AP-BGY,BGZ=10)	A	12/ 08/ 11/ 10	6/ 4/ 6/ 5	Fifty percent may be inoperative or missing provided repairs are made within 10 calendar days.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 25: EQUIPMENT/FURNISHINGS	25-11 (PIA Rev 23) Sep , 2023
---	---	----------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-41-01-02	777F				NOT APPLICABLE
-41-02	LAVATORY WASTE CONTAINER FLAPPER/ACCESS DOORS (AP-BGJ, BGK, BGL=12/12) (AP-BHX&BMS=11/11) (AP-BMG & BMH=8/8) (AP-BGY & BGZ=10/10) (AP-BHV,BHW,BID=12/12)	C	12/12 11/11 8/8 10/10 12/12	0	(M) May be inoperative provided: a) Associated waste container is empty and access is secured to prevent waste introduction into the waste container, b) Lavatory is used only by crew members, and c) Associated Lavatory entrance door is locked closed & placarded. "INOPERATIVE – DO NOT ENTER" NOTE: These provisions are not intended to prohibit Lavatory use or inspection by crewmembers.
-52-01	LOWER CARGO COMPARTMENT LINING (FORWARD AND AFT)	C	2	0	(O) May be damaged or missing provided Loading Supervisor ensure and verify that the associated cargo compartment remains empty or contains only ballast, empty cargo handling equipment (ballast may be loaded in ULDs), or fly away kits.
-53-01	LOWER CARGO HANDLING SYSTEMS	D	2	0	NOTE: Any portion of the system which operates normally may be used.
-53-02	LOWER CARGO RESTRAINT SYSTEMS (-200LR/ER(EXCEPT AP- BMG & BMH) =109)/ (AP-BMG & BMH=103)/ (APBMS=317)/ (OTHER-300 ER= 209)				
-53-02A		A	109/ 103/ 317/ 209	-	(M) May be inoperative or missing provided: a) Approved cargo-loading limits are observed. The only source documents are: • Type Certificate (TC) • Supplemental Type Certificate (STC), • Airplane Flight Manual (AFM), • Airplane Flight Manual Supplement (AFMS), • TC/STC Weight and Balance Manual (WBM), and b) Repairs are made within 120 consecutive calendar-days.
-53-02B		A	109/ 103/ 317/ 209	0	May be inoperative or missing provided: a) Cargo compartment remains empty, and b) Repairs are made within 120 consecutive calendar-days.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 25: EQUIPMENT/FURNISHINGS	25-12 (PIA Rev 23) Sep , 2023
---	---	----------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES	
-53-02C	A	109/ 103/ 317/ 209		-	Individual cargo areas may be inoperative provided: a) Aircraft is operated in accordance with Original Equipment Manufacturer (OEM) W&B source document, and b) Repairs are made within 120 consecutive calendar-days.	
-57-01 MAIN DECK CARGO HANDLING SYSTEM (777F)					NOT APPLICABLE	
-58-01 MAIN DECK CARGO RESTRAINT SYSTEM (777F)					NOT APPLICABLE	
-59-01 MAIN DECK CARGO COMPARTMENT LINING (777 F)					NOT APPLICABLE	
-63-01 EMERGENCY EVACUATION SIGNAL SYSTEM	C	1	0		(O) May be inoperative provided cabin crew is briefed by the Captain on use of cabin interphone for initiating emergency evacuation.	
-63-02 FASTEN SEAT BELT WHILE SEATED PLACARDS APBMG &BMH=284/ 200ER=310 / 200LR=291/ 300ER=374/ BMS=442	C	284/ 310/ 291/ 374/ 442		-	One or more signs or placards may be illegible or missing provided a legible sign or placard is visible from each occupied passenger seat.	
-63-03 PORTABLE EMERGENCY LOCATOR TRANSMITTER (ELT)						
<u>-200ER:</u> (AP-BGJ,BGK,BGL,BMG & BMH)		1	1			
<u>-200LR:</u> (AP-BGY & BGZ)		1	1			
<u>-200ER:</u> (AP-BHX)	D	2	1		One may be inoperative or missing.	
<u>-300ER:</u> (APBHV,BHW,BID&BMS)	D	2	1		One may be inoperative or missing.	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 25: EQUIPMENT/FURNISHINGS	25-13 (PIA Rev 23) Sep , 2023
---	---	----------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES	
-64-01	MEGAPHONES (PASSENGER)		
-64-01A (AP-BMS=3/ ALL OTHER=2)	D	3/2	2
			Megaphone at door 3 may be inoperative or missing provided: a) Inoperative megaphone remains in a certified location until removed from the aircraft at the next suitable maintenance facility, b) Location placarding is removed or obscured, and c) Required distribution is maintained.
-64-01B (AP-BMS=3/ ALL OTHER=2)	C	2/3	0
			(O) May be inoperative or missing provided: a) No passengers are carried, b) A maximum of 19 authorized persons including crewmembers, company employees or PCAA inspectors for non-passenger carrying operations are carried if required, and c) PA is used for functions of megaphone.
-64-01-01 TEMPER SEALS OR TAGS			NOT APPLICABLE
-64-02	PORTABLE FLASHLIGHTS/FLASHLGH T HOLDERS		
200ER(EXCEPT BMG&H)=17/ BMG&H,200LR & 300ER =18 -64-02A	C	17/ 18	-
			NOTE: Each crewmember shall carry a serviceable flashlight with 'D' size battery cells.
-64-02B 200ER(EXCEPT BMG&H)=17/ BMG&H,200LR & 300ER =18	D	17/ 18	-
			Any in excess of those required by regulations may be inoperative or removed provided: a) Inoperative flashlight remains in a certified location until removed from the aircraft at the next suitable maintenance facility, and b) Location placarding is removed or obscured.
-64-02C 200ER(EXCEPT BMG&H)=17/ BMG&H,200LR & 300ER =18	C	17/ 18	-
			(O) May be inoperative or missing provided: a) No passengers are carried, b) A maximum of 19 authorized persons including crewmembers, company employees or PCAA inspectors for non-passenger carrying operations are carried if required, and c) All crewmembers shall carry a serviceable flashlight with 'D' size battery cells.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 25: EQUIPMENT/FURNISHINGS	25-14 (PIA Rev 23a) Jul , 2024
---	---	-----------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES	
-64-03	-64-02-01 TAMPERED SEALS OR TAGS		NOT APPLICABLE
	EMERGENCY MEDICAL EQUIPMENT		
	-64-03-01 FIRST AID KITS (FAK) AND / OR ASSOCIATED EQUIPMENT		
	-64-03-01A 200ER EXCEPT BMGH & 200LR=4/ AP-BMG, H & 300ER=5	A 4/5 3	(O) To retrieve the aircraft back to Pakistan, one FAK may be incomplete provided: a) Incomplete FAK is distinguished by having plastic seal, so that it cannot be mistaken for a fully serviceable unit having metal seal. b) Location placarding is removed or obscured, and c) Repair or replacement is made within one flight. NOTE: Medical equipment installed in the aircraft as part of an EMS operation is not considered part of the normal complement of equipment. No MEL relief applies to that equipment and regulations maintenance and inspection requirements do not apply.
	-64-03-01B AP-BMG, H & 300ER=5	D 5 4	One FAK may be incomplete, missing or inoperative.
	-64-03-01-01 TAMPERED SEALS OR TAGS AP-BMS, BMG&BMH, 300ER=5/ 200ER & 200LR=4	C 5/ 4 0	(O) May be inoperative, damaged, or missing provided proper FAK servicing is verified at each preflight.
	-64-03-02 EMERGENCY MEDICAL KIT (EMK) AND / OR ASSOCIATED EQUIPMENT		
	-64-03-02A	A 1 0	(O) To retrieve the aircraft back to Pakistan, EMK may be incomplete provided: a) Incomplete EMK is distinguished by having plastic seal, so that it cannot be mistaken for a fully serviceable unit having metal seal. b) Location placarding is removed or obscured, and c) Repair or replacement is made within one flight. (Continued.....)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 25: EQUIPMENT/FURNISHINGS	25-15 (PIA Rev 23) Sep , 2023
---	---	----------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES		
-64-03-02B			NOTE: Medical equipment installed in the aircraft as part of an EMS operation is not considered part of the normal complement of equipment. No MEL relief applies to that equipment and regulations maintenance and inspection requirements do not apply.
-64-03-02-01 TAMPERED SEALS OR TAGS	C	1	0 NOT APPLICABLE (O) May be inoperative, damaged, or missing provided proper EMK servicing is verified at each preflight.
-64-03-03 AUTOMATED EXTERNAL DEFIBRILLATORS (AED) AND / OR ASSOCIATED EQUIPMENT			NOT APPLICABLE
-64-04 SMOKE VISION SYSTEM (SVS)			NOT APPLICABLE

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 26: FIRE PROTECTION	26-1 (PIA Rev 23) Sep , 2023
--	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-11-01	ENGINE FIRE DETECTOR LOOPS				
-11-0101	PW & GE	C	4	2	One per engine may be inoperative.
-11-01-02	RR				NOT APPLICABLE
-11-02	ENGINE OVERHEAT CIRCUITS	C	4	0	
-13-01	LAVATORY SMOKE DETECTION SYSTEMS				
-13-01-01	PASSENGER (APBMG&BMH = 8 APBMS = 11 -200ER/-300ER=12) (-200LR = 10)				
-13-01-01A		C	8/ 11/ 12/ 10	0	(M)(O) For each lavatory, may be inoperative provided associated: a) Lavatory waste container is empty, b) Lavatory door is locked closed and placarded – INOPERATIVE DO NOT ENTER, and c) Lavatory is used only by crew members.
-13-01-01B		D	8/ 11/ 12/ 10	0	NOTE: These provisions are not intended to prohibit lavatory use or inspections by crewmembers. Any in excess of that required by standard equipment may be inoperative.
-13-01-01-01	LAVATORY CALL LIGHT SMOKE DETECTION FUNCTION (APBMG&BMH =8 APBMS = 11 -200ER/-300ER=12 -200LR = 10)	C	8/ 11/ 12/ 10	0	NOTE: Attendant call and occupancy indications are considered NEF.
-13-01-02	777F				NOT APPLICABLE
-13-02	OVERHEAD CROSS AISLE STOWAGE (OCAS) SMOKE DETECTION SYSTEM (DETECTOR, HORN AND LIGHT) (APBMS ONLY)	D	2	0	

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 26: FIRE PROTECTION	26-2 (PIA Rev 23) Sep , 2023
--	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-14-01	LOWER LOBE ATTENDANT REST (LLAR) SMOKE DETECTION SYSTEM (IF INSTALLED) (AP-BMG & BMH)	C	1	0	(M)May be inoperative provided: a) LLAR shutoff valve is deactivated closed, and b) LLAR is considered inoperative.
-14-01-01	Remote Smoke Detector Channels	C	2	1	One channel may be inoperative provided both aft cargo compartment smoke detector channels operate normally.
-14-02	FLIGHT CREW REST (FCR) SMOKE DETECTION SYSTEMS (AP-BMG & BMH)	C	1	0	(M) May be inoperative provided: a) FCR smoke detection system is deactivated, and b) FCR is considered inoperative.
-14-02-01	TWO BUNK FCR BUNK SMOKE DETECTORS	C	2	1	(M)(O) One may be inoperative provided: a) Associated bunk is not used and personal items are removed, and b) A conspicuous barrier strap or rope is placed across the associated bunk with a placard attached stating that the bunk is not to be used.
-14-02-02	SINGLE BUNK FCR SMOKE DETECTORS				NOT APPLICABLE
-14-02-03	SEAT ONLY FCR SMOKE DETECTORS				NOT APPLICABLE
-14-03	MAIN DECK CREW REST (MDCR)/MAIN DECK FLIGHT CREW REST (MDFCR) SMOKE DETECTION SYSTEM				NOT APPLICABLE
-14-04	OVERHEAD FLIGHT CREW/ATTENDANT REST SMOKE DETECTION SYSTEMS (-200LR / BMS)	C	2/2	0	(M) May be inoperative provided: a) Inoperative smoke detection system is deactivated, and b) Associated crew rest facility is considered inoperative.
-14-04-01	BUNK SMOKE DETECTORS APBMG&H=2/ APBMS=10/ 200LR=8	C	2/10 /8	0	May be inoperative provided: a) Adjacent aisle/common area smoke detector(s) operate normally, and b) For bunk curtain installed, associated curtain is secured open or removed.

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 26: FIRE PROTECTION	26-3 (PIA Rev 22a2) JUN , 2023
--	---	-----------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-14-04-02 COMMON AREA SMOKE DETECTORS				
-14-04-02-01 OVERHEAD FLIGHT CREW REST (OFCR) (-200LR & BMS)	C	3	0	May be inoperative provided: a) Bunk smoke detector(s) operate normally, and b) For common area or bunk curtain(s) installed, curtain(s) is secured open or removed.
-14-04-02-02 OVERHEAD FLIGHT ATTENDANT REST (OFAR) (-200LR & BMS)	C	2	1	May be inoperative provided no more than one bunk smoke detector in adjacent bunk area(s) is inoperative.
-14-04-03 AISLE SMOKE DETECTORS (OFAR) -200LR=2 / BMS=4	C	2/4	0	May be inoperative provided adjacent aisle/common area smoke detector(s) operates normally.
-14-04-04 CLOSET SMOKE DETECTOR(S) (-200LR & BMS)	C	1	0	(M)(O) May be inoperative provided: a) Closet is not used and personal items are removed, and b) A conspicuous barrier strap or rope is placed across the closet door with a placard attached stating the closet is not to be used.
14-04-05 VANITY MODULE (INCLUDES SINK WITH DRINK STORAGE AREA SMOKE DETECTOR (OFCR)				NOT APPLICABLE
-14-04-06 STAIRWELL SMOKE DETECTORS (APBMS ONLY)				
-14-04-06-01 OFCR WITHOUT LAVATORY	C	1	0	May be inoperative provided: a) All common area smoke detectors operate normally, and b) For common area curtain installed, common area curtain is secured open or removed.
-14-04-06-02 OFCR WITH LAVATORY				NOT APPLICABLE
-14-04-07 CHANGING AREA SMOKE DETECTOR (OFAR)				NOT APPLICABLE

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 26: FIRE PROTECTION	26-4 (PIA Rev 23) Sep , 2023
--	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES			
-14-04-08	LAVATORY SMOKE DETECTOR (OFCR)				NOT APPLICABLE
-14-05	OVERHEAD FLIGHT CREW/ATTENDANT REST SMOKE DETECTION SYSTEMS (FSI INSTALLATION)				NOT APPLICABLE
-15-01	APU FIRE DETECTION SYSTEM				
-15-01A		C	1	0	(O) May be inoperative provided: a) Other procedures do not require use of APU, b) Backup AC power system is verified to operate normally before each departure, c) APU selector switch remains in the OFF position, and d) Flight remains within 180 minutes of landing at a suitable airport.
-15-01B		C	1	0	(M)(O) May be inoperative provided: a) Other procedures do not require use of APU, b) Backup AC power system is verified to operate normally before each departure, c) APU is used for ground operations only, d) APU is continuously monitored by ground personnel when operating, e) APU external control system operates normally, f) APU is not used during taxi, and g) Flight remains within 180 minutes of landing at a suitable airport.
-15-01-01	APU FIRE DETECTOR LOOPS	C	2	1	
-16-01	LOWER CARGO COMPARTMENT SMOKE DETECTION SYSTEMS (FORWARD & AFT) (PASSENGER)	C	2	0	(M)(O) May be inoperative provided: a) Loading Supervisor to ensure and verify that the associated compartment remains empty or contains only ballast, empty cargo handling equipment (ballast may be loaded in ULDs), or fly away kits, and b) For LLAR installed and aft compartment system inoperative, LLAR is considered inoperative, (AP-BMG & BMH) and c) For FCAC installed and Forward compartment system inoperative, FCAC remains OFF.(-200ER)

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 26: FIRE PROTECTION	26-5 (PIA Rev 23) Sep , 2023
--	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-16-01-01	LOWER CARGO COMPARTMENT SMOKE DETECTOR CHANNELS	C	4	2	One channel per compartment may be inoperative.
-16-01-02	LOWER CARGO COMPARTMENT SMOKE DETECTOR FANS	C	4	2	One fan per compartment may be inoperative.
-16-01-03	LOWER CARGO COMPARTMENT SMOKE DETECTOR ZONES (200ER/LR = 6 300ER = 8)	C	6/8	0	(M)(O) Smoke detection in any zone may be inoperative provided: a) Loading Supervisor to ensure and verify that the associated compartment zone and adjacent compartment zone(s) remain empty, or contains only ballast empty cargo handling equipment (ballast may be loaded in ULDs), or fly away kits, b) For LLAR installed and aft compartment zone 2 or zone 3 detector inoperative, LLAR is considered inoperative, and (AP-BMG & BMH) c) For FCAC installed and any forward compartment system zone detector inoperative, FCAC remains OFF. (-200ER)
-16-01-04	LOWER CARGO COMPARTMENT SMOKE DETECTOR HEATERS				
-16-01-04A		C	8	0	May be inoperative provided humid cargo is not carried in the associated compartment.
-16-01-04B		C	8	0	(O) May be inoperative provided cargo is wrapped/enclosed and packed to reduce the possibility for false fire warning.
-16-02	LOWER CARGO COMPARTMENT SMOKE DETECTION SYSTEMS (777F)				NOT APPLICABLE
-16-03	MAIN DECK CARGO COMPARTMENT SMOKE DETECTION SYSTEMS (777F)				NOT APPLICABLE
-16-04	CARGO SMOKE DETECTION (CSD) SYSTEM CONTROLLER (777F)				NOT APPLICABLE

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 26: FIRE PROTECTION	26-6 (PIA Rev 23) Sep , 2023
--	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-17-01	WHEEL WELL FIRE DETECTION SYSTEM				
-17-01A	C	1	0	(M)(O) May be inoperative provided: a) Both wheel well fire detection loops are deactivated, and b) Brake temperature monitoring system (BTMS) operates normally.	
				NOTE: Avoid the possibility of retracting an overheated wheel by monitoring brake temperature indications.	
-17-01B	C	1	0	(M)(O) May be inoperative provided: a) Both wheel well fire detection loops are deactivated, b) Landing gear remains extended for ten minutes after takeoff, and c) Appropriate performance adjustments are applied.	
				NOTE 1: In case of engine failure after V1, landing gear should be retracted until takeoff obstacles are cleared.	
-18-01	WING DUCT LEAK DETECTOR LOOPS	C	4	2	One per side may be inoperative.
-18-02	BODY DUCT LEAK DETECTOR LOOPS	C	2	1	One may be inoperative provided both ASG cards in the opposite card file operate normally.
-18-03	STRUT OVERHEAT DETECTOR LOOPS	C	4	2	One per side may be inoperative.
-18-04	ENGINE FAN CASE OVERHEAT DETECTION SYSTEMS				
-18-04-01	PW & GE	C	2	1	One may be inoperative provided: a) Associated engine anti-ice selector remains OFF, b) Airplane is not operated in known or forecast icing conditions, and c) Flight remains within 120 minutes of landing at a suitable airport.
-18-04-02	RR				NOT APPLICABLE
-19-01	E/E COOLING SMOKE DETECTOR CHANNELS	C	2	1	
-19-02	EQUIPMENT COOLING SMOKE DETECTORS (777F)				NOT APPLICABLE

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 26: FIRE PROTECTION	26-7 (PIA Rev 23) Sep , 2023
--	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-21-01	FIRE BTL DISCH LIGHTS (ENGINE, APU, CARGO)	C	4	0	
-21-02	FIRE EXTINGUISHING SQUIB TEST SYSTEM	C	1	0	(M) May be inoperative provided squib electrical continuity is verified once each flight day.
-21-02-01	CARGO SQUIB TEST SYSTEM	C	1	0	(M)(O) May be inoperative provided: a) Loading Supervisor to ensure and verify that the lower cargo compartments remain empty, or contains only ballast, empty cargo handling equipment (ballast may be loaded in ULDs), or fly away kits, and b) For LLAR installed, LLAR is considered inoperative. (APBMG & BMH)
-21-02-02	LOWER LOBE ATTENDANT REST (LLAR) SQUI TEST SYSTEM (IF INSTALLED) (AP-BMG & BMH)				
-21-02-02A		C	1	0	(M) May be inoperative provided squib electrical continuity is verified once each flight day using LLAR Smoke Test Switch.
-21-02-02B		C	1	0	(M) May be inoperative provided : a) LLAR shutoff valve is deactivated closed, and b) LLAR is considered inoperative.
-22-01	APU FIRE EXTINGUISHER SYSTEM	C	1	0	(O) May be inoperative provided: a) Other procedures do not require use of APU, b) Backup AC power system is verified to operate normally before each departure, c) APU selector switch remain in the OFF position, and d) Flight remains within 180 minutes of landing at a suitable airport.
-22-02	APU AUTO DISCHARGE	C	1	0	(M) May be inoperative provided APU is monitored during APU ground operations for fire warning.
-23-01	LOWER CARGO COMPARTMENT FIRE EXTINGUISHER BOTTLES				
-23-01-01	WITHOUT LLAR INSTALLED (-200ER(EXCEPT APBMG & BMH) -200LR = 5/ (-300ER = 6)	C	5/6	0	(O) May be inoperative provided: Loading Supervisor to ensure and verify that the cargo compartments remain empty, or contains only ballast, empty cargo handling equipment (ballast may be loaded in ULDs), or fly away kits.

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 26: FIRE PROTECTION	26-8 (PIA Rev 11) MAR , 2019
--	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES			
-23-01-02 WITH LLAR INSTALLED (IF INSTALLED) (APBMG & BMH)	C	1	0	(M)(O) May be inoperative provided: a) LLAR shutoff valve is deactivated closed. b) Load controller is informed and on loadsheets this is to be verified that cargo compartments remain empty or contain only ballast, empty cargo handling equipment (ballast may be loaded in ULDs), or fly away kits, and c) LLAR is considered inoperative.
-23-01-03 METERED BOTTLES (-200ER/-200LR= 3) (-300ER = 4)	C	3/4	1	(M)(O) May be inoperative provided: a) Bottles 1A and 1B operate normally, b) Metered bottle 2A operate normally, c) Associated Bottle is deactivated, d) Airplane is operated pressurized, and e) Appropriate flight planning adjustments are applied to account for remaining fire suppression capability. NOTE: For Extended Diversion Time Operations (EDTO) previously known as ETOPS flight planning, use total fire suppression times as mentioned in DDG according to following applicable FILTER / REGULATOR NO. for planning time-limited system alternates minus 15 minutes. -200ER = 473494-4 / -5 -200LR = 473995-1 / -2 / -3 -300ER = 473857-4 / -5
-23-01-04 BOTTLE PRESSURE SWITCHES (-200ER EXCEPT APBMG&BMH AND-200LR = 5)/ (-300ER AND APBMG&BMH= 6)	C	5/6	0	(M) May be inoperative provided: a) Associated bottle is verified full, and b) Associated bottle squib firing circuit is verified operating normally before each departure.

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 26: FIRE PROTECTION	26-9 (PIA Rev 22a2) JUN , 2023
--	---	-----------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-23-02	LOWER CARGO COMPARTMENT FIRE EXTINGUISHER FLOW VALVES (FORWARD OR AFT)				
-23-02A	C	2	1	(M)(O) One may be inoperative provided:	
				a) Associated flow valve is capped,	
				b) Associated flow valves squib electrical connectors are capped and stowed,	
				c) Loading Supervisor to ensure and verify that the associated cargo compartment remains empty, or contains only ballast, empty cargo handling equipment (ballast may be loaded in ULDs), or fly away kits.	
				d) For LLAR installed, and aft compartment flow valve inoperative, LLAR is considered inoperative. (APBMG & BMH)	
-23-02B	C	2	0	(M)(O) May be inoperative provided:	
				a) Loading Supervisor to ensure and verify that the cargo compartments remain empty, or contains only ballast, empty cargo handling equipment (ballast may be loaded in ULDs), or fly away kits.	
				b) For LLAR installed, LLAR is considered inoperative. (APBMG & BMH)	
-24-01	LAVATORY FIRE EXTINGUISHER SYSTEMS				
-24-01-01 PASSENGER					
(APBMG & BMH =8)/					
(APBMS & BHX=11)/					
(-200LR =10)/					
(APBGJ,BGK,BGL&-300ER=12)					
-24-01-01A	C	8/ 11/ 10/ 12	0	May be inoperative for each lavatory provided associated lavatory smoke detection system operates normally.	
-24-01-01B	C	8/ 11/ 10/ 12	0	(M)(O) May be inoperative for each lavatory provided associated:	
				a) Lavatory waste container is empty,	
				b) Lavatory door is locked closed and placarded, INOPERATIVE – DO NOT ENTER, and	
				c) Lavatory is only used by crewmembers.	
				NOTE: These provisions are not intended to prohibit lavatory use or inspections by crewmembers.	
-24-01-01C	D	8/ 11/ 10/ 12	0	Any in excess of that required by standard equipment may be inoperative.	
-24-01-02 777F				NOT APPLICABLE	

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 26: FIRE PROTECTION	26-10 (PIA Rev 22a2) JUN , 2023
---	---	------------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-25-01	LOWER LOBE ATTENDANT REST (LLAR) FIRE EXTINGUISHER BOTTLE (IF INSTALLED) (AP-BMG & BMH)	C	1	0	(M) May be inoperative provided: a) LLAR shutoff valve is deactivated closed, and b) LLAR is considered inoperative.
-26-01	PORTABLE FIRE EXTINGUISHERS (-200ER=8/ APBMS=18/ -300ER=11/ -200LR=12)	D	8/ 18/ 11/ 12	6/ 7/ 6/ 6	At least two of the required fire extinguishers must be of Halon type. Note: Inoperative fire extinguishers removed from a certified location or removed from the aircraft, are subject to dangerous goods regulations.
-26-01-01	TAMPER SEALS OR TAGS (-200ER=8/ APBMS=18/ -300ER=11/ -200LR=12)	C	8/ 18/ 11/ 12	0	(O) May be inoperative, damaged or missing provided proper installation and servicing is verified at each preflight. Note: For Halon type; if seal is broken verify pressure from gauge. For Water Glycol type; if seal is broken, consider unservisable.
-27-01	MAIN DECK CARGO FIRE SUPPRESSION SYSTEM (FSS) (STC ST02375LA)				NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 27: FLIGHT CONTROLS	27-1 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-00-01	FLIGHT CONTROLS SYNOPTIC DISPLAY	C	1	0	
-02-01	BANK ANGLE PROTECTION				
-02-01-01	WITHOUT STANDBY ATTITUDE INDICATOR P/N S231W120-4 OR EQUIVALENT INSTALLED				NOT APPLICABLE
-02-01-02	WITH STANDBY ATTITUDE INDICATOR P/N S231W120-4 OR EQUIVALENT INSTALLED	C	1	0	
-02-02	PRIMARY FLIGHT COMPUTER (PFC) LANES	C	9	7	
-02-03	PRIMARY FLIGHT COMPUTER (PFC) CHANNELS	A	3	2	Note: For CAT III B approaches, all must be serviceable. (M) One may be inoperative provided: a) Inoperative PFC channel is deactivated, b) Operations are limited to three flights before repairs are made, and c) Approach minimums do not require its use.
-02-04	PFCS INTERFACE	C	1	0	(M) May be inoperative provided landing gear truck tilt pressure is verified to be normal before each departure.
-02-05	ACTUATOR PRESSURE SENSORS	B	7	6	One flaperon or rudder sensor may be inoperative.
-02-06	FLIGHT CONTROL HYDRAULIC SHUTOFF VALVE SYSTEMS	C	6	3	(M) May be inoperative provided the associated valve is deactivated open.
-02-07	PRIMARY FLIGHT COMPUTER DISC LIGHT	C	1	0	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 27: FLIGHT CONTROLS	27-2 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-02-08	THRUST ASYMMETRY COMPENSATION (TAC) FUNCTION	C	1	0	Must be operative if actual/forecast Wx for departure and/or destination airports indicate low visibility/CAT II weather conditions.
-02-08-01	THRUST ASYM COMP SWITCH LIGHTS				
-02-08-01-01	OFF LIGHT	C	1	0	
-02-08-01-02	AUTO LIGHT	C	1	0	
-03-01	FLAP/SLAT CONTROL LANES				Note: For CAT III B approaches both must be serviceable.
		C	2	1	(M) One may be inoperative provided: a) Flap lever control position sensor is verified to operate normally, and b) Alternate control is verified to operate normally before each departure.
-03-02	FLAP SECONDARY CONTROL				Note: For CAT III B approaches must be serviceable.
		C	1	0	(M) May be inoperative provided Slat Secondary Control is verified to operate normally.
-03-03	SLAT SECONDARY CONTROL				Note: For CAT III B approaches must be serviceable.
		C	1	0	(M) May be inoperative provided Flap Secondary Control is verified to operate normally.
-11-01	AILERON TRIM SYSTEM	C	1	0	(M)(O) May be inoperative deactivated provided: a) Aileron trim system is deactivated, b) Aileron trim system is verified to be centered before departure, and c) Autopilot roll modes operate normally.
-11-02	CONTROL WHEEL POSITION TRANSDUCERS	C	6	5	Note: For CAT III B approaches all six (6) must be serviceable.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 27: FLIGHT CONTROLS	27-3 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-11-03	AILERON POWER CONTROL UNITS (PCUs)				Note: For CAT III B approaches, all four (4) must be serviceable.
-11-03-01	PASSENGER (WITH PRRS 61384-15 AND 62200 OR EQUIVALENT INSTALLED)	A	4	3	(M) One may be inoperative provided: a) Inoperative PCU is deactivated in the bypass mode, b) Inoperative PCU blocking mode is verified to operate normally, c) Ailerons are verified to operate normally, and d) Repairs are made within three flight days.
-11-03-02	777F				NOT APPLICABLE
-11-04	FLAPERON POWER CONTROL UNITS (PCUS)				Note: For CAT III B approaches, all four (4) must be serviceable.
-11-04-01	PASSENGER (WITH PRRS 61384-15 AND 62200 OR EQUIVALENT INSTALLED)	A	4	3	(M) One may be inoperative provided: a) Inoperative PCU is deactivated in the bypass mode, b) Flaperons are verified to operate normally, and c) Repairs are made within three flight days.
-11-04-02	777F				NOT APPLICABLE
-21-01	RUDDER TRIM SYSTEM				
-21-01-01	RUDDER TRIM CONTROL HIGH RATE FUNCTION	C	1	0	
-21-01-02	RUDDER MANUAL TRIM CANCEL SWITCH	C	1	0	
-21-02	RUDDER TRIM INDICATOR	C	1	0	(O) May be inoperative provided rudder trim is verified centered before each departure.
-21-03	RUDDER PEDAL ADJUST CRANK HANDLE SPRING (WITH PRR 62539-1R OR EQUIVALENT INCORPORATED)				NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 27: FLIGHT CONTROLS	27-4 (PIA Rev 23) Sep, 2023
---	---	--

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-31-01	CONTROL COLUMN POSITION TRANSDUCERS	C	6	5	Note: For CAT III B approaches all six (6) must be serviceable.
-32-01	STALL WARNING SYSTEMS	C	2	1	
-32-01-01	STICK SHAKERS	C	2	1	
-41-01	CONTROL WHEEL PITCH TRIM SWITCHES	C	2	1	
-41-02	ALTERNATE PITCH TRIM POSITION SWITCHES	C	6	5	One may be inoperative provided both control wheel pitch trim switches operate normally.
-41-03	STABILIZER TRIM RATE SOLENOID VALVES	C	2	1	Note: For CAT III B approaches both must be serviceable.
-48-01	STAB POSITION INDICATORS	C	2	1	(O) One may be inoperative provided it is blanked or covered.
-48-02	STABILIZER POSITION TRANSDUCER MODULES	C	3	2	Note: For CAT III B approaches all three (3) must be serviceable.
-48-03	NOSE GEAR PRESSURE SWITCH				NOT APPLICABLE
-48-04	NOSE GEAR PRESSURE TRANSDUCER	C	1	0	(O) May be inoperative provided stabilizer trim position is verified to be properly set before each departure.
-51-01	INBOARD FLAP, OUTBOARD SUPPORT MECHANISM SPRINGS (NO.3 & NO.6 SUPPORTS)	A	4	2	NOTE: For Manual Stab trim setting refer Weight & Balance Manual. (M) One may be broken or missing on each support provided: a) Broken springs are removed, b) Remaining spring on each support is verified in place and not broken before each departure, and c) Operations are limited to fifteen departures before repairs are made.
-51-02	ALTN FLAPS ARM SWITCH ALTN LIGHT	C	1	0	
-59-01	FLAP/SLAT SKEW SENSORS	C	28	14	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 27: FLIGHT CONTROLS	27-5 (PIA Rev 23a) Jul, 2024
---	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-61-01	SPEEDBRAKE LEVER POSITION TRANSDUCERS	C	4	3	
-61-02	SPOILER AUXILIARY RETRACT DEVICE (SARD) (-300ER)	A	2	1	One may be inoperative provided: a) Associated passenger entry door 3 is considered inoperative, and b) Repairs are made within one flight day.
-61-03	SPOILER POWER CONTROL UNITS (PCUS)				Note: For CAT III B approaches, all fourteen (14) must be serviceable.
-61-03-01	PASSENGER (WITH PRRS 61384-15 AND 62200, OR EQUIVALENT INSTALLED)	A	14	12	(M)(O) One symmetrical pair (except 4/11) may be inoperative provided: a) Symmetrical pair is deactivated in the retracted position, b) Remaining spoilers are verified to operate normally, c) Appropriate performance adjustments are applied, (Refer DDG) and d) Repairs are made within three flight days.
-61-03-02	777F				NOT APPLICABLE
-62-01	AUTOMATIC SPEEDBRAKE FUNCTION	C	1	0	(M)(O) May be inoperative provided: a) Automatic Speedbrake Function is deactivated, b) Landing gear truck tilt pressure is verified to be normal before each flight, and c) Landing performance is based on manual speedbrakes.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 28: FUEL	28-1 (PIA Rev 23) Sep, 2023
---	------------------------------------	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-11-01	SUMP DRAIN VALVES				
-11-01-01	SURGE TANKS	C	2	0	(M) May be inoperative provided there is no evidence of leakage.
-11-01-02	MAIN AND CENTER TANKS	C	4	3	(M) One may be inoperative provided: a) There is no evidence of leakage, and b) AMM procedures are used to prevent water accumulation in associated tank.
-11-01-03	AUXILIARY TANK(S)				NOT APPLICABLE
-14-01	AUXILIARY TANK FUEL VENT VALVES				NOT APPLICABLE
-14-02	AUXILIARY TANK REFUEL ISOLATION VALVES				NOT APPLICABLE
-14-03	AUXILIARY TANK REFUEL TRANSFER VALVE(S)				NOT APPLICABLE
-14-04	AUXILIARY TANK FUEL PUMP(S)				NOT APPLICABLE
-14-05	AUXILIARY TANK FUEL PUMP ISOLATION VALVE(S)				NOT APPLICABLE
-14-06	AUXILIARY TANK FUEL TRANSFER VALVES				NOT APPLICABLE
-14-07	AUXILIARY TANK FUEL BACKUP TRANSFER SYSTEM				NOT APPLICABLE
-14-08	AUXILIARY TANK FUEL PRESSURE HOLD MODE				NOT APPLICABLE
-21-01	PRESSURE FUELING SYSTEM				
-21-01-01	REFUEL VALVES				
-21-01-01A		C	6	0	(M) May be inoperative provided: a) Inoperative refuel valve(s) is closed, and b) DDG procedures are used for refuelling.
(Continued...)					

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 28: FUEL	28-2 (PIA Rev 23) Sep , 2023
---	------------------------------------	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-21-01	PRESSURE FUELING SYSTEM (Continued...)				
-21-01-01B	C	6	5	(M) One main tank refuel valve may be inoperative provided: a) Inoperative refuel valve is open, b) Fuel jettison system is considered inoperative, and c) AMM procedures are used for refuelling.	
-21-01-02	INTEGRATED REFUEL PANEL				
-21-01-02-01	FUEL QUANTITY INDICATORS	C	4	0	(M) May be inoperative provided alternate procedures are used for refuelling.
-21-01-02-02	LOAD SELECT SYSTEM	C	1	0	(M) May be inoperative provided alternate procedures are used for refuelling.
-21-01-02-03	REFUEL VALVE LIGHTS	C	6	0	(M) May be inoperative provided: a) Overfill function operate normally, and b) Associated refuel valve is verified closed after each refuelling.
-21-01-02-04	OVERFILL FUNCTION (NORMAL / RESET SWITCH, LIGHT AND TEST)	C	1	0	(M) May be inoperative provided: a) Refuel valve lights operate normally, and b) Verify refuel valves close when appropriate during refuelling.
-21-01-02-05	DEFUEL VALVE FUNCTION (SWITCH AND OPEN LIGHT)	C	1	0	May be inoperative provided defuel valve is considered inoperative.
-21-01-02-06	POWER SWITCH- BATT POSITION	C	1	0	
-21-01-02-07	TEST FUNCTIONS (INDICATION AND SYSTEM)	C	2	0	
-21-01-02-08	REFUEL VALVE SWITCHES	C	3	0	May be inoperative provided: a) Load select system operates normally, and b) Overfill function operates normally.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 28: FUEL	28-3 (PIA Rev 23) Sep , 2023
---	------------------------------------	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-21-02	AUXILIARY TANK FUEL QUANTITY INDICATION (AUXILIARY REFUEL PANEL)				NOT APPLICABLE
-21-03	REFUEL ADAPTERS	C	4	1	(M) May be inoperative provided there are no fuel leaks.
-22-01	MAIN TANK FUEL PUMPS	C	4	3	(M) One may be inoperative provided: a) Inoperative main tank fuel pump is deactivated, b) Both main tank quantity indications operate normally, and c) Flight remains within 120 minutes of landing at a suitable airport.
-22-01-01	PUMPS SWITCH PRESS LIGHTS	C	4	0	
-22-01-02	PUMPS SWITCH ON LIGHTS	C	4	0	
-22-02	CENTER TANK FUEL OVERRIDE/JETTISON PUMPS				
-22-02A		C	2	1	(M)(O) One may be inoperative provided: a) Inoperative pump is deactivated, b) Center tank quantity indication operates normally, c) With center tank fuelled, fuel quantity remaining in main wing tanks is adequate to reach a suitable airport if remaining center pump fails at any time, and d) Centre tank fuel is accounted for in the airplane weight and balance in the event centre tank fuel cannot be used.
-22-02B		C	2	0	(M)(O) May be inoperative provided: a) Pumps are deactivated. b) Center tank quantity indication operates normally, and c) Center tank fuel is considered unusable and is accounted for in the airplane weight and balance. NOTE: AFM fuel loading and usage limitations are for usable fuel (Refer respective Boeing Weight & Balance Control & Loading Manual, where concerned AFM pages are attached).
-22-02-01	PUMP SWITCH PRESS LIGHTS	C	2	0	
-22-02-02	PUMPS WITCH ON LIGHTS	C	2	0	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 28: FUEL	28-4 (Rev 23) Sep , 2023
---	------------------------------------	-----------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-22-03	FUEL CROSSFEED VALVES	C	2	1	(M)(O) One may be inoperative provided: a) Inoperative fuel crossfeed valve is deactivated closed, and b) Remaining valve is verified to operate normally before each departure. FOR ETOPS / (EDTO) FLIGHTS Note: Before each departure, perform the following fuel crossfeed valve check: 1. Position operative crossfeed valve on and verify associated FUEL CROSSFEED AFT or FWD advisory message does not display. 2. Position operative crossfeed valve off and verify associated FUEL CROSSFEED AFT or FWD advisory message does not display.
-22-03-01	CROSSFEED SWITCH VALVE LIGHTS	C	2	0	
-22-04	FUEL SCAVENGE SYSTEMS	C	2	0	(O) May be inoperative provided: a) Center tank quantity indication operates normally, and b) Appropriate amount of center tank fuel is considered unusable and is accounted for in the airplane weight and balance. NOTE: AFM fuel loading and usage limitations are for usable fuel (Refer respective Boeing Weight & Balance Control & Loading Manual, where concerned AFM pages are attached).
-22-05	FUEL SHUTOFF VALVE BATTERY	C	1	0	
-22-06	FUEL SCAVENGE SHUTOFF VALVES (WITHOUT PRR 62777-79S OR EQUIVALENT INSTALLED)	C	4	3	(M) One valve may be inoperative provided: a) Inoperative valve is open, b) Fuel quantity system operates normally, and c) Remaining valve on that side is verified to operate normally.
-22-06A		C	4	0	(M) May be inoperative provided: a) Inoperative valve(s) is open, b) Center tank remains empty, and c) Center tank quantity indication operates normally.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 28: FUEL	28-5 (Rev 23) Sep , 2023
---	------------------------------------	-----------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-22-07	AUXILIARY (AUX) FUEL SWITCH				NOT APPLICABLE
-25-01	APU DC FUEL PUMP	C	1	0	(M) May be inoperative provided fuel pump is deactivated.
-25-02	APU FUEL SHUTOFF VALVE	C	1	0	(M)(O) May be inoperative provided: a) Valve is deactivated closed, b) Other procedures do not require the use of the APU, c) Backup AC power system is verified to operate normally before each departure, and d) Flight remains within 180 minutes of landing at a suitable airport.
-25-03	APU FUEL ISOLATION VALVE	C	1	0	(M) May be inoperative provided isolation valve is deactivated closed.
-26-01	DEFUEL VALVE	C	1	0	(M) Defuel valve may be inoperative provided it is secured closed.
-31-01	FUEL JETTISON SYSTEM				
-31-01-01	(WITHOUT PRR 62777-79S OR EQUIVALENT INSTALLED)	C	1	0	(M)(O) May be inoperative provided: a) Jettison system is deactivated, b) Jettison nozzle valves are secured closed, and c) Appropriate performance adjustments are applied (Refer DDG).
-31-01-01-01	ARM SWITCH FAULT LIGHT	C	1	0	
-31-01-01-02	ARM SWITCH ARMED LIGHT	C	1	0	
-31-01-02	(WITH PRR 62777-79S OR EQUIVALENT INSTALLED)				NOT APPLICABLE
-31-02	CENTER TANK JETTISON ISOLATION VALVES				
-31-02-01	-200				NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 28: FUEL	28-6 (Rev 23) Sep , 2023
---	------------------------------------	-----------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-31-02-02 -200ER/200LR/300ER (WITHOUT PRR 62777-79S OR EQUIVALENT INSTALLED)				
-31-02-02A	C	2	0	(M) May be inoperative provided: a) Inoperative valve(s) is secured closed, and b) Fuel jettison system is considered inoperative.
-31-02-02B	C	2	0	(M)(O) May be inoperative provided: a) Inoperative valve(s) is secured closed, and b) Appropriate gross weight and center-of-gravity adjustments are applied.
-31-02-03 -200ER/200LR/300ER (WITH PRR 62777-79S OR EQUIVALENT INSTALLED)				NOT APPLICABLE
-31-03 MAIN TANKS JETTISON PUMPS				
-31-03-01 (WITHOUT PRR 62777-79S OR EQUIVALENT INSTALLED)	C	2	0	(M)(O) May be inoperative provided: a) Inoperative pump is deactivated, and b) Appropriate performance adjustments are applied. (Refer DDG)
-31-03-02 (WITH PRR 62777-79S OR EQUIVALENT INSTALLED)				NOT APPLICABLE
-31-04 FUEL JETTISON NOZZLE VALVES				
-31-04-01 (WITHOUT PRR 62777-79S OR EQUIVALENT INSTALLED)				
-31-04-01A	C	2	1	(M) One nozzle valve may be inoperative provided it is secured closed.
-31-04-01B	C	2	0	(M)(O) May be inoperative provided: a) Both jettison nozzle valves are secured closed, b) Jettison system is deactivated, and c) Appropriate performance penalties are applied. (Refer DDG)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 28: FUEL	28-7 (Rev 22a) Sep , 2020
---	------------------------------------	------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-31-04-01-01 SWITCH VALVE LIGHTS	C	2	0		
-31-04-01-02 SWITCH ON LIGHTS	C	2	0		
-31-04-02 (WITH PRR 62777-79S OR EQUIVALENT INSTALLED)					NOT APPLICABLE
-40-01 FUEL SYNOPTIC DISPLAY	C	1	0		May be inoperative provided individual fuel quantity indications required for dispatch operate normally.
-41-01 FUEL QUANTITY INDICATIONS (FLIGHT DECK)					
-41-01-01 CENTER TANK	B	1	0		(M)(O) May be inoperative provided: a) Main tank fuel quantity indications operate normally, b) Fuel quantity in center tank is verified by fuel quantity measuring stick, c) All pumps for the center tank operate normally, d) Fuel flow indications operate normally, e) FMC FUEL is initialized with the known total fuel quantity, f) Flight remains within 180 minutes of landing at a suitable airport, and g) For -200ER, -200LR and -300ER appropriate gross weight and center-of-gravity adjustments are applied. (Refer DDG)
-41-01-02 MAIN TANKS					
-41-01-02-01(WITHOUT PRR62777-79S OR EQUIVALENT INSTALLED)	B	2	1		(M)(O) One may be inoperative provided: a) Center tank fuel quantity indication operates normally, b) Fuel quantity in associated tank is verified by fuel quantity measuring stick, c) All pumps for the associated tank operate normally, d) Fuel flow indications operate normally, e) FMC FUEL is initialized with the known total fuel quantity, f) Flight remains within 180 minutes of landing at a suitable airport, and g) For -200ER, -200LR and -300ER appropriate gross weight and center-of-gravity adjustments are applied. (Refer DDG)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 28: FUEL	28-8 (Rev 22a) Sep , 2020
---	------------------------------------	------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-41-01-02-02 (WITH PRR62777-79S OR EQUIVALENT INSTALLED)				NOT APPLICABLE	
-41-01-03 AUXILIARY TANK(S)				NOT APPLICABLE	
-41-02 FUEL QUANTITY PROCESSOR INPUT/OUTPUT (I/O) CHANNELS	B	2	1	(O) One channel may be inoperative provided: a) All flight deck fuel indications operate normally, b) Fuel flow indications operate normally, and c) FMC TOTALIZER FUEL quantity agrees with fuel quantity indications.	
-41-03 TOTAL FUEL QUANTITY INDICATION	C	1	0	(O) May be inoperative provided: a) Fuel flow indications operate normally, b) FMC fuel is initialized with the known total fuel quantity, and c) Flight remains within 180 minutes of landing at a suitable airport.	
-42-01 AUXILIARY TANK FUEL PUMP PRESSURE TRANSDUCER(S)				NOT APPLICABLE	
-43-01 FUEL TEMPERATURE INDICATING SYSTEM	C	1	0	(O) May be inoperative provided Total Air Temperature (TAT) is used as an indication of fuel temperature.	
-44-01 MEASURING STICKS	C	16	0	May be inoperative provided fuel quantity is determined by other acceptable means.	
-45-01 AUXILIARY TANK FUEL CELL PRESSURE TRANSDUCER(S)				NOT APPLICABLE	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 29: HYDRAULIC POWER	29-1 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-11-01	ENGINE DRIVEN PUMPS (EDP) DEPRESSURIZATION FUNCTION	C	2	1	
-11-02	CENTER SYSTEM PRIMARY ALTERNATING CURRENT MOTOR PUMPS (ACMP)	C	2	1	(M) One may be inoperative provided: a) Inoperative center ACMP is deactivated, and b) Both center ADPs operate normally.
-11-03	CENTER SYSTEM DEMAND AIR DRIVEN PUMPS (ADP)				
-11-03A		C	2	1	(M)(O) One may be inoperative provided: a) Inoperative ADP is selected off, b) Both center system ACMPs operate normally, c) Remaining ADP heater operates normally, d) Remaining ADP AUTO function operates normally, e) Associated pump is verified not running when selected OFF, f) APU is used as ADP air source during takeoff, and g) Appropriate performance adjustments are applied. (Ref DDG)
-11-03B		C	2	1	(M)(O) One may be inoperative provided: a) Inoperative ADP is deactivated, b) Both center system ACMPs operate normally, c) Associated pump is verified not running when selected OFF, d) Remaining ADP is selected ON for the entire flight, e) APU is used as ADP air source during takeoff, and f) Appropriate performance adjustments are applied. (Ref DDG)
-11-03C		C	2	1	(M)(O) One may be inoperative provided: a) Inoperative ADP is selected off, b) Both center system ACMPs operate normally, c) Associated pump is verified not running when selected OFF, d) Remaining ADP is selected ON for the entire flight, e) APU is used as ADP air source during takeoff, and f) Appropriate performance adjustments are applied. (Ref DDG)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 29: HYDRAULIC POWER	29-2 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES	
-11-03-01 ADP AUTO / HEATER FUNCTION (-200ER WITH PRR 61570 OR SB 777-29-0004 INCORPORATED & (-200LR/300ER)				
	-11-03-01A	C 2 1	(M)(O) One may be inoperative provided: a) Remaining ADP operates normally, b) Associated ADP ON and OFF selector positions are verified to operate normally, and c) Associated ADP is selected ON for the entire flight.	
	-11-03-01B	C 2 1	(M)(O) One may be inoperative provided: a) Both center system ACMPs operate normally, b) Associated ADP ON and OFF selector positions are verified to operate normally, c) Associated ADP is selected ON for the entire flight, d) APU is used as ADP air source during takeoff, and e) Appropriate performance adjustments are applied. (Ref DDG)	
	-11-03-01C	C 2 0	(M)(O) May be inoperative provided: a) Both center system ACMPs operate normally, b) ADP ON and OFF selector positions are verified to operate normally for both pumps, c) One ADP is selected ON for the entire flight, d) APU is used as ADP air source during takeoff, and e) Appropriate performance adjustments are applied. (Ref DDG)	
-11-04 DEMAND PUMP SELECTORS				
-11-04-01 CENTER SYSTEM AUTO POSITION	C 2 0	May be inoperative provided associated demand ADP auto function is considered inoperative.		

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 29: HYDRAULIC POWER	29-3 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-11-04-02	LEFT & RIGHT SYSTEM AUTO POSITION	C	2	0	(O) May be inoperative provided: a) ON and OFF positions operate normally, and b) Associated pump selector is ON for takeoff and landing.
-11-04-03	ON POSITION	C	4	0	May be inoperative provided the AUTO and OFF positions for associated pump operate normally.
-11-05	HYDRAULIC INTERFACE MODULE (HYDIM) CARDS	C	4	3	(M) One may be inoperative provided: a) Inoperative card is in the HYDIM center right (HCR) card position, b) Individual center system pump pressure indications operate normally, and c) Center system Demand ADP C1 auto function is considered inoperative.
-11-06	CENTER HYDRAULIC ISOLATION SYSTEM	C	1	0	(M) May be inoperative provided center hydraulic isolation system is deactivated open.
-18-01	RESERVOIR QUANTITY GAGE (REMOTE)	C	1	0	
-18-02	HYDRAULIC SYSTEM ACCUMULATORS	C	3	0	
-18-02-01	CHARGING VALVES	C	3	0	
-18-02-02	CHARGING GAGES	C	3	0	
-21-01	RAT HEATER SYSTEM				
-21-01-01	-200ER WITH PRR 61570 OR SB 777-29-0004 INCORPORATED, AND (-200LR/300ER)	A	1	0	May be inoperative provided repairs are made within three flight days.
-21-01-02	-200ER WITHOUT PRR 61570 OR SB 777-29-0004 INCORPORATED				NOT APPLICABLE
-21-02	RAM AIR TURBINE SWITCH LIGHTS				
-21-02-01	UNLKD LIGHT	C	1	0	
-21-02-02	PRESS LIGHT	C	1	0	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 29: HYDRAULIC POWER	29-4 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-30-01	HYDRAULIC PUMP LIGHTS				
-30-01-01	FAULT LIGHTS	C	8	5	One in each system may be inoperative.
-30-01-02	ON LIGHTS	C	4	0	
-30-02	HYDRAULIC SYNOPTIC DISPLAY	C	1	0	
-31-01	HYDRAULIC SYSTEM PRESSURE TRANSDUCERS	C	3	0	May be inoperative provided all associated system pump pressure indications operate normally.
-31-02	PUMP PRESSURE INDICATION SYSTEMS				
-31-02-01	LEFT & RIGHT SYSTEM	C	4	2	(M) One in each system may be inoperative provided: a) Associated system pressure transducer operates normally, and b) Associated pump operation is verified normal before each departure.
-31-02-02	CENTER SYSTEM				
-31-02-02A		C	4	3	(M) One may be inoperative provided: a) Associated system pressure transducer operates normally, and b) Associated pump operation is verified normal before each departure.
-31-02-02B		C	4	3	One may be inoperative for an associated inoperative pump.
-32-01	PUMP TEMPERATURE INDICATIONS				
-32-01-01	LEFT & RIGHT SYSTEMS	C	4	2	(M) One in each system may be inoperative provided: a) Associated pump pressure indications operate normally, and b) Associated pump operation is verified normal before each departure.
-32-01-02	CENTER SYSTEM				
-32-01-02A		C	4	3	(M) One may be inoperative provided: a) Associated pump pressure indications operate normally, and b) Associated pump operation is verified normal before each departure.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 29: HYDRAULIC POWER	29-5 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-32-01-02B	C	4	3	One may be inoperative for an associated inoperative pump.
-33-01 HYDRAULIC FLUID QUANTITY INDICATIONS (FLIGHT DECK)	C	3	1	(M) Two may be inoperative provided: a) Reservoir level is verified normal before each departure, b) Associated system pressure indication operates normally, and c) For the center system indication inoperative, center hydraulic isolation system is considered inoperative.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 30: ICE AND RAIN PROTECTION	30-1 (PIA Rev 00) JULY, 2012
---	---	---

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-11-01	WING ANTI-ICE SYSTEMS	C	2	0	(M) May be inoperative provided: a) Associated valve is locked closed, b) Wing anti-ice control switch remains OFF, and c) Airplane is not operated in known or forecast icing conditions.
-11-02	WING ANTI-ICE CONTROL (CARD AND SWITCH)	C	1	0	(M) May be inoperative provided: a) Both wing anti-ice valves are locked closed, b) Wing anti-ice control switch remains OFF, and c) Airplane is not operated in known or forecast icing conditions.
-11-03	WING ANTI-ICE INDICATIONS (WAI)	C	2	0	
-21-01	ENGINE ANTI-ICE SYSTEMS	C	2	1	(M) One may be inoperative provided: a) Valve is locked closed, b) Associated engine anti-ice control switch remains OFF, c) Airplane is not operated in known or forecast icing conditions, and d) Flight remains within 120 minutes of landing at a suitable airport.
-21-01-01	PW & RR				NOT APPLICABLE
-21-01-02	GE				
-21-01-02A		C	2	1	(M)(O) For operations at ambient temperature 38 degrees C or below, one may be inoperative provided: a) Valve is deactivated open using deactivation kit, b) Engine fan case overheat detection system operates normally, c) Turbine case cooling air flow systems operate normally, d) Appropriate performance adjustments are applied, (Refer DDG) and e) Except for GE90-100 series, EECs must be operated in the normal mode. (-200ER)
-21-01-02B		C	2	1	(M)(O) For operations at ambient temperature 38 degrees C or below, one may be inoperative provided: a) Valve is electrically disconnected and verified open, b) Engine fan case overheat detection system operates normally, (Continued...)

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-21-01	ENGINE ANTI-ICE SYSTEMS (Continued...)				c) Associated EAI pressure sensor system operates normally, d) Associated EAI card operates normally, e) Turbine case cooling air flow systems operate normally, f) Appropriate performance adjustments are applied, (Refer DDG) and g) Except for GE90-100 series, EECs must be operated in the normal mode. (-200ER)
	-21-01-02C	A	2	1	(M)(O) For operations at ambient temperature above 38 degrees C, one may be inoperative provided: a) Valve is deactivated open using deactivation kit, b) Engine fan case overheat detection system operates normally, c) Turbine case cooling air flow systems operate normally, and d) Appropriate performance adjustments are applied, (Refer DDG) e) Repairs are made within three flight days, and f) Except for GE90-100 series, EECs must be operated in the normal mode. (-200ER)
	-21-01-02D	A	2	1	(M)(O) For operations at ambient temperature above 38 degrees C, one may be inoperative provided: a) Valve is electrically disconnected and verified open, b) Engine fan case overheat detection system operates normally, c) Associated EAI pressure sensor system operates normally, d) Associated EAI card operates normally, e) Turbine case cooling air flow systems operate normally, f) Appropriate performance adjustments are applied, (Refer DDG) g) Repairs are made within three flight days, and h) Except for GE90-100 series, EECs must be operated in the normal mode. (-200ER)
21-02	ENGINE ANTI-ICE INDICATIONS (EAI)	C	2	0	

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-31-01	PITOT PROBE HEATER SYSTEMS				
	-31-01-01 RIGHT PITOT HEATER	B	1	0	(M) May be inoperative provided: a) Right pitot air data module is deactivated, b) Left and center pitot air data modules operate normally, c) Left and center pitot probe heater systems operate normally, d) Left static air data module operates normally, e) Standby airspeed indication operates normally, f) Right AIR DATA/ATT instrument source switch operates normally, g) Approach minimums do not require its use, h) SAARU data is verified to be available to the right PFD before each departure, and i) Left and center pitot probes are inspected before each departure.
	-31-01-02 LEFT PITOT HEATER	B	1	0	(M) May be inoperative provided: a) Left pitot air data module is deactivated, b) Right and center pitot air data modules operate normally, c) Right and center pitot probe heater systems operate normally, d) Right static air data module operates normally, e) Standby airspeed indication operates normally, f) Left AIR DATA/ATT instrument source switch operates normally, g) Approach minimums do not require its use, h) SAARU data is verified to be available to the left PFD before each departure, and i) Right and center pitot probes are inspected before each departure.
	-31-01-03 CENTER PITOT HEATER	B	1	0	(M) May be inoperative provided: a) Left and right pitot air data modules operate normally, b) Left and right pitot probe heater systems operate normally, c) Standby airspeed indication operates normally, d) Approach minimums do not require its use, e) Airplane is not operated in known or forecast icing conditions or visible moisture, f) Left and Right pitot probes are inspected before each departure, and g) Flight remains within 120 minutes of landing at a suitable airport.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 30: ICE AND RAIN PROTECTION	30-4 (PIA Rev 23) Sep , 2023
---	---	---

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-33-01	TOTAL AIR TEMPERATURE (TAT) PROBE HEATER SYSTEM				
-33-01-01	SINGLE TAT SYSTEM (EXCEPT APBMS)	C	1	0	May be inoperative provided: a) Airplane is not operated in known or forecast icing conditions, and b) Flight remains within 120 minutes of landing at a suitable airport.
-33-01-02	DUAL TAT SYSTEM (APBMS ONLY)				
-33-01-02A		C	2	1	
-33-01-02B		C	2	0	May be inoperative provided: a) Airplane is not operated in known or forecast icing conditions, and b) Flight remains within 120 minutes of landing at a suitable airport.
-34-01	ENGINE PT2/TT2 PROBE HEATER SYSTEMS (PW & RR)				NOT APPLICABLE
-41-01	FLIGHT DECK FORWARD WINDOW PRIMARY HEATER SYSTEMS	C	2	1	One may be inoperative provided: a) Both flight deck side (No. 2) window heater systems operate normally, b) Airplane is not operated in known or forecast icing conditions, c) Associated switch remains OFF, and d) Flight remains within 120 minutes of landing at a suitable airport.
-41-02	FLIGHT DECK SIDE (NO.2) WINDOW HEATER SYSTEMS	C	2	1	One may be inoperative provided: a) Both flight deck forward window primary heater systems operate normally, and b) Associated switch remains OFF.
-41-03	FLIGHT DECK AFT (NO.3) WINDOW HEATER SYSTEMS	D	2	0	
-41-04	WINDOW HEAT SWITCH LIGHTS				
-41-04-01	INOP LIGHTS	C	4	0	
-41-04-02	ON LIGHTS	C	4	0	

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-42-01	WINDSHIELD WIPERS	C	2	0	May be inoperative provided: a) Airplane is not operated in precipitation within 5 statute miles of the airport of departure or intended landing, and b) Approach minimums do not require its use.
-42-01-01	LOW SPEED FUNCTIONS	C	2	0	May be inoperative provided associated high speed function operates normally.
-42-01-02	HIGH SPEED FUNCTIONS				
-42-01-02A		C	2	1	One may be inoperative provided associated low speed function operates normally.
-42-01-02B		C	2	0	May be inoperative provided: a) Both low speed functions operate normally, and b) Airplane is not operated in known or forecast precipitation of moderate or greater intensity within 5 statute miles of the airport of departure or intended landing.
-42-01-03	INTERMITTENT FUNCTION	C	2	0	
-71-01	DRAIN MAST HEATERS	C	2	0	(M) May be inoperative provided: a) Associated galley service and lavatory sinks are not used, and b) Associated galley and lavatory sink water supply shutoff valves are closed.
-81-01	ICE DETECTORS	C	2	0	(O) May be inoperative provided engine and wing anti-ice systems are operated manually.



06 MAY 2019

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 31: INDICATING/RECORDING SYSTEMS	31-1 (PIA Rev 23) Sep, 2023
---	--	---

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-09-01	SYSTEMS CARDFILE ARINC SIGNAL GATEWAY (ASG) CARDS	C	4	2	(O) Two ASG cards and/or the associated ARINC 629 couplers may be inoperative provided: a) One inoperative ASG card and/or associated ARINC 629 coupler is in the left systems cardfile, b) One inoperative ASG card and/or associated ARINC 629 coupler is in the right systems cardfile, c) Left and right hydraulic Demand pump ON and OFF selectors operate normally, d) Left and right hydraulic Demand pump selectors are ON for takeoff and landing, and e) Center system hydraulic Demand pump C1 or C2 is ON for takeoff and landing.
-09-01-01	LEFT SYSTEMS CARDFILE ASG CARDS	C	2	1	(O) One ASG card and/or the associated ARINC 629 coupler may be inoperative in the left systems cardfile provided: a) Left hydraulic Demand pump ON and OFF selector operate normally, b) Left hydraulic demand pump selector is ON for takeoff and landing, and c) Both right systems cardfile ASG cards operate normally.
-09-01-02	RIGHT SYSTEMS CARDFILE ASG CARDS	C	2	1	(O) One ASG card and/or the ARINC 629 coupler may be inoperative in the right systems cardfile provided: a) Right hydraulic Demand pump ON and OFF selector operate normally, b) Right hydraulic Demand pump selector is ON for takeoff and landing, and c) Both left systems cardfile ASG cards operate normally.
-09-02	SYSTEMS CARDFILE POWER SUPPLIES				
-09-02-01	LEFT SYSTEMS CARDFILE (LSCF) POWER SUPPLIES	C	2	1	(M)(O) One power supply may be inoperative provided it is deactivated.
-09-02-02	RIGHT SYSTEMS CARDFILE (RSCF) POWER SUPPLIES				
(Continued...)					

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 31: INDICATING/RECORDING SYSTEMS	31-2 (Rev 23) Sep, 2023
---	--	-------------------------------------

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-09-02	SYSTEMS CARDFILE POWER SUPPLIES (Continued...)			
-09-02-02A	C	2	1	(M) Power supply 2 may be inoperative provided it is deactivated.
-09-02-02B	C	2	1	(M) Power supply 1 may be inoperative provided: a) Power supply 1 is deactivated, and b) Left air/ground system operates normally.
-20-01	COUNTDOWN TIMER			NOT APPLICABLE
-25-01	CLOCKS	C	2	1
-25-02	CLOCKS SWITCHES	C	2	1
-31-01	FLIGHT DATA RECORDER (FDR) SYSTEM		1	1
-33-01	AIRBORNE PRINTER (FLIGHT DECK)			
-33-01A	C	1	0	(O) May be inoperative provided ACARS system is operative
-33-01B	D	1	0	May be inoperative provided procedures do not require its use.
-33-01-01	MISCELLANEOUS FEATURES	D	1	0
-35-01	QUICK ACCESS RECORDER			
-35-01A	C	1	0	(O) May be inoperative provided alternate procedures are used.
-35-01B	D	1	0	May be inoperative provided procedures do not require its use.
-35-02	AIRPLANE CONDITION MONITORING FUNCTION (ACMF)	D	1	0

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 31: INDICATING/RECORDING SYSTEMS	31-3 (Rev 23) Sep , 2023
---	--	--------------------------------------

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-41-01	AIRPLANE INFORMATION MANAGEMENT SYSTEM (AIMS)				Note: For CAT IIIB approaches must be serviceable.
-41-01-01	AIMS-2 CABINET BUS	C	1	0	May be dispatched with AIMS CABINET BUS faults.
-51-01	MASTER WARNING LIGHTS (GLARESHIELD)	C	2	1	One may be inoperative provided the aural for the master warning system operates normally.
-51-02	MASTER CAUTION LIGHTS (GLARESHIELD)	C	2	1	One may be inoperative provided the aural for the master caution system operates normally.
-51-03	AURAL WARNING SPEAKER SYSTEMS	C	2	1	One may be inoperative provided master warning and master caution lights operate normally.
-51-04	WARNING ELECTRONICS SYSTEM (WES) CHANNELS				
-51-04-01	PASSENGER				
-51-04-01A		C	4	3	One may be inoperative provided: a) Both stabilizer position indicators operate normally, and b) SPEED LIM flag is not displayed adjacent to the airspeed indication on either PFD.
-51-04-01B		C	4	3	(M) One WES CHANNEL may be inoperative provided it is deactivated.
-51-04-02	777F				NOT APPLICABLE
-51-05	WARNING ELECTRONICS SYSTEM (WES) AUTOPILOT DISCONNECT WARNING FUNCTION	B	1	0	(O) May be inoperative provided: a) Autopilots are not used, b) Approach minimums do not require use of the autopilots, c) Number of flight segments and segment duration is acceptable to flight crew, d) Enroute operations do not require use of the autopilots, and e) Flight remains within 180 minutes of landing at a suitable airport.
-51-05-01	WES AUTOPILOT INTERFACES	C	3	2	(O) One may be inoperative provided the WES Autopilot disconnect warning function is verified to operate normally.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 31: INDICATING/RECORDING SYSTEMS	31-4 (PIA Rev 23a) Jul , 2024
---	--	-----------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES	
-51-06	TAKEOFF CONFIGURATION CHECK SWITCH (APBMG & BMH)			
-51-06A	C	1	0	
-51-06B	D	1	0	May be inoperative provided procedures do not require its use.
-61-01	DISPLAY UNITS (DU)	C	6	5
-61-02	CURSOR CONTROL DEVICES (CCD)			
-61-02A	C	2	1	
-61-02B	C	2	0	(O) May be inoperative provided paper checklist procedures are used.
-61-02-01	CURSOR LOCATION LIGHTS	C	6	0
-61-02-02	CURSOR LOCATION SWITCH LIGHTS	C	6	0
-61-03	REMOTE LIGHT SENSOR (RLS) SYSTEM	B	1	0
-61-04	DISPLAY SELECT PANEL (DSP)			
-61-04-01	-200ER & -200LR	C	1	0
-61-04-02	-300ER	C	1	0
-61-04-03	MULTIFUNC- TION DISPLAY LIGHTS	C	3	0
-61-04-04	ILLUMINATED SWITCH LIGHTS			
-61-04-04-01	-200ER & -200LR	C	15	0

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 31: INDICATING/RECORDING SYSTEMS	31-5 (PIA Rev 23a) Jul , 2024
---	--	--

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-61-04-04-02 -300ER	C	16	0		
-61-05 EICAS STATUS MESSAGES (APBGJ,BGK,BGL,200LR, 300ER EXCEPT BMS / BMG,BMH,BHX / BMS)					
-61-05A	C	531/ 515/ 534	0	(M)(O) May be inoperative provided it is verified before each flight that the associated equipment operates normally.	
-61-05B	C	531/ 515/ 534	0	May be inoperative provided associated equipment is considered inoperative.	
-61-06 INBOARD DISPLAY SELECTOR POSITIONS	B	8	7	(M)(O) One may be inoperative provided: a) Lower center display unit operates normally, b) Remaining positions are verified to operate normally on associated selector, and c) Alternate procedures are used when required. (Ref. DDG)	
-61-07 ELECTRONIC CHECKLIST (ECL) SYSTEM	C	1	0	(M)(O) May be inoperative provided electronic checklist is deactivated and established paper checklist procedures are used.	
-61-07-01 ECL CLOSED LOOP SWITCH INDICATIONS	C	1	0	(O) May be inoperative provided ECL line item override procedures are used when required to complete checklists.	
-61-08 EFIS CONTROL PANELS	C	2	1	(M)(O) One may be inoperative provided the associated CDU EFIS control panel backup feature is verified to operate normally.	
-61-08-01 MAP SWITCH LIGHTS	C	14	0		
-61-09 INSTRUMENT SOURCE SWITCHES					
-61-09-01 NAV AND DSPL CTRL SWITCHES	C	5	0	May be inoperative provided associated switches are not moved in flight.	
-61-09-02 AIR DATA/ATT SWITCHES					
-61-09-02A	C	2	1	One may be inoperative provided associated switch is not moved in flight.	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 31: INDICATING/RECORDING SYSTEMS	31-6 (PIA Rev 23) Sep, 2023
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-61-09-02B	C	2	0		(M) May be inoperative provided: a) One AIR DATA/ATT switch is in the normal position, b) Associated display units are verified to operate from selected sources, and c) Associated switches are not moved inflight.
-61-10 GROUND MANEUVER CAMERA SYSTEM (-300ER)	D	1	0		
-61-11 HEADING REFERENCE (HDG REF) SWITCH					
-61-11-01 TRUE FUNCTION	C	1	0		(O) May be inoperative provided enroute or contingency procedures including diversion airports do not require its use.
-61-11-02 SWITCH LIGHTS					
-61-11-02-01 TRUE LIGHT	C	1	0		
-61-11-02-02 NORM LIGHT	C	1	0		
-61-12 HEAD-UP DISPLAY (HUD)/ENHANCED FLIGHT VISION SYSTEM (EFVS) (STC ST03891AT)					NOT APPLLCABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 32: LANDING GEAR	32-1 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-00-01	LANDING GEAR SYNOPTIC DISPLAY	C	1	0	
-08-01	PROXIMITY SENSOR ELECTRONIC UNIT (PSEU) CHANNELS				
-08-01A		C	4	3	One may be inoperative in PSEU 1 provided the flight lock system is considered inoperative.
-08-01B		C	4	3	One may be inoperative in PSEU 2.
-08-01C		C	4	2	(M)(O) One may be inoperative in each PSEU provided: a) PSEU 1 transmission is verified on the left ARINC 629 system bus, b) PSEU 2 transmission is verified on the right ARINC 629 system bus, and c) Flight lock system is considered inoperative.
-08-01D		C	4	2	(M)(O) One may be inoperative in each PSEU provided: a) PSEU 1 transmission is verified on the right ARINC 629 systems bus, b) PSEU 2 transmission is verified on the left ARINC 629 systems bus, c) After takeoff, gear remains down for 2 minutes before retraction, d) Takeoff performance is based on landing gear extended, (Ref. FPPM) and e) Flight lock system is considered inoperative.
-08-01E		C	4	2	(M)(O) One may be inoperative in each PSEU provided: a) Landing gear are secured in the down position, b) Airplane is dispatched in accordance with Gear Down procedure. (Ref. FPPM), and c) Flight lock system is considered inoperative.
-09-01	AIR/GROUND SYSTEM WEIGHT ON WHEELS				
-09-01-01	LEFT SYSTEM	C	1	0	(M) May be inoperative provided: a) Associated system is deactivated, b) Right air/ground system operates normally, and c) Right system card file power supply 1 operates normally.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 32: LANDING GEAR	32-2 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-09-01-02 RIGHT SYSTEM	C	1	0	(M) May be inoperative provided: a) Associated system is deactivated, b) Left air/ground system operates normally, and c) All galley/lavatory water supply shutoff valves are closed.	
-11-01 NOSE LANDING GEAR STRUT UPPER AIR CHAMBER PRESSURE INDICATOR (-300ER)	D	1	0		
-30-01 LANDING GEAR ACTUATION SYSTEM	B	1	0	(M)(O) May be inoperative provided: a) Inoperative components are properly secured by an accepted procedure, b) Landing Gear is secured in the down position, and c) Airplane is dispatched in accordance with Gear Down procedure. (Ref. FPPM)	
-30-02 SEMI-LEVER GEAR (SLG) SYSTEM (-300ER)	C	1	0	(M)(O) May be inoperative provided: a) SLG system is deactivated, and b) Appropriate performance adjustments are applied (Ref. DDG)	
-31-01 LANDING GEAR LEVER LOCK SOLENOID	C	1	0	(O) May be inoperative provided solenoid is in the locked position.	
-31-02 LANDING GEAR SELECTOR VALVE ELECTRICAL CONTROL CIRCUITS	C	2	1	(M) One UP/DOWN electrical control circuit may be inoperative provided the remaining UP/DOWN circuit is verified to operate normally each flight day.	
-32-01 MAIN GEAR DOOR UPLOCK SPRINGS ASSEMBLIES	B	4	2	(M)(O) One spring on one door up-lock mechanism may be missing and gear retraction allowed provided 270 KIAS/0.82 Mach is not exceeded during flight.	
-32-01-01 SPRING RETENTION CORD	C	4	0		
-32-02 MAIN GEAR UPLOCK SPRINGS	B	4	3	(M)(O) One spring on one main gear uplock mechanism may be missing and gear retraction allowed provided 270 KIAS/0.82 Mach is not exceeded during flight.	
-32-03 MAIN GEAR SIDE BRACE SPRINGS		4	4		
-35-01 LANDING GEAR ALTERNATE EXTEND SYSTEM	B	1	0	(M)(O) May be inoperative provided: a) Landing Gear are secured in the down position, b) Alternate extend system is deactivated, and c) Airplane is dispatched in accordance with Gear Down procedure. (Ref FPPM)	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 32: LANDING GEAR	32-3 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-35-01-01	ALTERNATE EXTEND HYDRAULIC PRESSURE SWITCH	B	1	0	(M) May be inoperative provided: a) Inoperative pressure switch is open, and b) Landing gear doors are verified to open using the alternate extend system.
-35-02	GROUND DOOR RELEASE CONTROL SYSTEM	C	1	0	(M) May be inoperative provided: a) Both door open control switches are verified to be open, b) Landing gear doors are verified to open using the Alternate extend system, and c) Landing gear doors are closed before each departure.
-35-02-01	DOOR OPEN CONTROL SWITCHES	B	2	0	(M)(O) May be inoperative closed provided: a) Inoperative control switch(s) is closed, b) Landing Gear are secured in the down position, c) Landing gear Alternate extend system is deactivated, and d) Airplane is dispatched in accordance with Gear Down procedure. (Ref. FPPM)
-41-01	BRAKE ACCUMULATOR PRESSURE INDICATOR (WHEEL WELL)	D	1	0	May be inoperative provided flight deck brake accumulator pressure indicator operates normally.
-41-02	BRAKE ACCUMULATOR PRESSURE INDICATOR (FLIGHT DECK)	C	1	0	(M) May be inoperative provided brake accumulator charge is verified normal once each flight day.
-41-03	BRAKE SOURCE INDICATION SYSTEM	A	1	0	(M)(O) May be inoperative provided: a) Flight deck brake accumulator pressure indicator operates normally, b) Normal and alternate brake systems are verified to operate normally, c) Brake accumulator isolation valve is verified to operate normally, d) Towing staff is informed of brake source failure indication, and e) Repairs are made within three flight days.
-41-03-01	BRAKE SOURCE LIGHT	C	1	0	May be inoperative provided the BRAKE SOURCE alerting message operates normally.
-42-01	NORMAL ANTISKID VALVES				
-42-01A		C	12	10	(M)(O) One valve per each six wheel truck may be inoperative provided: a) Associated brake is deactivated using the deactivation assembly, and b) FPPM performance decrements for brake(s) deactivated are applied.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 32: LANDING GEAR	32-4 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-42-01B	C	12	10	(M)(O) One valve per each six wheel truck may be inoperative provided: a) Associated brake is deactivated by capping the brake line, b) After takeoff, gear remains down for two minutes before retraction, c) FPPM decrements for brake(s) deactivated are applied, and d) Takeoff performance is based on landing gear extended.	
-42-02 ANTISKID WHEEL SPEED TRANSDUCERS	C	12	10	(O) One transducer per each six wheel truck may be inoperative provided: a) FPPM performance decrements for brake(s) deactivated are applied, and b) No other brakes are deactivated on that truck.	
-42-03 ALTERNATE ANTISKID VALVES	C	8	0	(M) May be inoperative provided manual braking capability on the alternate brake system is verified to operate normally.	
-42-04 AUTOBRAKE SYSTEM (INCLUDING AUTOBRAKE SOLENOID VALVE)					
-42-04A	C	1	0	(M) May be inoperative provided: a) Auto brake solenoid valve is verified closed, and b) Auto brake selector remains in the OFF position.	
-42-04B	C	1	0	(M) May be inoperative provided: a) Auto brake hydraulic control module is deactivated, and b) Auto brake selector remains in the OFF position.	
-44-01 BRAKE STATUS LIGHTS (ON NOSE GEAR)					
-44-01A	C	3	0	(O) May be inoperative provided ground crew is informed of the brake system status.	
-44-01B	D	3	0	May be inoperative provided procedures do not require their use.	
-44-02 GEAR RETRACTION BRAKING SYSTEM	C	1	0	(O) May be inoperative provided: a) After takeoff gear remains down for two minutes before retraction, and b) Appropriate performance adjustments are applied. (Ref. DDG) (Continued....)	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 32: LANDING GEAR	32-5 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-44-02	GEAR RETRACTION BRAKING SYSTEM (Continued)			NOTE: In the event of engine failure after V1, retract landing gear after takeoff.	
-44-03	PARKING BRAKE SET INDICATION SYSTEM (FLIGHT DECK)	C	1	0	(M)(O) May be inoperative provided: a) Ground crew is informed of the brake system status, b) Parking brake valve is verified to operate normally once each flight day, c) Parking brake and brake antiskid interface indication is verified to operate normally once each flight day, and d) Parking brake takeoff configuration warning system is verified to operate normally.
-45-01	WHEEL BRAKES				
-45-01A		C	12	10	(M)(O) One per each six wheel truck may be inoperative provided: a) Associated brake is deactivated with a deactivation assembly, and b) FPPM performance decrements for brake(s) deactivated are applied.
-45-01B		C	12	10	(M)(O) One per each six wheel truck may be inoperative provided: a) Associated brake is deactivated by capping the brake line, b) After takeoff gear remains down for two minutes before retraction, c) FPPM performance decrements for brake deactivated are applied, and d) Takeoff performance is based on landing gear extended. (Ref. FPPM)
-45-01C		C	12	10	(M)(O) One per each six wheel truck may be removed from the center axle only provided: a) Associated brake line is capped, b) After takeoff gear remains down for two minutes before retraction, c) FPPM performance decrements for brakes deactivated are applied, and d) Takeoff performance is based on landing gear extended. (Ref. FPPM)
-45-02	WHEEL TIE BOLTS	A	244	230	(M) One per wheel may be broken or missing provided: a) Affected wheel is removed, checked for broken parts or damage, and replaced if broken parts or damage is found, b) Associated brake is checked for broken parts or damage, and is replaced or deactivated if broken parts or damage is found, (Continued...)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 32: LANDING GEAR	32-6 (PIA Rev 11) SEP, 2019
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-45-02	WHEEL TIE BOLTS (Continued...)				c) After each landing, wheel is inspected for additional broken or missing tie bolts, and d) Operations are limited to five departures before repairs are made.
-45-03	INTEGRAL TIRE PRESSURE INDICATORS				NOT APPLICABLE
-45-04	NOSE GEAR SPIN BRAKE	C	2	0	(O) May be inoperative or missing provided: a) After takeoff, gear remains down for two minutes before retraction, and b) Appropriate performance adjustments are applied. (Refer DDG) NOTE: In the event of engine failure after V1, retract landing gear after takeoff.
-46-01	BRAKE TEMPERATURE INDICATION SYSTEM	C	1	0	(O) May be inoperative provided FPPM Maximum Quick Turnaround Weight limitations are observed. For brake cooling fans installed: NOTE 1: Brake cooling fans will be inoperative when all brake temperature indications are inoperative. NOTE 2: Any portion of the system that operates normally may be used.
-47-01	BRAKE COOLING FANS				NOT APPLICABLE
-49-01	TIRE PRESSURE INDICATION SYSTEM				
-49-01A					NOT APPLICABLE
-49-01B		D	1	0	May be inoperative provided procedures do not require its use. NOTE: The pressure check (by using direct gauge /TPG is already covered in daily check.
-53-01	MAIN GEAR STEERING SYSTEM (INCLUDING INDICATION)	C	1	0	(M) May be inoperative provided: a) Main gear steering actuators are verified locked in the center position, and b) Main gear steering system is deactivated.
-61-01	LANDING GEAR POSITION INDICATION SYSTEMS	B	2	0	(M)(O) May be inoperative provided: a) Landing Gear are secured in the down position, and b) Airplane is dispatched in accordance with Gear Down procedure. (Ref FPPM) (Continued....)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 32: LANDING GEAR	32-7 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-61-01	LANDING GEAR POSITION INDICATION SYSTEMS (Continued...)				
-61-01-01	TRUCK TILT SENSORS	C	4	0	(M)(O) May be inoperative provided the Nose Gear lock, Nose Gear down, Main Gear side brace and Main Gear drag brace sensors are verified to operate normally each flight day.
-61-01-02	NOSE GEAR NOT- COMPRESSED SENSORS				
-61-01-02-01	PSEU-1	C	1	0	M) May be inoperative provided: a) Nose Gear lock, Nose Gear down, Main Gear side brace and Main Gear drag brace sensors are verified to operate normally each flight day, and b) PSEU-2 operates normally.
-61-01-02-02	PSEU-2	C	1	0	(M) May be inoperative provided: a) Nose Gear lock, Nose Gear down, Main Gear side brace and Main Gear drag brace sensors are verified to operate normally each flight day, and b) Left equipment cooling controller operates normally, and c) PSEU-1 operates normally.
-61-02	LANDING GEAR DOOR POSITION SENSORS	C	6	3	(M) One per gear (Nose, left Main, right Main) may be inoperative provided sensor is failed in the door not closed position.
-61-03	LANDING GEAR UPLOCK POSITION SENSORS	C	6	3	(M) One per gear may be inoperative provided the sensor is failed in the unlocked position and the associated landing gear door position sensors operate normally.
-71-01	TAIL STRIKE DETECTOR CHANNELS				
-71-01A		C	2	1	
-71-01B		C	2	0	(M)(O) May be inoperative provided: a) Tail section is visually inspected for damage before each departure, b) During takeoff and flare, flight crew and cabin crew should be alert for a potential tail strike. If a tail strike is perceived by the flight crew or reported from the cabin during takeoff, do the Tail Strike Non-Normal Checklist. c) TAIL STRIKE caution message is disabled.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 32: LANDING GEAR	32-8 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-72-01	TAIL SKID (-300ER)	C	1	0	
	-72-01-01				NOT APPLICABLE
	-72-01-02 (-300ER)	C	1	0	(M)(O) May be inoperative provided: a) Tail skid is secured in the extended position, b) Water supplies associated with the aft drain mast are secured off, and c) Appropriate performance adjustments are applied. (Refer DDG)
-72-02	TAIL SKID POSITION SENSING SYSTEM (-300ER)				
	-72-02-01				NOT APPLICABLE
	-72-02-02 -300ER				
	-72-02-02A	C	1	0	(M) May be inoperative provided tail skid extend/retract function is verified to operate normally once each flight day.
	-72-02-02B	C	1	0	(M)(O) May be inoperative provided: a) Tail skid is secured in the extended position, b) Water supplies associated with aft drain mast are secured off, and c) Appropriate performance adjustments are applied. (Refer DDG)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 33: LIGHTS	33-1 (PIA Rev 22a2) JUN , 2023
---	--------------------------------------	-----------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-11-01	FLIGHT COMPARTMENT AND INSTRUMENT LIGHTING SYSTEM	C	1	0	Individual lights or light controls may be inoperative provided: a) Remaining lighting system lights are sufficient to clearly illuminate all required instruments, controls and other devices for which it is provided, b) Remaining lighting system lights are positioned so that direct rays are shielded from flight crew eyes, c) Lighting configuration and intensity is acceptable to the flight crew, and d) Captain's emergency dome light operates normally. NOTE: Individual button/switch lights and/or annunciations/indications are excluded from this relief.
-11-01-01	STORM SWITCH ON LIGHT	C	1	0	
-13-01	MASTER BRIGHTNESS CONTROL	C	1	0	May be inoperative provided the master brightness control switch is selected OFF.
-16-01	MASTER DIM AND TEST SYSTEM	B	1	0	Dim function may be inoperative provided: a) TEST and BRT functions operate normally, and b) Light intensity is acceptable to the flight crew.
-21-01	CABIN INTERIOR ILLUMINATION				
-21-01-01	PASSENGER				
-21-01-01-01	WITH POWERED FLOOR PROXIMITY EMERGENCY ESCAPE PATH LIGHTING SYSTEM	C	167/189	-	Individual lights may be inoperative provided: a) Sufficient lighting remains for crew members to perform their duties, and b) For night operations beyond 60 minutes of landing at a suitable airport, at least 75% of the standby lights operate normally.
(200ER&LR=167/300ER=189)					
-21-01-01-02	WITH PHOTOLUMINESCENT FLOOR PROXIMITY EMERGENCY ESCAPE PATH MARKING SYSTEM				NOT APPLICABLE
-21-01-02	777F				NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 33: LIGHTS	33-2 (PIA Rev 22a2) JUN, 2023
---	--------------------------------------	----------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES	
-24-01 PASSENGER INFORMATION SIGNS (PASSENGER) (APBMG & BMH = 83 OTHER-200ER/LR =72) BMS=85,OTHER300ER=80)	-24-01A	C 83/ 72/ 85/ 80	0	(M) May be inoperative provided: a) Associated passenger seat, or lavatory is not occupied from which a passenger information sign is not readily legible, and b) Associated seat or lavatory must be blocked and placarded – DO NOT OCCUPY. NOTE: These provisos are not intended to prohibit lavatory use or inspections by crewmembers.
	-24-01B	C 83/ 72/ 85/ 80	0	(O) May be inoperative and the associated passenger seat or lavatory may be occupied provided: a) PA system operates normally and can be clearly heard throughout the cabin during flight, and b) PA system is used to alert the cabin crew and to notify passengers when seat belts should be fastened, when smoking is prohibited, and when passengers should return to seats.
	-24-01C	C 83/ 72/ 85/ 80	0	(O) May be inoperative or missing provided: a) No passengers are carried, b) A maximum of 19 authorized persons including crewmembers, company employees or PCAA inspectors for non-passenger carrying operations are carried, and c) All authorized persons on board must be briefed prior to each takeoff and landing regarding the inoperative passenger information signs.
	-24-01-01 FLIGHT DECK AUTOMATIC FUNCTION	C 1	0	(O) May be inoperative provided: a) Manual control function operates normally, and b) Manual control function is used for takeoff and landing.
	-24-01-02 CREW / ATTENDANT REST AREAS (APBMG & BMH=2)/ (APBMS & -200LR=3)	C 2/3	0	(O) May be inoperative provided communication via cabin interphone system is established and used.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 33: LIGHTS	33-3 (PIA Rev 23) Sep, 2023
---	--------------------------------------	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-24-01-03 AURAL TONE FUNCTION	C	1	0	(O) May be inoperative provided passenger address system operates normally and may be used if required.	
-24-02 SUPERNUMERARY/ COURIER AREA LIGHTED INFORMATION SIGNS (777F)				NOT APPLICABLE	
-28-01 STERILE FLIGHT COMPARTMENT LIGHT SYSTEM				NOT APPLICABLE	
-31-01 MAIN WHEEL WELL AND NOSE WHEEL WELL SERVICE AREA LIGHTS (200ER=33/ 200LR & 300ER=35)					
-31-01A	C	33/35	0	NOTE: Relief for the Air Conditioning Compartment, APU Compartment, Stabilizer Compartment and Electrical Equipment Center Service Area Lights was moved to MEL Item 25-20-01.	
-31-01B	D	33/35	0	May be inoperative provided operations are not conducted at night. NOTE: Relief for the Air Conditioning Compartment, APU Compartment, Stabilizer Compartment and Electrical Equipment Center Service Area Lights was moved to MEL Item 25-20-01.	
-31-02 CARGO LOADING AREA LIGHTS 200ER,LR & 300ER=11/ BMG&H, BMS=12					
-31-02-01 PASSENGER	D	11/12	0	Deleted sub item in MMEL Rev 23	
-37-01 CARGO COMPARTMENT LIGHTS -200ER & LR = 39/ -300ER = 53	C	39/ 53	-	Individual lights may be inoperative provided sufficient lighting remains for ground personnel to perform their duties.	
-37-02 MAIN DECK ALERT SYSTEM (777F)				NOT APPLICABLE	
-41-01 WING ILLUMINATION LIGHTS	C	2	0		
-41-01-01 WING SWITCH ON LIGHT	C	1	0		
-42-01 TAXI LIGHTS	C	2	0		

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 33: LIGHTS	33-4 (PIA Rev 23) Sep, 2023
---	--------------------------------------	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-42-02	LANDING LIGHTS				
-42-02A	C	4	2	Two may be inoperative for night operations.	
-42-02B	C	4	0	May be inoperative provided operations are not conducted at night.	
-42-02-01	DIM FUNCTION	C	2	0	
-42-03	RUNWAY TURNOFF LIGHTS	C	2	0	
-43-01	POSITION LIGHTS				
-43-01A	C	8	4	May be inoperative provided: a) One stationary red wingtip bulb operates normally, b) One stationary green wingtip bulb operates normally, and c) One stationary white bulb per wingtip operates normally.	
-43-01B	C	8	0	May be inoperative between sunrise and sunset.	
-43-01-01	NAV SWITCH ON LIGHT	C	1	0	
-43-02	TAIL LIGHTS	D	2	0	
-44-01	ANTI-COLLISION LIGHTS				
-44-01-01	RED UPPER AND LOWER FUSELAGE BEACON LIGHTS				
-44-01-01A	C	2	1	One may be inoperative provided white tail and wing tip strobe lights operate normally.	
-44-01-01B	C	2	1	One be inoperative provided: a) At least one white tail or wing tip strobe light operates normally, and b) Operations are not conducted at night.	
-44-01-02	WHITE TAIL AND WING TIP STROBE LIGHTS				
-44-01-02A	C	3	0	May be inoperative provided red upper and lower fuselage beacon lights operate normally.	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 33: LIGHTS	33-5 (PIA Rev 23) Sep, 2023
---	--------------------------------------	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-44-01-02B	C	3	0	May be inoperative provided: a) At least one red fuselage beacon light operates normally, and b) Operations are not conducted at night.
-45-01 LOGO LIGHTS	D	4	0	
-45-01-01 LOGO SWITCH ON LIGHT	D	1	0	
-51-01 INTERIOR EMERGENCY LIGHTS (APBMG & BMH =227/ OTHER-200ER/LR =214/ BMS=224/ OTHER300ER=215)	C	227/ 214/ 224/ 215	-	A random 25% of lights/signs may be inoperative provided: a) Inoperative area illumination lights are not adjacent, b) Not more than one overhead area light or exit sign at each door is inoperative, c) Cross-aisle exit signs operate normally, and d) Flight deck emergency dome light operates normally. NOTE: Lights associated with an inoperative door or slide/raft are not required.
-51-02 EXTERIOR EMERGENCY SLIDE LIGHTS (-200ER&LR/-300ER)	C	8/14	0	May be inoperative provided operations are not conducted at night.
-51-02-01 (-200ER&200LR)	A	8	7	One may be inoperative provided: a) Associated passenger entry door is considered inoperative, and b) Repairs are made within one flight day.
-51-02-02 (-300ER) -51-02-02-01 DOORS 1L,1R,2L, 2R,4L,4R, 5L AND 5R	A	8	7	One may be inoperative provided: a) Associated passenger entry door is considered inoperative, b) Exterior emergency slide lights for doors 3L and 3R operate normally, and c) Repairs are made within one flight day.
-51-02-02-02 DOORS 3L AND 3R	A	6	3	Lights associated with one door may be inoperative provided: a) Associated passenger entry door is considered inoperative, b) All remaining door exterior emergency slide lights operate normally, and c) Repairs are made within one flight day.
-51-02-03 777F				NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 33: LIGHTS	33-6 (PIA Rev 23) Sep, 2023
---	--------------------------------------	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-51-03	FLOOR PROXIMITY EMERGENCY LIGHTING SYSTEMS (PASSENGER)				
-51-03-01	POWERED ESCAPE PATH LIGHTING SYSTEM	C	1	-	A random 25% of lights may be inoperative provided inoperative floor proximity lights are not adjacent. NOTE: Lights associated with an inoperative door or slide/raft are not required.
-51-03-02	PHOTOLUMINESCENT ESCAPE PATH MARKING SYSTEM				NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 34: NAVIGATION	34-1 (PIA Rev 23) Sep , 2023
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-12-01	MACH INDICATIONS				
-12-01A	C	2	1	(O) One may be inoperative provided flight descends to FL 290 or below, if failure of the second indication occurs in flight.	
-12-01B	C	2	0	(O) May be inoperative provided flight remains at FL 290 or below.	
-12-02	TRUE AIRSPEED INDICATIONS	C	2	0	
-13-01	STANDBY AIRSPEED INDICATOR SYSTEM (NON-ISFD SYSTEM)				NOT APPLICABLE
-16-01	ALTITUDE ALERTING SYSTEM	A	1	0	(O) May be inoperative provided: a) Autopilot with altitude hold and altitude capture operates normally, b) Enroute operations do not require its use, c) Airplane does not depart from KHI where repair or replacement can be made, and d) Repairs are made within three flight days. NOTE: Must be serviceable for RVSM operations.
-16-01-01	AURAL ALERT	C	1	0	May be inoperative provided: a) Visual alert operates normally, and b) Autopilot with altitude hold and altitude capture operates normally.
-16-01-02	VISUAL ALERT	C	1	0	May be inoperative provided: a) Aural alert operates normally, and b) Autopilot with altitude hold and altitude capture operates normally.
-21-01	DUAL TOTAL AIR TEMPERATURE (TAT) SYSTEMS (APBMS ONLY)	C	2	1	
-21-02	STATIC AIR TEMPERATURE (SAT) INDICATION	C	1	0	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 34: NAVIGATION	34-2 (PIA Rev 10) MAY , 2018
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-21-03	AIR DATA INERTIAL REFERENCE UNIT (ADIRU)			
-21-03-01	ADIRU FAULTS			
-21-03-01A	B	1	0	(M) May be dispatched with fault indicated by ADIRU status message provided: a) Adequate ground navigation facilities are available, b) Non-stabilized magnetic compass operates normally, c) Approach minimums do not require use of triple channel autoland, and d) SAARU data is verified available to both PFDs before each departure.
-21-03-01B	B	1	0	(M) May be dispatched with fault indicated by ADIRU status message provided: a) Both GPS receivers operate normally, b) Both FMCs operate normally, c) Non-stabilized magnetic compass operates normally, d) Approach minimums do not require use of triple channel autoland, and e) SAARU data is verified available to both PFDs before each departure.
-21-03-02	ON BAT LIGHT	C	1	0
-21-03-03	ADIRU SWITCH LIGHTS			
-21-03-03-01	OFF LIGHT	C	1	0
-21-03-03-02	ON LIGHT	C	1	0
-21-04	PITOT AIR DATA MODULES (PRIMARY – ARINC 629)			
-21-04-01	RIGHT PITOT AIR DATA MODULE	B	1	0
				(M) May be inoperative provided: a) Left and center pitot probe heater systems operate normally, b) Left and center pitot air data modules operate normally, c) Left static air data module operates normally, d) Standby airspeed indication operates normally, e) Right AIR DATA/ATT instrument source switch operate normally, f) SAARU data is verified to be available to the right PFD before each departure, g) Left and center pitot probes are inspected before each departure, and h) Approach minimums do not require its use.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 34: NAVIGATION	34-3 (PIA Rev 06) APR, 2016
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES	
-21-04-02	LEFT PITOT AIR DATA MODULE	B	1	0	(M) May be inoperative provided: a) Right and center pitot probe heater systems operate normally, b) Right and center pitot air data modules operate normally, c) Right static air data module operates normally, d) Standby airspeed indication operates normally, e) Left AIR DATA/ATT instrument source switch operates normally, f) SAARU data is verified to be available to the left PFD before each departure, g) Right and center pitot probes are inspected before each departure, and h) Approach minimums do not require its use.	
-21-04-03	CENTER PITOT AIR DATA MODULE	B	1	0	(M) May be inoperative provided: a) Left and right pitot probe heater systems operate normally, b) Left and right pitot air data modules operate normally, c) Left and right static air data modules operates normally, d) Standby airspeed indication operates normally, e) Both AIR DATA/ATT instrument source switches operate normally, f) SAARU data is verified to be available to the both PFDs before each departure g) Left and right pitot probes are inspected before each departure, and h) Approach minimums do not require its use.	
-21-05	STATIC AIR DATA MODULES (PRIMARY – ARINC 629)					
-21-05-01	RIGHT STATIC AIR DATA MODULE	C	1	0	(M) May be inoperative provided: a) Left and center static air data modules operate normally, b) Left pitot air data module operates normally, c) Right AIR DATA/ATT instrument source switch operates normally, d) Standby airspeed indication operates normally, e) SAARU data is verified to be available to the right PFD before each departure, and f) Approach minimums do not require its use.	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 34: NAVIGATION	34-4 (PIA Rev 06) APR, 2016
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-21-05-02	LEFT STATIC AIR DATA MODULE	C	1	0	(M) May be inoperative provided: a) Right and center static air data modules operate normally, b) Right pitot air data module operate normally, c) Left AIR DATA/ATT instrument source switch operates normally, d) Standby airspeed indication operates normally, e) SAARU data is verified to be available to the left PFD before each departure, and f) Approach minimums do not require its use.
-21-05-03	CENTER STATIC AIR DATA MODULE	C	1	0	(M) May be inoperative provided: a) Left and right static air data modules operate normally, b) Left and right pitot air data modules operate normally, c) Both AIR DATA/ATT instrument source switches operate normally, d) SAARU data is verified to be available to both PFDs before each departure, e) Standby airspeed indication operates normally, and f) Approach minimums do not require its use.
-21-06	ANGLE OF ATTACK (AOA) VANE SYSTEM	C	2	1	
-21-07	SECONDARY ATTITUDE AIR DATA REFERENCE UNIT (SAARU)				
-21-07-01	WITHOUT INTEGRATED STANDBY FLIGHT DISPLAY (ISFD)				NOT APPLICABLE
-21-07-02	WITH INTEGRATED STANDBY FLIGHT DISPLAY (ISFD)	C	1	0	(O) May be inoperative provided: a) Approach minimums do not require the use of the SAARU, b) ADIRU operates normally, c) Left, right and center pitot air data modules operate normally, d) Left, right and center static air data modules operate normally, e) ISFD operates normally, f) One GPS receiver operates normally, and g) Non-stabilized magnetic compass operates normally.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 34: NAVIGATION	34-5 (PIA Rev 06) APR, 2016
---	--	--

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-21-08	INTEGRATED STANDBY FLIGHT DISPLAY (ISFD)				
-21-08-01	ATTITUDE INDICATION	B	1	0	May be inoperative provided: a) Operations are conducted in Day VMC only, and b) Operations are not conducted into known or forecast over-the-top conditions.
-21-08-02	AIRSPEED INDICATION	B	1	0	(M) May be inoperative provided: a) All ARINC 629 pitot air data modules operate normally, b) All ARINC 629 static air data modules operate normally, c) All pitot probe heater systems operate normally, d) Both AIR DATA/ATT instrument source switches operate normally, and e) SAARU data is verified available to both PFDs before each departure.
-21-08-03	APPROACH MODE	C	1	0	
-21-08-04	HEADING DISPLAY	C	1	0	
-21-08-05	SWITCH LIGHTS	C	5	0	
-23-01	NON-STABILIZED MAGNETIC COMPASS (STANDBY)	B	1	0	May be inoperative provided ADIRU operates normally.
-24-01	STANDBY ATTITUDE INDICATOR (NON-ISFD SYSTEM)				NOT APPLICABLE
-31-01	INSTRUMENT LANDING SYSTEM (ILS)				Note: For CAT IIIB approaches all three ILS RECEIVERS must be serviceable.
		D	3	2	Two must be operative for CAT II approach.
		C	3	0	May be inoperative provided approach minimums, do not require their use.
-31-02	GLIDE SLOPE ANTENNA SWITCHING	D	3	2	One may be inoperative provided approach minimums do not require use of the associated ILS receiver.
		C	3	0	May be inoperative provided approach minimums, do not require their use.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 34: NAVIGATION	34-6 (PIA Rev 11A) SEP, 2019
---	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-31-03	LOCALIZER ANTENNA SWITCHING	D	3	2	One may be inoperative provided approach minimums do not require use of the associated ILS receiver.
		C	3	0	May be inoperative provided approach minimums do not require their use.
-32-01	MARKER BEACON SYSTEM	C	1	0	May be inoperative provided approach minimums do not require its use.
-33-01	RADIO ALTIMETER SYSTEMS	B	3	2	One may be inoperative provided approach minimums or operating procedures do not require its use. NOTE: No operational restrictions upto CAT III A minimas. For CAT III B & C approaches, all 3 Radio Altimeters must be serviceable.
-34-01	MICROWAVE LANDING SYSTEMS				NOT APPLICABLE
-35-01	PARA VISUAL DISPLAYS				NOT APPLICABLE
-43-01	WEATHER RADAR SYSTEMS				
	-43-01A				NOT APPLICABLE
	-43-01B				NOT APPLICABLE
	-43-01C	D	2	1	
	-43-01-01 PREDICTIVE WINDSHEAR FUNCTION				
	-43-01-01A	C	2	1	(O) May be inoperative provided: a) Latest ATIS reports are monitored, and b) Reactive windshear alert mode (GPWS Mode 7) operates normally.
	-43-01-01B	B	2	1	(O) May be inoperative provided: a) Latest ATIS reports are monitored, and b) Takeoffs and landings are not conducted in known or forecast windshear conditions. NOTE: FCOM supplementary procedures for windshear avoidance and windshear recovery are followed.
	-43-01-02 AUTO TILT FUNCTION	C	1	0	May be inoperative provided manual tilt function operates normally.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 34: NAVIGATION	34-7 (PIA Rev 06) APR, 2016
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES		
-45-01	TRAFFIC COLLISION AND AVOIDANCE SYSTEM (TCAS)	1	1	
-45-01-01	RESOLUTION ADVISORY (RA) DISPLAY SYSTEMS			
-45-01-01A	C 2	1	(O) One may be inoperative on the non-flying pilot side.	
-45-01-01B	C 2	0	(O) May be inoperative provided: a) Traffic Alert (TA) visual display and audio functions operate normally, b) TA only mode is selected by the crew, and c) Enroute or approach procedures do not require its use.	
-45-01-02	TRAFFIC ALERT (TA) DISPLAY SYSTEM	C 2	0	(O) May be inoperative provided: a) RA visual display and audio functions operate normally, and b) Enroute or approach procedures do not require its use.
-45-01-03	AUDIO FUNCTION	B 1	0	May be inoperative provided enroute or approach procedures do not require use of TCAS.
-45-01-04	AIRSPACE SELECTION FUNCTION (EXCEPT APBMG & BMH/ APBMG & BMH)	C 1 / 2	0	
-46-01	GROUND PROXIMITY WARNING SYSTEMS (GPWS)	1	1	
-51-01	VOR NAVIGATION SYSTEMS	D 2	1	a) No.1 must be serviceable. b) One must be serviceable for RNAV operations.
-53-01	ATC TRANSPONDER/ AUTOMATIC ALTITUDE REPORTING SYSTEMS			
-53-01A	D 2	1	One must be serviceable for RNAV operations.	
-53-01B	B 2	0	May be inoperative provided: a) Enroute operations do not require its use, and b) Prior to flight, approval is obtained from ATC facilities having jurisdiction over the planned route of flight.	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 34: NAVIGATION	34-8 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-53-01-01	ELEMENTARY AND ENHANCED DOWNLINK AIRCRAFT REPORTABLE PARAMETERS	A	2	0	May be inoperative provided: a) Enroute operations do not require their use, and b) Repairs are made prior to completion of next heavy maintenance visit.
-53-01-02	ADS-B SQUITTER TRANSMISSIONS				Dispatch relief for this equipment moved to Item 34-53-02 in MEL Rev 23.
-53-02	AUTOMATIC DEPENDANT SURVEILLANCE-BROADCAST (ADS-B) SYSTEM (OUT)				
-53-02A		B	2	0	(O) May be inoperative provided prior to flight, authorization is obtained from ATC facilities having jurisdiction over the planned route of flight using an approved authorization process. NOTE: Any ADS-B function that operates normally may be used.
-53-02B		C	2	1	(O) One may be inoperative provided operative transponder is selected.
-53-02C		D	2	0	May be inoperative provided: a) Enroute operations do not require their use, and b) It is not required by regulations. NOTE: Any ADS-B function that operates normally may be used.
-53-02-01	ADS-B EXTENDED SQUITTER				
-53-02-01A		B	2	0	(O) May be inoperative provided prior to flight, authorization is obtained from ATC facilities having jurisdiction over the planned route of flight using an approved authorization process. NOTE: Any ADS-B Out function that operates normally may be used.
-53-02-01B		C	2	1	(O) One may be inoperative provided operative transponder is selected.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 34: NAVIGATION	34-9 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-53-02-01C	D	2	0	May be inoperative provided: a) Enroute operations do not require its use, and b) It is not required by regulations. NOTE: Any ADS-B Out function that operates normally may be used.
-53-02-02 ADS-B IN				NOT APPLICABLE
-55-01 DISTANCE MEASURING EQUIPMENT (DME)	D	2	1	One must be serviceable if required by in flight procedures.
	D	2	0	Both may be inoperative if not required by in-flight and approach. Two GPS along with dual FMS must be serviceable and updating the data for RNAV operation.
57-01 ADF SYSTEMS		2	2	Both must be serviceable if flight procedures are predicted on ADF's use. Both must be serviceable for flights involving Russian routes.
-58-01 GLOBAL POSITIONING SYSTEMS				
-58-01A	C	2	0	May be inoperative provided: a) Enroute operations do not require their use, and b) SAARU operates normally.
-58-01B	D	2	1	One may be inoperative provided enroute operations do not require its use. NOTE: ONE MUST BE OPERATIVE FOR RNAV OPERATIONS IF BOTH DMEs ARE INOPERATIVE.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 34: NAVIGATION	34-10 (PIA Rev 23) Sep , 2023
---	--	----------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-61-01	FLIGHT MANAGEMENT COMPUTING SYSTEMS (FMCS)				
-61-01-01	WITH AIMS-1				NOT APPLICABLE
-61-01-02	WITH AIMS-2	C	2	1	(M) One may be inoperative provided: a) Remaining FMC is verified to operate normally, b) Enroute operations do not require its use, and c) One must be serviceable for RNAV and CPDLC Operations.
-61-01-03	NAVIGATION DATABASES	A	2	0	(O) May be inoperative provided: a) Operations do not require its use, b) Status and suitability of Navigation facilities used to define route of flight are verified by dispatch. (Refer Jeppesen chart Notams) c) Current aeronautical charts are used to verify navigation fixes before dispatch, d) The ICAO flight plan is update(s) to notify ATC of the navigation equipment status of the aircraft, and e) Is repaired within 10 flight days. f) RNAV APPROACHES, RNAV1 or RNAV2 STAR and SIDS not be flown. RNAV5 is allowed. The waypoint entry to be manual. Enroute charts to be used to check any gross error by inserting Fix data on selected waypoints on RNAV5 routes. Note: An out-of-currency or out-of-date navigation database is not authorized
-61-02	FMC SELECTOR	C	1	0	
-61-03	CONTROL DISPLAY UNITS (CDU)				
-61-03-01	PASSENGER	C	3	2	(O) Center CDU may be inoperative. Note: Any function that operates normally may be used.
-61-03-01-01	DSPY,MSG, OFST AND EXEC LIGHTS	C	12	0	
-61-03-01-02	LINE SELECT LIGHTS,FUNCTION LIGHTS, EXECUTE LIGHTS, ALPHA/ NUMERIC LIGHTS AND MISCELLANEOUS KEY LIGHTS	C	207	0	
-61-03-02	777F				NOT APPLICABLE

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 35: OXYGEN	35-1 (PIA Rev 22a2) JUN, 2023
--	--------------------------------------	----------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-11-01	CREW OXYGEN SYSTEM				
-11-01-01	CREW OXYGEN PRESSURE INDICATION SYSTEM	B	1	0	(M) May be inoperative provided: a) Oxygen supply is verified to be above minimum required before each departure, and b) Crew oxygen shutoff valve(s) is verified open.
-11-01-01-01	OVERBOARD DISCHARGE INDICATOR DISC	B	1	0	May be damaged or missing.
-11-01-02	CREW OXYGEN SOLENOID BLEED VALVE	B	1	0	(M) May be inoperative provided: a) Solenoid bleed valve is deactivated closed, and b) Crew oxygen shutoff valve(s) is verified open.
-21-01	PASSENGER OXYGEN SYSTEM (CHEMICAL) (PASSENGER)	B	1	0	(O) May be inoperative provided: a) Flight is not conducted where the minimum enroute altitude is above 14000 feet MSL. - Flight remains at or below FL 250, - Portable oxygen units are provided for 10% of the passengers for a minimum of 30 minutes. b) Both air conditioning packs operate normally, c) Pressurization system operates normally, d) Both engines bleed systems operate normally, and e) Passengers are appropriately briefed.
-21-02	PASSENGER OXYGEN SERVICE UNITS (PASSENGER) (APBMG&BMH, 200LR = 141/ -200ER=137/ BMS=168/ 300ER= 159)				
-21-02A		B	141 137/ 168/ 159	0	(M) May be inoperative provided a) Associated seats are blocked and placarded to prevent occupancy. b) Associated flight attended seat is considered inoperative, and c) Associated lavatory door is locked closed and placarded, INOPERATIVE – DO NOT ENTER. Note: This provision is not intended to prohibit lavatory inspections by crewmembers.

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 35: OXYGEN	35-2 (PIA Rev 23) Sep , 2023
--	--------------------------------------	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES	
-21-02B	B	141 137/ 168/ 159	0	(O) Use DDG item 35-21-01 (Boeing recommendation ref:PIA-PIA-15-0016-01C) May be inoperative provided: a) Flight is not conducted where the minimum enroute altitude is above 1400 feet MSL. - Flight remains at or below FL 250, - Portable oxygen units are provided for 10% of the passengers for a period of 30 minutes. b) Both air conditioning packs operate normally, c) Pressurization system operates normally, d) Both engines bleed systems operate normally, and e) Passengers are appropriately briefed.
-21-03 PASSENGER/ SUPERNUMERARY OXYGEN AUTOMATIC PRESENTATION SYSTEM	B	1	0	(O) May be inoperative provided: a) Manual deployment system operates normally, and b) Flight remains at FL 300 or below.
-21-04 PASSENGER OXYGEN ON LIGHT	C	1	0	
-21-05 CREW/ATTENDANT REST OXYGEN MODULES (PASSENGER) (APBMG&BMH(IF INSTALLED)/- 200LR/APBMS)				
-21-05-01 SEAT MODULE	B	2/2/ 2	0	(M) May be inoperative provided associated seat is blocked and placarded to prevent occupancy.
-21-05-02 BUNK MODULES	B	6/8/ 10	0	(M) May be inoperative provided a conspicuous barrier strap or rope is placed across the associated bunk with a placard attached stating the bunk is not to be used.
-21-05-03 VANITY MODULE (INCLUDES SINK WITH DRINK STORAGE AREA)				NOT APPLICABLE
-21-06 SUPERNUMERARY SEATS/CREW REST/LAVATORY GASEOUS OXYGEN SYSTEM (777F)				NOT APPLICABLE

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 35: OXYGEN	35-3 (PIA Rev 23) Sep , 2023
--	--------------------------------------	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES	
-21-07	SUPERNUMERARY SEATS (ONLY) GASEOUS OXYGEN SYSTEM (777F)					NOT APPLICABLE
-21-08	LAVATORY CHEMICAL OXYGEN SYSTEM (777F)					NOT APPLICABLE
-21-09	CREW REST CHEMICAL OXYGEN SYSTEMS (777F)					NOT APPLICABLE
-22-01	PASSENGER/ SUPERNUMERARY OXYGEN PRESSURE INDICATION SYSTEM (GASEOUS) (APBMS ONLY)	C	1	0	(M)	May be inoperative provided: a) Oxygen supply is verified to be above minimum required before each departure, and b) Associated oxygen shutoff valves are verified open before each departure. Note: For minimum required oxygen pressure, refer details on page 35-5.
	-22-01-01 OVERBOARD DISCHARGE INDICATOR (APBMS ONLY)	B	1	0		May be damaged or missing
-31-01	PORTABLE OXYGEN DISPENSING UNITS (OR EQUIVALENT) (BOTTLE AND MASK) (11 CUBIC FEET) (APBMG&BMH =15 OTHER-200ER/LR = 14 APBMS=21,OTHER300ER= 16)	D	15/ 14/ 21/ 16	-	a)	1 Upto 50 cabin occupants. - 2 Upto 100 cabin occupants. - 3 Upto 150 cabin occupants - 4 Upto 200 cabin occupants - 5 Upto 250 cabin occupants - 6 Upto 300 cabin occupants - 7 Upto 350 cabin occupants - 8 Upto 400 cabin occupants b) An inoperative or not properly serviced portable oxygen bottle/unit remains in a certified location until removed or serviced at the next suitable maintenance facility, c) Location placarding is removed or obscured, and d) Required distribution is maintained throughout the airplane, as per Emergency Equipment Chart. Note 1: Inoperative portable oxygen bottles or units, removed from a certified location or removed from the aircraft, are subject to dangerous goods regulations. Note 2: Medical equipment installed in the aircraft as part of an EMS operation is not considered part of the normal complement of equipment. No MEL relief applies to that equipment and maintenance and inspection requirements do not apply.

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 35: OXYGEN	35-4 (PIA Rev 23) Sep , 2023
--	--------------------------------------	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES		
-31-01-01 TAMPER SEALS OR TAGS			NOT APPLICABLE
-31-02 PROTECTIVE BREATHING EQUIPMENT (PBE)			
PBE IN PASSENGER CABIN EXCEPT CREW REST AREAS			
-200ER & -200LR=8/ BMS=18/ OTHER -300ER=11	D	8/18/ 11	5/6/5
PBE IN CREW REST AREAS APBMG&H(IF INSTALLED=1/ 200LR=8/BMS=7		1/8/ 7	1/8/ 7
-31-02-01 TAMPER SEALS OR TAGS			NOT APPLICABLE

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 35: OXYGEN	35-5 (PIA Rev 23) Sep , 2023
--	--	---

For AP-BMS aircraft, passenger oxygen system is of gaseous oxygen cylinders instead of chemical generators. Duration of oxygen availability in case of decompression depends upon oxygen cylinder pressure, temperature and number of passengers onboard. Guidance for this calculation is given on page 2.1.2 in FPPM for AP-BMS available on web. For ease of use of that information following table is formulated.

This table is based on following assumptions:

1. FL390 at decompression.
2. Total post decompression time is one hour. This includes descent, level-off at intermediate altitude (if applicable) and flight at final level-off altitude.
3. Time to shut down 90% of masks at or below 14000 ft pressure altitude is 11 minute. This duration is a nominal time determined by Boeing as the amount of time it would take for the Flight Attendants to walk down the aisle and shut off 90% of the oxygen masks in order to obtain the minimum required oxygen availability for 10% of the passengers when the airplane is flying at altitudes above 10,000 ft up to and including 14,000 ft.

AP-BMS MINIMUM OXYGEN CYLINDER PRESSURE DISPATCH REQUIREMENT(FOR PAX)

NO. OF PAX →	100	150	200	250	300	350	400	442
CYLINDER TEMPERATURE ↓ (DEG C)	REQUIRED PRESSURE (PSI)							
-10	365	425	484	542	608	666	731	797
-5	372	434	494	554	621	680	746	813
0	379	443	504	566	634	694	761	829
5	386	452	514	578	647	708	776	845
10	393	461	524	590	660	722	791	861
15	400	470	534	602	673	736	806	877
20	407	479	544	614	686	750	821	893
25	414	488	554	626	699	764	836	909
30	421	497	564	638	712	778	851	925
35	428	506	574	650	725	792	866	941
40	435	515	584	662	738	806	881	957
45	442	524	594	674	751	820	896	973
50	449	533	604	686	764	834	911	989

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 36: PNEUMATIC	36-1 (PIA Rev 23a) Jul, 2024
---	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-00-01	AIR SUPPLY AND CABIN PRESSURE CONTROLLERS (ASCPC)			
-00-01-01	PRIMARY (DIGITAL) CONTROLLERS	C	2	1
				(M)(O) Right Primary ASCPC may be inoperative provided: a) Right Primary ASCPC is deactivated, b) Both ASCPC backup (analog) controllers are verified to operate normally, c) Both right CTC channels are verified to operate normally once each flight day, d) Left engine bleed system operates normally, e) Hydraulic center system demand Air Driven Pump C1 operates normally, f) Right engine Idle Selection System is considered inoperative, g) Right isolation system indications are considered inoperative, h) APU bleed air shutoff valve indications are considered inoperative, i) Right Auto Cabin Pressure Control is considered inoperative, and j) Appropriate performance adjustments are applied. (Refer DDG)
-11-01	PRESSURE REGULATING AND SHUTOFF SYSTEMS (PRSOV, PRSOVC)			
-11-01-01	-200ER (WITHOUT PRR 61980 OR EQUIVALENT INCORPORATED)			
				NOT APPLICABLE AS PRR 61980 IS INCORPORATED ON 777 FLEET. (Refer Sub Item -11-01-02)
-11-01-02	-200ER (WITH PRR 61980 OR EQUIVALENT INCORPORATED)	C	2	1
				(M)(O) One valve (PRSOV) and/or the associated controller (PRSOVC) may be inoperative provided: a) Associated PRSOV is locked closed, b) Opposite engine bleed system operates normally, c) Associated engine bleed air switch remains OFF, d) Left and right bleed isolation systems operate normally, e) Center bleed isolation system operates normally,
(Continued...)				

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 36: PNEUMATIC	36-2 (PIA Rev 23) Sep, 2023
---	---	--

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES
-11-01 PRESSURE REGULATING AND SHUTOFF SYSTEMS (PRSOV, PRSOVC) (Continued...) -11-01-03 -300 (WITHOUT SB 777-25-0227 AND ASCPC SW P/N 3670-GRS-012-00 OR LATER INSTALLED) OR (WITHOUT PRR 61980 OR EQUIVALENT INCORPORATED) -11-01-04 -300 (WITH SB 777-25-0227 AND ASCPC SW P/N 3670-GRS-012-00 OR LATER INSTALLED) OR (WITH PRR 61980 OR EQUIVALENT INCORPORATED) -11-01-05 -200LR/-300ER C	2	1	f) Both packs operate normally, g) Both outflow valves operate normally, h) Airplane remains at FL 350 or below, i) APU is used as air source for center system hydraulic demand pumps for takeoff and landing, and j) Appropriate performance adjustments are applied. (Refer DDG) NOT APPLICABLE NOT APPLICABLE (M)(O) One valve (PRSOV) and/or the associated controller (PRSOVC) may be inoperative provided: a) Associated PRSOV is locked closed, b) Opposite engine bleed system operates normally, c) Associated engine bleed air switch remains OFF, d) Left and right bleed isolation systems operate normally, e) Center bleed isolation system operates normally, f) Both packs operate normally, g) Both outflow valves operate normally, (Continued....)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 36: PNEUMATIC	36-3 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-11-01-06	777F			h) APU is used as air source for center system hydraulic demand pumps for takeoff and landing, and i) Appropriate performance adjustments are applied. (Refer DDG) NOT APPLICABLE
-11-01-07	ENG BLEED AIR SWITCH LIGHTS			
-11-01-07-01	OFF LIGHTS	C	2	0
-11-01-07-02	ON LIGHTS	C	2	0
-11-02	HIGH PRESSURE SHUTOFF VALVES (HPSOV)			
-11-02-01	-200ER (WITHOUT PRR 61980 OR EQUIVALENT INCORPORATED)			NOT APPLICABLE AS PRR 61980 IS INCORPORATED ON 777 FLEET. (Refer Sub Item -11-02-02)
-11-02-02	-200ER (WITH PRR 61980 OR EQUIVALENT INCORPORATED)			
-11-02-02A		C	2	1
				(M)(O) One may be inoperative provided: a) Inoperative HPSOV is locked closed, b) Opposite engine bleed system operates normally, c) Both outflow valves operate normally, and d) Associated engine bleed air is cycled OFF, then ON at 55% N1 or greater before takeoff.
-11-02-02B		C	2	1
				(M)(O) One may be inoperative provided: a) Inoperative HPSOV is locked closed, b) Associated PRSOV is locked closed, c) Opposite engine bleed system operates normally, d) Associated engine bleed air switch remains OFF, e) Left & Right bleed isolation systems operate normally, f) Center bleed isolation system operates normally, g) Both packs operate normally, h) Both outflow valves operate normally, (Continued.....)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 36: PNEUMATIC	36-4 (PIA Rev 23) Sep, 2023
---	---	--

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-11-02-03 -300 (WITHOUT SB 777-25-0227 AND ASCPC SW P/N 3670-GRS-012-00 OR LATER INSTALLED) OR (WITHOUT PRR 61980 OR EQUIVALENT INCORPORATED) -11-02-04 -300 (WITH SB 777-25-0227 AND ASCPC SW P/N 3670-GRS-012-00 OR LATER INSTALLED) OR (WITH PRR 61980 OR EQUIVALENT INCORPORATED) -11-02-05 -200LR/-300ER -11-02-05A -11-02-05B				i) APU is used as air source for center system hydraulic demand pumps for takeoff and landing, and j) Appropriate performance adjustments are applied. (Refer DDG) NOT APPLICABLE NOT APPLICABLE
	C	2	1	(M)(O) One may be inoperative provided: a) Inoperative HPSOV is locked closed, b) Opposite engine bleed system operates normally, c) Both outflow valves operate normally, and d) Associated engine bleed air is cycled OFF, then ON at 55% N1 or greater before takeoff.
	C	2	1	(M)(O) One may be inoperative provided: a) Inoperative HPSOV is locked closed, b) Associated PRSOV is locked closed, c) Opposite engine bleed system operates normally, d) Associated engine bleed air switch remains OFF, e) Left & Right bleed isolation systems operate normally, f) Center bleed isolation system operates normally,

(Continued.....)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 36: PNEUMATIC	36-5 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES	
-11-02-06 777F			g) Both packs operate normally, h) Both outflow valves operate normally, i) APU is used as air source for center system hydraulic demand pumps for takeoff and landing, and j) Appropriate performance adjustments are applied. (Refer DDG)
-11-03 INTERMEDIATE PRESSURE CHECK VALVES (IPCV)			NOT APPLICABLE
-11-03-01 -200ER (WITHOUT PRR 61980 OR EQUIVALENT INCORPORATED)			NOT APPLICABLE AS PRR 61980 IS INCORPORATED ON 777 FLEET. (Refer Sub Item -11-03-02)
-11-03-02 -200ER (WITH PRR 61980 OR EQUIVALENT INCORPORATED)	C	2	1 (M)(O) May be inoperative open provided: a) Inoperative IPCV is open, b) Associated HPSOV is locked closed, c) Associated PRSOV is locked closed, d) Opposite engine bleed system operates normally, e) Associated engine bleed air switch remains OFF, f) Left and right bleed isolation systems operate normally, g) Center bleed isolation system operates normally, h) Both packs operate normally, i) Both outflow valves operate normally, j) APU is used as air source for center system hydraulic demand pumps for takeoff and landing, and k) Appropriate performance adjustments are applied. (Refer DDG)
-11-03-03 -300 (WITHOUT SB 777-25-0227 AND ASCPC SW P/N 3670-GRS-012-00 OR LATER INSTALLED) OR (WITHOUT PRR 61980 OR EQUIVALENT INCORPORATED)			NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 36: PNEUMATIC	36-6 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES		
-11-03-04 -300 (WITH SB 777-25-0227 AND ASCPC SW P/N 3670-GRS-012-00 OR LATER INSTALLED) OR (WITH PRR 61980 OR EQUIVALENT INCORPORATED)				NOT APPLICABLE
-11-03-05 -200LR/-300ER	C	2	1	(M)(O) One may be inoperative provided: a) Inoperative IPCV is open, b) Associated HPSOV is locked closed, c) Associated PRSOV is locked closed, d) Opposite engine bleed system operates normally, e) Associated engine bleed air switch remains OFF, f) Left and right bleed isolation systems operate normally, g) Center bleed isolation system operates normally, h) Both packs operate normally, i) Both outflow valves operate normally, j) APU is used as air source for center system hydraulic demand pumps for takeoff and landing, and k) Appropriate performance adjustments are applied. (Refer DDG)
-11-03-06 777F				NOT APPLICABLE
-11-04 PRECOOLERS	C	2	1	(M)(O) Airplane may be operated with damage to one pre-cooler provided: a) It is verified that pre-cooler airflow is not completely blocked, b) Pre-cooler bleed air leakage is verified within normal limits, and c) Opposite engine bleed system operates normally.
-11-05 FAN AIR MODULATION VALVES (FAMV)	C	2	1	(M)(O) One may be inoperative provided: a) Valve is locked full open, b) Opposite engine bleed system operates normally, and c) Appropriate performance adjustments are applied. (Refer DDG)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 36: PNEUMATIC	36-7 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-12-01	LEFT AND RIGHT ISOLATION SYSTEMS (VALVE AND/OR INDICATION)			
-12-01A	C	2	1	(M)(O) One may be inoperative provided: a) Valve is locked closed after engine start, b) Associated valve switch remains in the CLOSED position, c) Center bleed isolation system operates normally, d) Both engine bleed systems operate normally, e) Isolation valve on opposite side is selected CLOSED for takeoff and landing, and selected AUTO with flaps UP, and f) APU is used as air source for center system hydraulic demand pumps for takeoff and landing.
-12-01B	C	2	1	(M)(O) One may be inoperative provided: a) Associated valve is locked open, b) Both center system hydraulic demand pumps operate normally, and c) Appropriate performance adjustments are applied. (Refer DDG)
-12-01-01	ISLN SWITCH LIGHTS			
-12-01-01-01	CLOSED LIGHTS	C	2	0
-12-01-01-02	AUTO LIGHTS	C	2	0
-12-02	CENTER ISOLATION SYSTEM (VALVE AND/OR INDICATION)			
-12-02A	C	1	0	(M)(O) May be inoperative provided: a) Valve is locked closed after engine start, b) Both center system hydraulic demand pumps operate normally, c) Left and right isolation valves operate normally, d) Both engine bleed systems operate normally, and e) Appropriate performance adjustments are applied. (Refer DDG)
-12-02B	C	1	0	(M)(O) May be inoperative provided: a) Valve is locked open, b) Left and right isolation valves are selected CLOSED for takeoff and landing, (Continued....)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 36: PNEUMATIC	36-8 (Rev 23) Sep, 2023
---	---	----------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES	
-12-02-01 ISLN SWITCH LIGHT			c) APU is used as air source for center system hydraulic demand pumps for takeoff and landing, and d) Left or right isolation valve is selected AUTO with flaps up.	
-12-02-01-01 CLOSED LIGHT	C	1		
-12-02-01-02 AUTO LIGHT	C	1		
-12-03 APU BLEED AIR SHUTOFF SYSTEM (VALVE AND/OR INDICATIONS)	C	1	0	(M)(O) May be inoperative provided: a) Other procedures do not require APU as a pneumatic source, b) Valve is locked closed, c) APU bleed switch remains OFF, and d) Flight remains with 180 minutes of landing at a suitable airport.
-12-03-01 VALVE INDICATIONS				NOTE: APU may be used for electrical power.
-12-03-01A	C	1	0	(M)(O) May be inoperative provided: a) Other procedures do not require use of the APU, b) Backup AC power system is verified to operate normally before each departure, c) APU bleed air valve is verified to operate normally, and d) Flight remains within 180 minutes of landing at a suitable airport.
-12-03-01B	C	1	0	(M)(O) May be inoperative provided: a) Other procedures do not require APU as a pneumatic source, b) APU bleed air valve is verified to operate normally before each departure, c) APU bleed switch remains OFF for flight, and d) Flight remains within 180 minutes of landing at a suitable airport. NOTE: APU may be used for electrical power and for pneumatic power for ground operations only.
-12-03-02 APU SWITCH LIGHT				
-12-03-02-01 OFF LIGHT	C	1	0	
-12-03-02-01 ON LIGHT	C	1	0	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 36: PNEUMATIC	36-9 (PIA Rev 23) Sep, 2023
---	---	--

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-20-01	AIR SYNOPTIC DISPLAY	C	1	0	
-21-01	MANIFOLD PRESSURE/FLOW SENSING SYSTEMS	C	2	1	One may be inoperative provided the associated pack flow control valve inlet pressure sensor operates normally.
-21-02	INTERMEDIATE PRESSURE SENSING SYSTEMS	C	2	1	
-22-01	MANIFOLD TEMPERATURE SENSING SYSTEMS				
-22-01-01	-200ER (WITHOUT PRR 61980 OR EQUIVALENT INCORPORATED)				NOT APPLICABLE AS PRR 61980 IS INCORPORATED ON 777 FLEET. (Refer Sub Item -22-01-02)
-22-01-02	-200ER (WITH PRR 61980 OR EQUIVALENT INCORPORATED)				
-22-01-02A		C	2	1	(M)(O) One may be inoperative provided: a) Associated HPSOV is locked closed, b) Opposite engine bleed system operates normally, c) Both outflow valves operate normally, d) Associated engine bleed air switch is cycled OFF, then ON at 55% N1 or greater before takeoff, and e) Appropriate performance adjustments are applied. (Refer DDG)
-22-01-02B		C	2	1	(M)(O) One may be inoperative provided: a) Associated HPSOV is locked closed, b) Associated PRSOV is locked closed, c) Opposite engine bleed system operates normally, d) Associated engine bleed air switch remains OFF, e) Left & Right bleed isolation systems operate normally, f) Center bleed isolation system operates normally, g) Both packs operate normally, h) Both outflow valves operate normally, i) APU is used as air source for center system hydraulic demand pumps for takeoff and landing, and j) Appropriate performance adjustments are applied. (Refer DDG)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 36: PNEUMATIC	36-10 (PIA Rev 23) Sep, 2023
---	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-22-01-03 -300 (WITHOUT SB 777-25-0227 AND ASCPC SW P/N 3670-GRS-012-00 OR LATER INSTALLED) OR (WITHOUT PRR 61980 OR EQUIVALENT INCORPORATED)				NOT APPLICABLE
-22-01-04 -300 (WITH SB 777-25-0227 AND ASCPC SW P/N 3670-GRS-012-00 OR LATER INSTALLED) OR (WITH PRR 61980 OR EQUIVALENT INCORPORATED)				NOT APPLICABLE
-22-01-05 -200LR/-300ER				
-22-01-05A	C	2	1	(M)(O) One may be inoperative provided: a) Associated HPSOV is locked closed, b) Opposite engine bleed system operates normally, c) Both outflow valves operate normally, d) Associated engine bleed air switch is cycled OFF, then ON at 55% N1 or greater before takeoff, and e) Appropriate performance adjustments are applied. (Refer DDG)
-22-01-05B	C	2	1	(M)(O) One may be inoperative provided: a) Associated HPSOV is locked closed, b) Associated PRSOV is locked closed, c) Opposite engine bleed system operates normally, d) Associated engine bleed air switch remains OFF, e) Left & Right bleed isolation systems operate normally, f) Center bleed isolation system operates normally, g) Both packs operate normally, h) Both outflow valves operate normally, i) APU is used as air source for center system hydraulic demand pumps for takeoff and landing, and j) Appropriate performance adjustments are applied. (Refer DDG)
-22-01-06 777F				NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 38: WATER/WASTE	38-1 (PIA Rev 23) Sep , 2023
---	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-10-01	PORTABLE WATER SYSTEMS			
-10-01A	C	1	0	(M) Individual components may be inoperative provided: a) Associated components are deactivated or isolated, and b) Associated system components are verified not to have leaks. NOTE: Any portion of system which operates normally may be used.
-10-01B	C	1	0	(M) May be inoperative provided: a) System is drained, and b) Procedures are established to ensure that system is not serviced.
-10-01-01	POTABLE WATER INDICATION SYSTEM	D	1	0
-30-01	WASTE WATER SYSTEM			
-30-01A	200ER(except BHX) & 300ER=12/ APBMG & BMH=8/ APBHX & BMS=11/ 200LR=10/	C	12/ 08/ 11/ 10	0
				(M) Individual components may be inoperative provided: a) Associated components are deactivated or isolated, and b) Associated system components are verified not to have leaks. NOTE: Any portion of system which operates normally may be used.
-30-01B	200ER(except BHX) & 300ER=12/ APBMG & BMH=8/ APBHX & BMS=11/ 200LR=10/	C	12/ 08/ 11/ 10	0
				(M) Associated lavatory system may be inoperative provided: a) Associated components are deactivated or isolated to prevent leaks, and b) Associated lavatory door is locked closed and placarded, INOPERATIVE- DO NOT ENTER. NOTE: These provisions are not intended to prohibit inspections by crewmembers.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 38: WATER/WASTE	38-2 (PIA Rev 23) Sep , 2023
---	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES
-30-01-01 VACUME BLOWERS	C	2	0
			(M)(O) May be inoperative provided: a) Associated vacuum blower is deactivated, and b) Lavatories affected by inoperative vacuum blower are not used on the ground or at flight altitudes at 16,000 feet MSL or below.
-30-01-02 WASTE TANKS		3	0
			(M) May be inoperative provided: a) Associated waste tank(s) is deactivated, b) Associated components are deactivated or isolated to prevent leaks, and c) Associated lavatory door(s) is secured closed and placarded, "INOPERATIVE - DO NOT ENTER". NOTE: These provisions are not intended to prohibit inspections by crewmembers.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 45: CENTRAL MAINTENANCE SYSTEM	45-1 (PIA Rev 02) AUGUST, 2013
---	--	-----------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-10-01	CENTRAL MAINTENANCE COMPUTING SYSTEM (CMCS)	C	1	0	NOT APPLICABLE
-11-01	MAINTENANCE ACCESS TERMINAL (MAT)	D	1	0	
-13-01	SIDE DISPLAYS				

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 46: INFORMATION SYSTEMS	46-1 (PIA Rev 23) Sep , 2023
--	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-11-01	ONBOARD NETWORK SYSTEM (ONS)			NOT APPLICABLE
-11-02	ELECTRONIC FLIGHT BAG (EFB) SYSTEMS			
-11-02-01	EFB SYSTEM (INSTALLED EFB SYSTEM) (EXCEPT APBMG , BMH & BMS)			
-11-02-01A	C	2	0	(O) May be inoperative provided alternate source of terminal charts required for the intended destination and planned alternate(s) is available to the flight crew. Class 1 EFB must be serviceable. NOTE: Any function, program or document which operates normally may be used.
-11-02-01B	D	2	0	May be inoperative provided procedures do not require its use.
-11-02-02	DATA CONNECTIVITY			NOT APPLICABLE
-11-02-03	POWER SUPPLY / POWER CONNECTION			
-11-02-03A	C	2	0	(O) May be inoperative provided alternate source of terminal charts required for the intended destination and planned alternate(s) is available to the flight crew.
-11-02-03B	D	2	0	May be inoperative provided procedures do not require its use.
-11-02-04	MOUNTING DEVICE			
-11-02-04A	C	2	0	(M)(O) May be inoperative provided: a) Associated EFB and hardware is stowed, secured by an alternate means, or removed from the aircraft, and b) Class 1 EFB must be serviceable.
-11-02-04B	D	2	0	(M) May be inoperative provided: a) Associated EFB and hardware is stowed, secured by an alternate means, or removed from the aircraft, and b) Procedures do not require its use.

STANDARD EQUIPMENT		MINIMUM FOR DISPATCH	
ITEM		SUPPLEMENTAL PROCEDURES	
-11-02-05 CLASS 3 EFB (STC ST00751DE)			NOT APPLICABLE
-11-03 TERMINAL WIRELESS LAN UNIT (TWLU)			NOT APPLICABLE
-11-04 AIRCRAFT WIRELESS LAN UNIT (AWLU)			NOT APPLICABLE

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 47: INERT GAS SYSTEM	47-1 (PIA Rev 10) MAY , 2018
--	--	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-11-01	NITROGEN GENERATION SYSTEM (NGS) (APBMS ONLY)	A	1	0	(M) May be inoperative provided: a) NGS shutoff valve is deactivated closed, and b) Repairs are made within ten flight days
-11-01-01	NITROGEN GENERATION PERFORMANCE	C	1	0	

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 49: AIRBORNE AUXILIARY POWER	49-1 (PIA Rev 23) Sep, 2023
--	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-11-01	AUXILIARY POWER UNIT (APU)	C	1	0	(O) APU may be inoperative provided: a) Other procedures do not require its use, b) Backup AC power system is verified to operate normally before each departure, and c) Flight remains within 180 minutes of landing at a suitable airport.
-15-01	APU AIR INLET DOOR ACTUATION SYSTEM				
-15-01A		C	1	0	(O) May be inoperative with door in any position provided: a) Other procedures do not require the use of the APU, b) APU is not used, and c) Backup AC power system is verified to operate normally before each departure, d) Flight remains within 180 minutes of landing at a suitable airport. e) Appropriate performance adjustments are applied. (Refer DDG)
-15-01B		C	1	0	(M)(O) May be inoperative provided: a) Door is deactivated in the fully open position, and b) Appropriate performance adjustments are applied. (Refer DDG)
-15-01-01	APU AIR INLET DOOR ACTUATOR POSITION INDICATION SWITCH	C	1	0	(M) May be inoperative provided: a) APU inlet door is verified to operate normally before each departure, and b) Both ELMS P310 panel channels operate normally.
-42-01	APU STARTING SYSTEM (INCLUDES ELECTRIC STARTER)				
-42-01A		C	1	0	(O) May be dispatched with APU START SYS faults provided APU is started before departure and operated continuously throughout the flight.
-42-01B		C	1	0	(O) May be dispatched with APU START SYS faults provided: a) Other procedures do not require use of the APU, b) Backup AC power system is verified to operate normally before each departure, and c) Flight remains within 180 minutes of landing at a suitable airport.

PIA 777-240 ER/LR/340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 49: AIRBORNE AUXILIARY POWER	49-2 (PIA Rev 23) Sep, 2023
--	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-43-01	APU AIR TURBINE STARTER	C	1	0	May be inoperative provided electric starter operates normally.
-52-01	APU BLEED AIR SYSTEM	C	1	0	(O) May be inoperative provided: a) Other procedures do not require use of the APU as a pneumatic source, and b) Flight remains within 180 minutes of landing at a suitable airport.
-52-02	APU BLEED AIR CHECK VALVE	C	1	0	NOTE: The APU may be used as an electrical power source. (O) May be inoperative provided: a) APU bleed air switch remains OFF except for main engine start, b) Other procedures do not require use of the APU as a pneumatic source, and c) Flight remains within 180 minutes of landing at a suitable airport.
-61-01	APU CONTROLLER	C	1	0	NOTE: The APU may be used for electrical power. Air Turbine Starter is not available with APU bleed air shutoff valve closed.
-61-02	APU GROUND CONTROL PANEL	C	1	0	May be dispatched with APU CONTROL faults.
-70-01	APU FAULT LIGHT	C	1	0	
-71-01	APU EGT INDICATION	C	1	0	
-73-01	APU RPM INDICATION	C	1	0	
-94-01	APU OIL QTY INDICATION				
-94-01A		C	1	0	(M) May be inoperative provided APU oil quantity is verified adequate once each flight day.
-94-01B		C	1	0	(O) May be inoperative provided: a) Other procedures do not require use of APU, b) Backup AC power system is verified to operate normally before each departure, and c) Flight remains within 180 minutes of landing at a suitable airport.
-94-02	APU OIL PRESS INDICATION	C	1	0	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 52: DOORS	52-1 (PIA Rev 23) Sep, 2023
---	-------------------------------------	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-00-01	DOOR SYNOPTIC DISPLAY	C	1	0	NOT APPLICABLE
-09-01	RIGID CARGO BARRIER (RCB) DOOR SEALS (777F)				
-11-01	MAIN ENTRY DOORS /SLIDES				
-11-01-01	PASSENGER CONFIGURATION	A	8/10	7/9	(M)(O) One door/slide may be inoperative or slide missing provided: a) All other main entry doors are fully operational, b) Affected door is not used for passenger loading, c) A conspicuous barrier strap or rope and a placard stating that the door is inoperative shall be placed across the inoperative door, d) Emergency exit sign and floor proximity lights associated with the inoperative exit must be covered to obscure the sign and lights, e) Passengers must be briefed not to use affected door, f) All passenger seats halfway to the next exit in each direction from the inoperative door, across the entire width of the airplane, shall be blocked off with conspicuous tapes or ropes that contrast with the airplane interior before loading passengers. Only the seats in these areas shall be blocked; main passenger aisles cross aisles and exit areas must not be blocked. (For an inoperative forward door /slide, the blocked seating area shall extend from the forward cabin end, rearward to a line halfway between the inoperative forward door and the next set of doors aft of the inoperative one. For an inoperative rear door/slide, the blocked seating area shall extend forward from the aft cabin end to a line halfway between the inoperative door and the next set of doors forward of the inoperative one), g) Conspicuous signs and placards shall be placed in appropriate locations to indicate seats are not to be occupied by passengers, h) Seated capacity must not exceed rated capacity of remaining pairs of exits,
-11-01-01A	200ER & 200LR= 8/ 300ER = 10				
					(Continued...)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 52: DOORS	52-2 (PIA Rev 23) Sep, 2023
---	-------------------------------------	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM		SUPPLEMENTAL PROCEDURES	
-11-01 MAIN ENTRY DOORS /SLIDES (Continued...)	-		i) For extended over water operations, occupancy shall not exceed the normal rated capacity of the slide/rafts, or the remaining slide/rafts, or the rated overload capacity of the slide/rafts remaining after loss of one additional slide/raft of greatest capacity, whichever is least, j) Refer to Weight and Balance Booklet for blocking of seats, and k) Repairs are made within one flight day. NOTE 1: Weight and Balance Manifest must be revised as necessary to ensure proper loading limits are observed. NOTE 2: Cabin attendants may be stationed in the vicinity of each door within blocked areas. NOTE 3: A door with an inoperative EPAS must be considered inoperative.
			(M)(O) May be inoperative or slides missing provided: a) No passengers are carried, b) A maximum of 19 authorized persons including crewmembers, company employees or PCAA inspectors for non-passenger carrying operations are carried, c) Affected door is not used for passenger loading, d) A conspicuous barrier strap or rope and a placard stating that the door is inoperative shall be placed across the inoperative door, e) Emergency exit sign and floor proximity lights associated with the inoperative exit must be covered to obscure the sign and lights, f) Each passenger carried has unobstructed access from their seat to an operative door, g) Safety briefing location of inoperative doors and instructions not to use them, and h) All authorized persons on board must be briefed prior to each takeoff and landing regarding the inoperative doors that cannot be used for emergency evacuation.
			NOT APPLICABLE
-11-01-01B 200ER & 200LR= 8/ 300ER = 10	C	8/10	1/1
-11-01-02 777F			

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 52: DOORS	52-3 (PIA Rev 02) AUGUST, 2013
---	---	---

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-11-02	MAIN ENTRY DOORS PRESSURE STOP ASSEMBLIES	C	16	8	(M)(O) One forward or aft stop per door (total of 8 stops per -200 airplane or 10 stops per -300 airplane) may be missing or inoperative provided: a) There are no visible defects on remaining stops for the affected door(s), b) Both cabin altitude auto Controllers operate normally, c) For inoperative or missing pressure stops 1, 2, 7 and 8, limit maximum cabin differential pressure to 2.5 psi, and d) For inoperative or missing pressure stops 3, 4, 5 and 6 limit maximum cabin differential pressure to 5.4 psi.
-11-03	MAIN ENTRY DOORS HOLD – OPEN MECHANISMS				
-11-03-01	(-200ER/-200LR)	C	8	4	
-11-03-02	(-300ER)	C	10	6	May be inoperative provided doors 3L and 3R hold-open mechanisms operate normally.
-11-03-03	777F				NOT APPLICABLE
-11-04	MAIN ENTRY DOORS HOLD – OPEN RELEASE HANDLES				
-11-04-01	(-200ER/-200LR)	C	8	4	
-11-04-02	(-300ER)				
-11-04-02-01	DOORS 1L, 1R, 2L, 2R, 4L, 4R, 5L AND 5R	C	8	4	
-11-04-02-02	DOORS 3L AND 3R	C	2	1	One may be inoperative provided supplemental raft is not installed in the associated door bustle.
-11-04-03	777F				NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 52: DOORS	52-4 (PIA Rev 10) MAY , 2018
---	---	---

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-11-05	MAIN ENTRY DOOR FLIGHT LOCK SYSTEMS	C	8	0	(M)(O) May be inoperative provided: a) Each affected door is verified to be capable of being unlatched and opened before each departure, and b) Flight attendant(s) to monitors the affected door handle(s) when cabin differential pressure is less than 1.5 psi.
-11-05-01	PASSENGER				
-11-05-02	777F				NOT APPLICABLE
-32-01	MAIN DECK CARGO DOOR (777F)				NOT APPLICABLE
-32-02	MAIN DECK CARGO DOOR CONTROL PANEL LIGHTS (OPENED, CLOSED, LATCHED, UNLOCKED, LOCKED & ARMED) (777F)				NOT APPLICABLE
-34-01	FORWARD CARGO DOOR HOOK/LATCH SYSTEM (ELECTRIC MODE)	C	1	0	(M) May be inoperative provided: a) Manual mode operates normally, b) There is no damage to the hook/latch mechanism, and c) Door is manually latched and locked using the Maintenance Manual procedure.
-34-02	FORWARD CARGO DOOR LIFT SYSTEM (ELECTRIC MODE)	C	1	0	(M) May be inoperative provided: a) Manual mode operates normally, b) There is no damage to the door lift system, and c) Door is manually closed, latched and locked using the Maintenance Manual procedure.
-34-03	FORWARD CARGO DOOR LATCHED LIGHT	C	1	0	(M) May be inoperative provided the forward cargo door is verified to be closed, latched and locked before each departure.
-35-01	AFT SMALL CARGO DOOR LIFT/LATCH SYSTEM (EXCEPT APBMG, BMH & BMS)	C	1	0	(M) May be inoperative provided the associated door is verified to be closed, latched and locked before each departure.
-35-01-01	ELECTRIC MODE	C	1	0	May be inoperative provided manual mode operates normally.
-35-02	AFT SMALL CARGO DOOR HINGE SYSTEM (ELECTRIC MODE) (EXCEPT APBMG, BMH & BMS)	C	1	0	(M) May be inoperative provided: a) Manual mode operates normally, b) There is no damage to the hinge system, and c) Door is manually operated using the Maintenance Manual procedure.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 52: DOORS	52-5 (PIA Rev 10) MAY , 2018
---	---	---

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-35-03	AFT SMALL CARGO DOOR LATCHED LIGHT (EXCEPT APBMG, BMH & BMS)	C	1	0	(M) May be inoperative provided: a) Aft small cargo door indication system operates normally, and b) Aft small cargo door is verified to be closed and latched before each departure.
-35-04	AFT SMALL CARGO DOOR ARMING RELAY/CONTROL SWITCH (EXCEPT APBMG, BMH & BMS)	C	1	0	(M) May be inoperative provided: a) Associated arming control circuit is deactivated, and c) Aft small cargo door is verified to be closed and latched before each departure.
-36-01	BULK CARGO DOOR COUNTER BALANCE MECHANISM	C	1	0	(M) May be inoperative provided a safety hold open device is used when the door is in the open position.
-37-01	AFT LARGE CARGO DOOR HOOK/LATCH SYSTEM (ELECTRIC MODE) (AP-BMG, BMH & BMS)	C	1	0	(M) May be inoperative provided: a) Manual mode operates normally, b) There is no damage to the hook/latch mechanism, and c) Door is manually latched and locked using the maintenance manual procedure.
-37-02	AFT LARGE CARGO DOOR LIFT SYSTEM (ELECTRIC MODE) (AP-BMG, BMH & BMS)	C	1	0	(M) May be inoperative provided: a) Manual mode operates normally, b) There is no damage to the door lift system, and c) Door is manually closed, latched and locked using the maintenance manual procedure.
-37-03	AFT LARGE CARGO DOOR LATCHED LIGHT (AP-BMG, BMH & BMS)	C	1	0	(M) May be inoperative provided the aft large cargo door is verified to be closed, latched and locked before each departure.
-51-01	FLIGHT DECK DOOR LOCK AUTOMATIC SYSTEM (NOT FAR 25.795 COMPLAINT)				NOT APPLICABLE
-51-02	BOEING ENHANCED FLIGHT DECK SECURITY DOOR AUTOMATIC LOCKING SYSTEM (FAR 25.795 COMPLAINT) (PASSENGER)	A	1	0	(M)(O) May be inoperative provided: a) Automatic locking system is deactivated, b) Door dead bolt operates normally and is used to lock the door, c) Dead bolt is used for locking and unlocking the door, and d) Repairs are made within two flight days.
-51-02-01	FLIGHT DECK ACCESS SYSTEM (KEYPAD, DOOR CHIME)	B	1	0	(M)(O) May be inoperative provided: a) Keypad is deactivated, and b) Flight Deck interphone system is used for access. (Continued...)

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 52: DOORS	52-6 (PIA Rev 06) APR , 2016
---	---	---

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-51-02	BOEING ENHANCED FLIGHT DECK SECURITY DOOR AUTOMATIC LOCKING SYSTEM (FAR 25.795 COMPLAINT) (PASSENGER)(Continued.)				
-51-02-01-01	LEDS	C	3	0	(O) May be inoperative provided Flight deck interphone is used for access.
-51-02-01-02	DOOR BELL MODE	C	1	0	(O) May be inoperative provided Flight deck interphone is used for access.
-51-02-01-03	SWITCH GUARD	C	1	0	May be inoperative or missing provided the flight deck door LOCK FAIL light operates normally.
-51-02-02	FLIGHT DECK DOOR LOCK FAIL LIGHT	B	1	0	(M) May be inoperative provided automatic lock controls are verified to operate normally.
-51-02-03	FLIGHT DECK DOOR AUTO UNLK LIGHT	B	1	0	(M) May be inoperative provided: a) Automatic lock controls are verified to operate normally, and b) Door chime operates normally.
-51-02-04	FLIGHT DECK DOOR LOCK CONTROL SELECTOR	B	1	0	(M)(O) May be inoperative provided: a) Keypad is deactivated, b) Automatic lock is verified to operate normally, and c) Dead bolt is used for locking and unlocking the door.
-51-02-05	PRESSURE RATE-OF-CHANGE SENSING MODULE	A	1	0	(M) May be inoperative provided: a) Pressure sensing module is deactivated, and b) Repairs are made within two flight days.
-51-03	BOEING ENHANCED FLIGHT DECK SECURITY DOOR DEAD BOLT (FAR 25.795 COMPLAINT) (PASSENGER)	C	1	0	May be inoperative provided automatic lock controls operate normally.
-51-04	JAMCO FLIGHT DECK SECURITY DOOR AUTOMATIC LOCKING SYSTEM				NOT APPLICABLE
-51-05	JAMCO FLIGHT DECK SECURITY DOOR MECHANICAL CATCH LATCH PIN LOCK				NOT APPLICABLE

STANDARD EQUIPMENT
MINIMUM FOR DISPATCH

ITEM			SUPPLEMENTAL PROCEDURES		
-51-06	FLIGHT DECK DOOR VIEWING PORT (PASSENGER)				
-51-06-01	WITHOUT ELECTRONIC VISUAL SURVEILLANCE SYSTEM				NOT APPLICABLE
-51-06-02	WITH ELECTRONIC VISUAL SURVEILLANCE SYSTEM				
-51-06-02A	A	1	0		(O) May be inoperative provided: a) Communication between Flight Deck and Cabin is established through interphone, and b) Repairs are made within three flight days.
-51-06-02B	C	1	0		(O) May be inoperative provided: a) A flight deck door visual surveillance system is installed and operates normally, and b) Communication between Flight Deck and Cabin is established through interphone.
-71-01	DOOR INDICATION SYSTEMS	C	13/15	0/0	(M) May be inoperative provided associated door is verified closed, latched and locked before each departure.
	(-200ER/LR = 13 INDICATIONS)				
	(-300ER = 15 INDICATIONS)				
-71-02	MAIN ENTRY DOOR STATUS ANNUNCIATION AND ALERTING SYSTEMS (FLIGHT ATTENDANT)				
	(-200ER/LR = 8 DOORS) (-300ER = 10 DOORS)				
-71-02A	C	8/10	0		(O) May be inoperative provided door is physically checked for status.
-71-02B	D	8/10	0		May be inoperative provided procedures do not require their use.

MINIMUM FOR DISPATCH

ITEM			↓	↓	SUPPLEMENTAL PROCEDURES
-11-01	FLIGHT DECK WINDOW INDICATION SYSTEMS (SIDE - NO.2)	C	2	0	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 73: ENGINE FUEL & CONTROL	73-1 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES
-21-01	ENGINE IDLE SELECTION SYSTEMS	C	2	0	(O) May be inoperative provided appropriate performance adjustments are applied. (Refer DDG)
-21-02	ELECTRONIC ENGINE CONTROLS (EEC) NORMAL MODE				
-21-02-01	PW				NOT APPLICABLE
-21-02-02	GE				
-21-02-02-01	ALL (EXCEPT GE90-100 SERIES) (-200ER)	B	2	0	(O) Normal (NORM) mode may be inoperative provided: a) Auto throttle system operates normally, b) LPT Turbine Case Cooling Air Flow Systems on both engines operate normally, c) Both engines are operated in the alternate (ALTN) mode, and d) Engine anti-ice valve may be inoperative open.
-21-02-02-02	GE90-100 SERIES (-200LR / -300ER)	B	2	0	(O) Normal (NORM) mode may be inoperative provided: a) Autothrottle system operates normally, b) LPT Turbine Case Cooling Air Flow Systems on both engines operate normally, c) Both engines are operated in the alternate (ALTN) mode, and d) Appropriate performance adjustments are applied. (Refer DDG)
-21-02-03	RR				NOT APPLICABLE
-21-03	ELECTRONIC ENGINE CONTROLS (EEC) MODE SWITCH LIGHTS				
-21-03-01	ALTN LIGHTS	C	2	0	
-21-03-02	NORM LIGHTS	C	2	0	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 73: ENGINE FUEL & CONTROL	73-2 (PIA Rev 23a) Jul, 2024
---	---	---------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM					SUPPLEMENTAL PROCEDURES													
-21-04	EEC C1 FAULTS																	
-21-04-01	GE90-100 SERIES WITHOUT P/N 730A- GEC-A08-06 OR LATER EEC SOFTWARE INSTALLED	A	2	0	(M) May be dispatched with C1 faults provided: a) Prior to each flight EEC faults are reviewed to determine if EEC must be replaced, and b) Repairs are made in accordance with NOTE 2. However dispatch of airplane is prohibited if the engine indicating and crew alerting system (EICAS) displays the status message "ENG EEC C1 L" or "ENG EEC C1 R" AND any of below mentioned condition present: i. If there are 12 faults recorded in either FADEC channel for the Flight Leg that corresponds with the ENG EEC C1 L or ENG EEC C1 R status message, OR ii. If there are no maintenance messages correlated with the ENG EEC C1 L or ENG EEC C1 R status message, OR iii. FMV/TLA Fault combination present.	<table><tr><th>Condition</th><th>Maintenance Message Combination</th><th>Comments</th></tr><tr><td>FMV Disagree Fault</td><td>(73-1439P or 73-2439P) and (76-3520P or 76-1521P or 76-2521P)</td><td>FMV disagree fault on one of the two channels and any TLA range or disagree on one of the two channels</td></tr><tr><td>TLA Disagree Fault</td><td>76-3520P and (73-1325P or 73-2325P or 73-1439P or 73-2439P)</td><td>TLA disagree fault on one of the two channels and any FMV range or disagree fault on one of the two channels</td></tr><tr><td>Range Faults</td><td>(76-1521P and 73-1325P) or (76-2521P and 73-2325P)</td><td>FMV and TLA range faults on the same channel</td></tr></table> NOTE: P=1 or 2, where 1=Left Engine and 2=Right Engine NOTE 1: If airplane is dispatched under MEL with EEC C1 FAULTS, above restriction must be checked prior to each flight. NOTE 2: Maximum operating time is 150 hrs/10 calendar days, whichever occurs first.	Condition	Maintenance Message Combination	Comments	FMV Disagree Fault	(73-1439P or 73-2439P) and (76-3520P or 76-1521P or 76-2521P)	FMV disagree fault on one of the two channels and any TLA range or disagree on one of the two channels	TLA Disagree Fault	76-3520P and (73-1325P or 73-2325P or 73-1439P or 73-2439P)	TLA disagree fault on one of the two channels and any FMV range or disagree fault on one of the two channels	Range Faults	(76-1521P and 73-1325P) or (76-2521P and 73-2325P)	FMV and TLA range faults on the same channel
Condition	Maintenance Message Combination	Comments																
FMV Disagree Fault	(73-1439P or 73-2439P) and (76-3520P or 76-1521P or 76-2521P)	FMV disagree fault on one of the two channels and any TLA range or disagree on one of the two channels																
TLA Disagree Fault	76-3520P and (73-1325P or 73-2325P or 73-1439P or 73-2439P)	TLA disagree fault on one of the two channels and any FMV range or disagree fault on one of the two channels																
Range Faults	(76-1521P and 73-1325P) or (76-2521P and 73-2325P)	FMV and TLA range faults on the same channel																
-21-04-02	GE90-90 SERIES, AND GE90-100 SERIES WITH P/N 730A-GEC-A08-06 OR LATER EEC SOFTWARE INSTALLED	A	2	0	May be dispatched with C1 faults provided repairs are made in accordance with NOTE below. NOTE: Maximum operating time is 150 hrs / 10 calendar days, whichever occurs first.													
-21-05	TURBINE OVERSPEED SYSTEMS (RR)				NOT APPLICABLE													
-21-06	ENGINE FUEL SHUTOFF VALVE INDICATION SYSTEMS	C	2	1	(M) One may be inoperative provided the associated valve is verified to operate normally each flight day.													
-21-07	ENGINE THRUST CONTROL MALFUNCTION ACCOMMODATION (TCMA) FUNCTIONS (-200LR/-300ER)	C	2	1														

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 73: ENGINE FUEL & CONTROL	73-3 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES
-21-08	Engine Fuel High Pressure Shut Off Valve (HPSOV) Run Solenoid (GE)			
-21-08-01	PASSENGER	B	2	1
				(M)(O) One may be inoperative provided: a) Associated HPSOV solenoid is deactivated in the open position, b) Associated fuel spar valve is verified to operate normally before each departure, c) Associated Hydro-Mechanical Unit Fuel Metering Valve shutdown function is verified to operate normally before each departure, d) Autostart system operates normally, e) EEC C1/C2 faults are not present on the associated engine, f) Airplane is not operated in areas of known or forecast volcanic ash contamination, g) A flight attendant is seated at each exit aft of the wing during taxi, takeoff, and landing, and h) Flight attendants are appropriately briefed before each departure.
	-21-08-01 777F			NOT APPLICABLE
-31-01	FUEL FLOW INDICATIONS	C	2	1
				One may be inoperative provided: a) Flight deck fuel tank quantity indicating systems operate normally, and b) Flight remains within 180 minutes of landing at a suitable airport.
-34-01	ENGINE FUEL FILTER BYPASS WARNING SYSTEMS			
-34-01-01	PW & RR			NOT APPLICABLE
-34-01-02	GE	C	2	1
				(M) One may be inoperative provided fuel is drained from filter plug and checked for contaminants before each departure.

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES		
-00-01 IGNITION SYSTEMS			
-00-01A	B 4	3	One may be inoperative provided associated engine anti-ice system operates normally.
-00-01B	B 4	3	One may be inoperative provided associated engine anti-ice system is inoperative with valve deactivated open.

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 75: BLEED AIR	75-1 (PIA Rev 23) Sep, 2023
---	---	--------------------------------

STANDARD EQUIPMENT	MINIMUM FOR DISPATCH
ITEM	SUPPLEMENTAL PROCEDURES

-23-01	NACELLE ZONE VENTILATION VALVES (PW)				NOT APPLICABLE
-23-02	CORE COMPARTMENT COOLING VALVES (GE)	C	2	0	(M) May be inoperative provided the inoperative valve(s) is locked open.
-24-01	TURBINE CASE COOLING AIR FLOW SYSTEMS (PW & GE)				
-24-01-01	PW				NOT APPLICABLE
-24-01-02	GE				
-24-01-02-01	LPT SYSTEMS	C	2	0	(M) (O) May be inoperative provided: a) Associated LPT ACC valve is locked in the closed position, and b) Both EECs operate in the normal mode.
-24-02	TURBINE COOLING AIR SYSTEMS (PW)				NOT APPLICABLE.

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM	SUPPLEMENTAL PROCEDURES		
-11-01 ENGINE PRESSURE RATIO INDICATING SYSTEMS (PW AND RR)			NOT APPLICABLE
-12-01 N2 TACHOMETER SYSTEMS (RR)			NOT APPLICABLE
-21-01 PYROMETER EXHAUST GAS TEMPERATURE (EGT) INDICATION SYSTEM (GE EXCEPT GE90-100 SERIES (-200ER))	C 2	0	(M) May be inoperative provided: a) Inoperative EGT pyrometer indication system is deactivated, and b) Associated engine EGT indications are verified to be normal.
-22-01 ENGINE TURBINE OVERHEAT SENSORS (RR)			NOT APPLICABLE
-31-01 ENGINE VIBRATION MONITOR SYSTEMS	C 2	1	

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 78: ENGINE EXHAUST	78-1 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-31-01	THRUST REVERSERS				
-31-01-01	-200ER	C	2	1	(M) One may be inoperative provided: a) Both sync locks are verified in the locked position, b) One locking actuator on each sleeve is verified in the locked position, and c) Inoperative reverser is secured in the forward thrust position. NOTE 1: Both Thrust Reversers must be operative for operation to/from a slippery or runway contaminated with standing water, slush/snow. NOTE 2: In case of hydraulic leak from the thrust reverser Return tubing, this MEL procedure should not be followed.
-31-01-02	-200LR/-300ER	C	2	1	(M)(O) One may be inoperative provided: a) Both sync locks are verified in the locked position, b) One locking actuator on each sleeve is verified in the locked position, c) Inoperative reverser is secured in the forward thrust position, and d) Appropriate performance adjustments are applied. (Refer FPPM) NOTE 1: Both Thrust Reversers must be operative for operation to/from a slippery or runway contaminated with standing water, slush/snow. NOTE 2: In case of hydraulic leak from the thrust reverser Return tubing, this MEL procedure should not be followed.
-34-01	REVERSER THRUST LEVER INTERLOCKS				
-34-01A		C	2	1	One may be inoperative provided the interlock is released.
-34-01B		C	2	1	(O) One may be inoperative provided: a) Inoperative interlock is retracted, and b) Appropriate performance adjustments are applied. (Refer DDG)
-36-01	REVERSER PROXIMITY SENSORS	C	14	12	One per engine may be inoperative.

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-21-01	ENGINE AIR/OIL HEAT EXCHANGER VALVES (RR)				NOT APPLICABLE
-21-02	ENGINE FUEL/OIL COOLER BYPASS VALVES (PW)				NOT APPLICABLE
-31-01	ENGINE OIL QUANTITY INDICATING SYSTEMS	A	2	1	(M) One may be inoperative provided: a) It is verified before each departure that the oil tank is filled to the recommended capacity, b) Oil consumption is within limits, and c) Repairs are made within three flight days.
-35-01	ENGINE OIL FILTER BYPASS WARNING SYSTEMS				
-35-01-01	PW				NOT APPLICABLE
-35-01-02	GE	C	2	1	
-35-01-03	RR				NOT APPLICABLE

PIA 777-240 ER/LR/-340ER OPERATIONS MANUAL	MINIMUM EQUIPMENT LIST 80: STARTING	80-1 (PIA Rev 23) Sep, 2023
---	--	--------------------------------

STANDARD EQUIPMENT

MINIMUM FOR DISPATCH

ITEM				SUPPLEMENTAL PROCEDURES	
-11-01	ENGINE START VALVES	C	2	1	(M)(O) One may be inoperative provided: a) Inoperative valve is closed, and b) Starting procedure may be used as DDG .
-11-02	AUTOSTART SYSTEM	C	1	0	(O) May be inoperative provided manual start procedures are established and used.
-11-02-01	AUTOSTART SWITCH POSITION INDICATION	C	1	0	May be inoperative provided engine autostart switch is selected ON.
-11-02-02	AUTOSTART SWITCH LIGHTS				
-11-02-02-01	OFF LIGHT	C	1	0	
-11-02-02-02	ON LIGHT	C	1	0	
-11-03	START SELECTOR HOLDING/CUTOUT SYSTEMS	C	2	0	(O) May be inoperative provided alternate start procedures are used. (Refer DDG)