



Sandia
National
Laboratories

Exceptional service in the national interest

ME469: Review: Discretization, low-Mach, splitting/stabilization, advection stabilization

Stefan P. Domino^{1,2}


¹ Computational Thermal and Fluid Mechanics, Sandia National Laboratories

² Institute for Computational and Mathematical Engineering, Stanford

This presentation has been authored by an employee of National Technology & Engineering Solutions of Sandia, LLC under Contract No. DE-NA0003525 with the U.S. Department of Energy (DOE). The employee owns all right, title and interest in and to the presentation and is solely responsible for its contents. The United States Government retains and the publisher, by accepting the article for publication, acknowledges that the United States Government retains a non-exclusive, paid-up, irrevocable, world-wide license to publish or reproduce the published form of this article or allow others to do so, for United States Government purposes. The DOE will provide public access to these results of federally sponsored research in accordance with the DOE Public Access Plan (<http://www.energy.gov/ea/doe-public-access-plan>).

SAND2018-4536 PE





Fundamentals of Discretization: Surface vs Volume Integrations

- Given a partial differential equation (PDE) and associated volumetric form:

$$\int \frac{\partial F_j}{\partial x_j} dV = \int S dV$$

- Applying Gauss Divergence provides the standard finite volume form for fluxes in surface integral form (no distinction between internal control volume faces and boundary faces):

$$\sum_k \int_{\Omega_k} \frac{\partial F_j}{\partial x_j} d\Omega_k = \sum_k \int_{\Omega_k} S d\Omega_k \longrightarrow \sum_k \int_{\Gamma_k} F_j n_j d\Gamma_k = \sum_k \int_{\Omega_k} S d\Omega \longrightarrow \int F_j n_j dS = \int S dV$$

- We can also multiply PDE by an arbitrary test function, w , and integrate over a volume,

$$\int w \frac{\partial F_j}{\partial x_j} dV = \int w S dV$$

$$-\int F_j \frac{\partial w}{\partial x_j} dV + \int \frac{\partial w F_j}{\partial x_j} dV = -\int F_j \frac{\partial w}{\partial x_j} dV + \int w F_j n_j dS$$

↑ ↑
Interior Boundary


Next, integrate by parts and apply Gauss-Divergence. Note, that test function must be differentiable – shown here, at least once..

$$\frac{\partial w F_j}{\partial x_j} = w \frac{\partial F_j}{\partial x_j} + \frac{\partial w}{\partial x_j} F_j$$




Discretization Approaches: Two-state (Left) and Element-based (right)

- Cell-centered




$$N_1 = N_2 = \frac{1}{2}$$

- Edge-based vertex-centered



$$\phi_{ip} = \sum_n N_n^{ip} \phi_n$$

- Control-volume finite element




$$N_1 = \frac{1}{4}(1 - \xi)(1 - \eta)$$

$$N_2 = \frac{1}{4}(1 + \xi)(1 - \eta)$$

$$N_3 = \frac{1}{4}(1 + \xi)(1 + \eta)$$

$$N_4 = \frac{1}{4}(1 - \xi)(1 + \eta)$$






Final low-Mach Equation Set

The resulting Equation set is as follows:

$$\begin{aligned} \frac{\partial \rho}{\partial t} + \frac{\partial \rho u_j}{\partial x_j} &= 0, \\ \frac{\partial \rho u_i}{\partial t} + \frac{\partial \rho u_j u_i}{\partial x_j} + \frac{\partial p^m}{\partial x_i} &= \frac{\partial \tau_{ij}}{\partial x_j} + (\rho - \rho_\circ) g_i, \\ \frac{\partial \rho h}{\partial t} + \frac{\partial \rho u_j h}{\partial x_j} &= -\frac{\partial q_j}{\partial x_j} + \frac{\partial P_{th}}{\partial t} \end{aligned} \quad \left. \right\} \text{2+nDim}$$


- Equation of state given by the thermodynamic pressure: $\rho = \frac{P_{th} M}{R T}$
- Energy transport is only required when the system modeled has a temperature difference

EOS does not provide an equation for closure: An alternative approach is required for motion pressure!



Thought Experiment... Solver Ramifications

- For Elliptic systems, fixed point iterative solvers fail since the sequential propagation of information is not adequate for a system with infinite wave speeds





Multigrid Methods: The Approach

- Multigrid methods (MG) are essential for efficient solver performance in fluids-based Elliptic systems
- In simple, structured domains, this can be geometric (GMG), while in unstructured, algebraic (AMG)

$$A\phi = f$$


$$\epsilon = \phi - \tilde{\phi}$$

$$r = f - A\tilde{\phi}$$



$$A(\tilde{\phi} + \epsilon) = f$$

$$A\epsilon = r$$

$$\phi = \tilde{\phi} + \epsilon$$



Multigrid Methods: V- and W-Cycles



https://en.wikipedia.org/wiki/Multigrid_method

Figure 3.6: Schedule of grids for (a) V-cycle, (b) W-cycle, and (c) FMG scheme, all on four levels.



Pressure Projection and Block Factorization

- Semi-discrete approach (uniform density)

$$\begin{aligned} \rho \frac{\hat{u}_i - u_i^n}{\Delta t} + \frac{\partial}{\partial x_j} (\rho \hat{u}_i u_j^n) &= - \frac{\partial p^n}{\partial x_i} + \frac{\partial \hat{\tau}_{ij}}{\partial x_j} \\ \rho \frac{u_i^{n+1} - \hat{u}_i}{\Delta t} &= - \frac{\partial}{\partial x_i} (p^{n+1} - p^n) \\ \frac{\partial^2}{\partial x_i^2} (p^{n+1} - p^n) &= \frac{\rho}{\Delta t} \frac{\partial \hat{u}_i}{\partial x_i} \end{aligned}$$

- Chorin (1968)
- Time scale is the time step:

$$u_i^{n+1} = \hat{u}_i - \Delta t \left(\frac{1}{\rho} \frac{\partial}{\partial x_i} (p^{n+1} - p^n) \right)$$

- Fully discrete approach

$$\begin{bmatrix} \mathbf{A} & \mathbf{G} \\ \mathbf{D} & \mathbf{0} \end{bmatrix} \begin{Bmatrix} \mathbf{U}^{n+1} \\ \mathbf{P}^{n+1} \end{Bmatrix} = \begin{Bmatrix} \mathbf{f} \\ \mathbf{0} \end{Bmatrix}$$

- Factored matrix:

$$\begin{bmatrix} \mathbf{A} & \mathbf{G} \\ \mathbf{D} & \mathbf{0} \end{bmatrix} \approx \begin{bmatrix} \mathbf{A} & \mathbf{0} \\ \mathbf{D} & -\mathbf{D}\bar{\mathbf{A}}^{-1}\mathbf{G} \end{bmatrix} \begin{bmatrix} \mathbf{I} & \bar{\mathbf{A}}^{-1}\mathbf{G} \\ \mathbf{0} & \mathbf{I} \end{bmatrix}$$

$\bar{\mathbf{A}}^{-1}$ is an approximation to \mathbf{A}^{-1}

- SIMPLE family of methods
- Time scale is the characteristic scale of $\bar{\mathbf{A}}^{-1}$:

$$\mathbf{U}^{n+1} = \hat{\mathbf{U}} - \bar{\mathbf{A}}^{-1} \mathbf{G} \mathbf{P}^{n+1}$$

- For convection-dominated flows, this looks like $\Delta x / U$

$$\begin{bmatrix} \mathbf{A} & \mathbf{G} \\ \mathbf{D} & \mathbf{0} \end{bmatrix} \begin{bmatrix} \mathbf{u}^{n+1} \\ \mathbf{p}^{n+1} \end{bmatrix} = \begin{bmatrix} \mathbf{f} \\ \mathbf{0} \end{bmatrix} + \begin{bmatrix} (\mathbf{I} - \mathbf{A}\tau)\mathbf{G}(p^{n+1} - p^n) \\ \tau(\mathbf{L} - \mathbf{D}\mathbf{G})(p^{n+1} - p^n) \end{bmatrix}$$



Monotonic Issues at High Pe: Simple Matrix Analysis

Consider our passive scalar concentration whose natural range (as a mass fraction) is bounded between zero and unity, here, shown as a stationary transport equation:

$$\frac{\partial \rho u_j \phi}{\partial x_j} - \frac{\partial}{\partial x_j} \left(\rho D \frac{\partial \phi}{\partial x_j} \right) = 0$$

Using our CDS and standard diffusion operator yields the following matrix system:

$$\left(\frac{\rho u}{2} [-1 \quad 0 \quad 1] + \frac{\rho D}{\Delta x} [-1 \quad 2 \quad -1] \right) \begin{bmatrix} \phi_{i-1} \\ \phi_i \\ \phi_{i+1} \end{bmatrix}. \quad a_{i,i-1} = \frac{\rho D}{\Delta x} \left(1 + \frac{Pe}{2} \right)$$

With coefficients, $a_{i,i}\phi_i = a_{i,i-1}\phi_{i-1} + a_{i,i+1}\phi_{i+1}$ and: $a_{i,i} = (a_{i,i-1} + a_{i,i+1})$

Substituting: $a_{i,i-1} = a_{i,i} - a_{i,i+1}$ and defining: $\xi = \frac{a_{i,i+1}}{a_{i,i}}$ $a_{i,i+1} = \frac{\rho D}{\Delta x} \left(1 - \frac{Pe}{2} \right)$

Yields: $\phi_i = \xi\phi_{i+1} + (1 - \xi)\phi_{i-1}$ Positive for $Pe < 2$

For $Pe < 2$, the value of the scalar at node i is a linear combination of the neighboring values

Monotonic Issues at high Pe: Alternative View (Diagonal Dominance)


Define Diagonal Dominance as:

$$\frac{\sum_{i \neq j} |a_{i,j}|}{|a_{i,i}|} \leq 1$$

For a monotonic operator and ease of solving the linear system, diagonal dominance is desired

In our advection/diffusion case, this is expressed as:

$$\frac{|\frac{\rho D}{\Delta x} (1 - \frac{Pe}{2})| + |\frac{\rho D}{\Delta x} (1 + \frac{Pe}{2})|}{\frac{2\rho D}{\Delta x}} \leq 1$$



Which, again, is only ensured when the Peclet number is less than two

Monotonic Issues Resolved When Using First-order Upwind

$$\frac{\partial \rho u_j \phi}{\partial x_j} - \frac{\partial}{\partial x_j} \left(\rho D \frac{\partial \phi}{\partial x_j} \right) = 0$$



$$a_{i,i-1} = \frac{\rho D}{\Delta x} (1 + Pe)$$

Positive for all Pe


$$a_{i,i} = (a_{i,i-1} + a_{i,i+1})$$

$$a_{i,i+1} = \frac{\rho D}{\Delta x}$$

$$\left(\frac{\rho u}{2} \begin{bmatrix} -1 & 1 & 0 \end{bmatrix} + \frac{\rho D}{\Delta x} \begin{bmatrix} -1 & 2 & -1 \end{bmatrix} \right) \begin{bmatrix} \phi_{i-1} \\ \phi_i \\ \phi_{i+1} \end{bmatrix}$$


$$\phi_i = \xi \phi_{i+1} + (1 - \xi) \phi_{i-1} \quad \xi = \frac{a_{i,i+1}}{a_{i,i}}$$

However, at what price?



Fully bounded with diagonal dominance

$$\frac{\sum_{i \neq j} |a_{i,j}|}{|a_{i,i}|} \leq 1$$



Volume-of-fluid example (Domino and Horne, Renew. Ener. 2022)



General Kappa-Method of Hirsh



Numerical Computation of Internal and External Flows, vol. 2, John Wiley & Sons, 1990

For the edge defined by the i and $i+1$ node, define a Left and Right state:

$$\tilde{\phi}_{i+\frac{1}{2}}^L = \phi_i + \frac{1}{4} [(1 - \kappa) (\phi_i - \phi_{i-1}) + (1 + \kappa) (\phi_{i+1} - \phi_i)],$$

$$\tilde{\phi}_{i+\frac{1}{2}}^R = \phi_{i+1} - \frac{1}{4} [(1 + \kappa) (\phi_{i+1} - \phi_i) + (1 - \kappa) (\phi_{i+2} - \phi_{i+1})].$$

- For $\kappa = +1$, we simply revert to CDS
- For $\kappa = -1$, Second-order upwind
- For $\kappa = 2/3$, QUICK (Leonard, "A stable and accurate convective modelling procedure based on quadratic upstream interpolation", Comput. Methods Appl. Mech. Eng. 19 (1979) 59–98.)




Quadratic basis (three-points required)



Classic Flux Limiters

Van Leer, B. (1974), "Towards the ultimate conservative difference scheme II. Monotonicity and conservation combined in a second order scheme", J. Comput. Phys., 14 (4): 361–370

- Consider our standard three-point stencil obtained by iterating edge 1 and 2



- In the above stencil, we are stressing that when iterating edge 2, we do not have information easily obtain for edge 1 (shown above as a dashed line); (speaking from an unstructured perspective)

$$\phi_{i+\frac{1}{2}} = \phi_{i+\frac{1}{2}}^{LOW} - \Phi(r_{i+\frac{1}{2}}) (\phi_{i+\frac{1}{2}}^{LOW} - \phi_{i+\frac{1}{2}}^{HIGH}) \quad \text{Monotonic upstream-centered scheme for conservation laws (MUSCL)}$$

- Above, the "LOW" and "HIGH" are any operators that you select, e.g.,

$$\phi_{i+\frac{1}{2}}^{LOW} = \phi_i \quad \phi_{i+\frac{1}{2}}^{HIGH} = \frac{\phi_i + \phi_{i+1}}{2} \rightarrow \phi_{i+\frac{1}{2}} = \phi_i + \frac{1}{2} \Phi(r_{i+\frac{1}{2}}) (\phi_{i+1} - \phi_i)$$

$$r_{i+\frac{1}{2}} = \frac{(\phi_i - \phi_{i-1})}{(\phi_{i+1} - \phi_i)} \quad (\phi_i - \phi_{i-1}) = 2G_x\phi_i\Delta x - (\phi_{i+1} - \phi_i) \quad G_x\phi_i = \frac{\phi_{i+1} - \phi_{i-1}}{2\Delta x}$$



Blending Approaches to Arrive at Pseudo Higher-order Methods: Upwind and Central

Define an upwind operator now at an arbitrary integration point:

$$\begin{aligned}\phi_{ip}^{UPW} &= \alpha_{upw} \tilde{\phi}_{ip}^L + (1 - \alpha_{upw}) \phi_{ip}^{CDS}; \dot{m} > 0, \\ &\alpha_{upw} \tilde{\phi}_{ip}^R + (1 - \alpha_{upw}) \phi_{ip}^{CDS}; \dot{m} < 0.\end{aligned}$$

And for a generalized CDS scheme:

$$\begin{aligned}\phi_{ip}^{GCDS} &= \frac{1}{2} \left(\hat{\phi}_{ip}^L + \hat{\phi}_{ip}^R \right), & \hat{\phi}_{ip}^L &= \alpha \tilde{\phi}_{ip}^L + (1 - \alpha) \phi_{ip}^{CDS}, \\ && \hat{\phi}_{ip}^R &= \alpha \tilde{\phi}_{ip}^R + (1 - \alpha) \phi_{ip}^{CDS}\end{aligned}$$

- Two new blending parameters: α_{upw} and α

