



GENERAL



SPECIAL TOOLS

Tool (Number and name)	Use	Tool (Number and name)	Use
MB990750 Brake booster holder	 Disassembly and reassembly of the brake booster	MB990964 Brake tool set	 Pushing-in of the front disc brake piston
MB990749 Lever attachment	 Installation of rear wheel cylinder piston cup	MB990520 Piston expander	