CSE 31 Computer Organization

Lecture 17 – Floating Point Numbers (1)

Announcement

- Lab #8 this week
 - Due in one week
- HW #5 (from zyBooks)
 - Due Monday (11/5)
- Project #2 out this Friday
 - Due Monday (12/3)
 - Don't start late, you won't have time!
- Reading assignment
 - Chapter 1.6, 6.1 6.7 of zyBooks (Reading Assignment #5)
 - Make sure to do the Participation Activities
 - Due Monday (11/5, extended)

Quote of the day

"95% of the folks out there are completely clueless about floating-point."

James Gosling Sun Fellow Java Inventor 1998-02-28



Review of Numbers

- Computers are made to deal with numbers
- What can we represent in N bits?
 - 2^N things, and no more! They could be...
 - Unsigned integers:

```
0 to 2^{N}-1
(for N=32, 2^{N}-1 = 4,294,967,295)
```

Signed Integers (Two's Complement)

```
-2^{(N-1)} to 2^{(N-1)} - 1 (for N=32, 2^{(N-1)} = 2,147,483,648)
```

What about other numbers?

- 1. Very large numbers? (seconds/millennium) $\Rightarrow 31,556,926,000_{10} (3.1556926_{10} \times 10^{10})$
- 2. Very small numbers? (Bohr radius) $\Rightarrow 0.0000000000529177_{10} \text{ m} (5.29177_{10} \text{ x } 10^{-11})$
- Numbers with <u>both</u> integer & fractional parts? $\Rightarrow 1.5$

First consider #3.

...our solution will also help with 1 and 2.

Representation of Fractions

"Binary Point" like decimal point signifies boundary between integer and fractional parts:

Example 6-bit representation:

$$10.1010_2 = 1x2^1 + 1x2^{-1} + 1x2^{-3} = 2.625_{10}$$

If we assume "fixed binary point", range of 6-bit representations with this format:

0 to 3.9375 (almost 4)

Fractional Powers of 2

i	2 ⁻ⁱ	
0.	1.0	1
1.	0.5	1/2
2.	0.25	1/4
3.	0.125	1/8
4.	0.0625	1/16
5.	0.03125	1/32
6.	0.015625	
7.	0.0078125	
8.	0.00390625	
9.	0.001953125	
10.	0.0009765625	
11.	0.00048828125	
12.	0.000244140625	
13.	0.0001220703125	
14.	0.00006103515625	
15.	0.000030517578125	

Fractions with Fixed Points

What about addition and multiplication?

Addition is straightforward:

$$\begin{array}{c}
01.100 & 1.5_{10} \\
+ & 00.100 & 0.5_{10} \\
10.000 & 2.0_{10}
\end{array}$$

Multiplication a bit more complex:

Where's the answer, 0.11? (need to remember where the point is)

```
01.100
               1.5_{10}
              0.5_{10}
     00.100
     0000
   0110
  00000
 0000
0000110000
```

Representation of Fractions

So far, in our examples we used a "fixed" binary point What we really want is to "float" the binary point. Why?

Floating binary point most effective use of our limited bits (and thus more accuracy in our number representation):

example: put 0.1640625 into binary. Represent as in 5-bits choosing where to put the binary point.

... 000000.001010100000...


Store these bits and keep track of the binary point 2 places to the left of the MSB

Any other solution would lose accuracy!

With floating point rep., each numeral carries an exponent field recording the whereabouts of its binary point.

The binary point can be outside the stored bits, so very large and small numbers can be represented.


Scientific Notation (in Decimal)



- Normalized form: no leadings 0s (exactly one digit to left of decimal point)
- Alternatives to representing 1/1,000,000,000
 - Normalized:
 - Not normalized:

- 1.0 x 10⁻⁹
- $0.1 \times 10^{-8}, 10.0 \times 10^{-10}$

Scientific Notation (in Binary)



- Computer arithmetic that supports it called <u>floating</u> <u>point</u>, because it represents numbers where the binary point is not fixed, as it is for integers
 - Declare such variable in C as float

Floating Point Representation (1/2)

- ► Normal format: +1.xxx...x_{two}*2^{yyy...y}two
- Multiple of Word Size (32 bits)



- S represents Sign
- Exponent represents y's
- Significand represents x's
- Represent numbers as small as
 2.0 x 10⁻³⁸ to as large as 2.0 x 10³⁸

Floating Point Representation (2/2)


What if result too large?

```
(> 2.0 \times 10^{38}, < -2.0 \times 10^{38})
```

- Overflow! ⇒ Exponent larger than represented in 8-bit Exponent field
- What if result too small?

$$(>0 \& < 2.0 \times 10^{-38}, <0 \& > -2.0 \times 10^{-38})$$

 <u>Underflow!</u> ⇒ Negative exponent larger than represented in 8-bit Exponent field



What would help reduce chances of overflow and/or underflow?

Double Precision Fl. Pt. Representation

Next Multiple of Word Size (64 bits)

313	30	20	19	0_
S	Exponent		Significand	
1 bi	t 11 bits		20 bits	
		Sig	nificand (cont'd)	
		_		

32 bits

- <u>Double Precision</u> (vs. <u>Single Precision</u>)
 - C variable declared as double
 - Represent numbers almost as small as 2.0×10^{-308} to almost as large as 2.0×10^{308}
 - But primary advantage is greater accuracy due to larger significand

QUAD Precision Fl. Pt. Representation

- Next Multiple of Word Size (128 bits)
 - Unbelievable range of numbers
 - Unbelievable precision (accuracy)
- ▶ IEEE 754-2008 "binary128" standard
 - Has 15 exponent bits and 112 significand bits (can represent 113 precision bits)
- Oct-Precision?
 - Some have tried, no real traction so far
- Half-Precision?
 - Yep, "binary16"

IEEE 754 Floating Point Standard (1/3)

Single Precision (DP similar):

31_3	0 23	22	0
S	Exponent	Significand	
$\frac{-}{1}$ bi	t 8 bits	23 bits	

- Sign bit:
 - 1 means negative
 - 0 means positive
- Significand:
 - To pack more bits, leading 1 implicit for normalized numbers
 - 1 + 23 bits single, 1 + 52 bits double
 - always true: 0 < Significand < 1 (for normalized numbers)
- Note: 0 has no leading 1, so reserve exponent value 0 just for number 0

IEEE 754 Floating Point Standard (2/3)

- ▶ IEEE 754 uses "biased exponent" representation.
 - Designers wanted FP numbers to be used even if no FP hardware; e.g., sort records with FP numbers using integer compares
 - Wanted bigger (integer) exponent field to represent bigger numbers.
 - 2's complement poses a problem (because negative numbers look bigger)
 - We're going to see that the numbers are ordered EXACTLY as in sign-magnitude
 - i.e., counting from binary odometer 00...00 up to 11...11 goes from 0 to +MAX to -0 to -MAX to 0

IEEE 754 Floating Point Standard (3/3)

- Called <u>Biased Notation</u>, where bias is number subtracted to get real number
 - IEEE 754 uses bias of 127 for single precision
 - Subtract 127 from Exponent field to get actual value for exponent
 - 1023 is bias for double precision
- Summary (single precision):

31	. 3	0 23	22 0
	S	Exponent	Significand
1	bit	t 8 bits	23 bits

- $(-1)^S \times (1 + Significand) \times 2^{(Exponent-127)}$
 - Double precision identical, except with exponent bias of 1023 (half, quad similar)

Understanding the Significand (1/2)

Method 1 (Fractions):

```
∘ In decimal: 0.340_{10} \Rightarrow 340_{10}/1000_{10}
\Rightarrow 34_{10}/100_{10}
```

• In binary:
$$0.110_2 \Rightarrow 110_2/1000_2 = 6_{10}/8_{10}$$

 $\Rightarrow 11_2/100_2 = 3_{10}/4_{10}$

 Advantage: less purely numerical, more thought oriented;
 this method usually helps people understand the meaning of the significand better

Understanding the Significand (2/2)

- Method 2 (Place Values):
 - Convert from scientific notation
 - In decimal:
 - $1.6732 = (1x10^{0}) + (6x10^{-1}) + (7x10^{-2}) + (3x10^{-3}) + (2x10^{-4})$
 - In binary:
 - $1.1001 = (1x2^{-0}) + (1x2^{-1}) + (0x2^{-2}) + (0x2^{-3}) + (1x2^{-4})$
 - Interpretation of value in each position extends beyond the decimal/binary point
 - Advantage: good for quickly calculating significand value; use this method for translating FP numbers

Converting Binary FP to Decimal

101 0101 0100 0011 0100 0010 0110 1000

- Sign: 0 → positive
- Exponent:

 - 0110 1000_{two} ≠ 104_{ten}
 Bias adjustment: 104 127 = -23
- Significand:

```
1 + 1x2^{-1} + 0x2^{-2} + 1x2^{-3} + 0x2^{-4} + 1x2^{-5} + ...
  =1+2^{-1}+2^{-3}+2^{-5}+2^{-7}+2^{-9}+2^{-14}+2^{-15}+2^{-17}+2^{-22}
  = 1.0 + 0.666115
```

Represents: $1.666115_{ten} * 2^{-23} \sim 1.986 * 10^{-7}$ (about 2/10,000,000)

Converting Decimal to FP

- -2.340625 x 10¹
- 1. Denormalize: -23.40625
- 2. Convert integer part:

$$23 = 16 + (7 = 4 + (3 = 2 + (1))) = 10111_{2}$$

3. Convert fractional part:

$$.40625 = .25 + (.15625 = .125 + (.03125)) = .01101_2$$

- 4. Put parts together and normalize:
 - $10111.01101 = 1.011101101 \times 2^4$
- 5. Convert exponent: $127 + 4 = 10000011_2$

Quiz

1 1000 0001 111 0000 0000 0000 0000 0000

What is the decimal equivalent of the floating pt # above?

a)
$$-7 * 2^129$$

b)
$$-3.5$$

c)
$$-3.75$$

$$d) -7$$

$$e) -7.5$$

Quiz Answer

What is the decimal equivalent of:

```
Significand
   Exponent
(-1)^{s} x (1 + Significand) x 2^{(Exponent-127)}
(-1)^1 \times (1 + .111) \times 2^{(129-127)}
 -1 \times (1.111) \times 2^{(2)}
                                        -7 * 2^129
                                    b) -3.5
-111.1
                                    c) -3.75
 111.1 \Rightarrow 4 + 2 + 1 + .5 \Rightarrow 7.5
                                       -7.5
```

Summary

- Floating Point lets us:
 - Represent numbers containing both integer and fractional parts; makes efficient use of available bits.
 - Store approximate values for very large and very small #s.
- ► IEEE 754 Floating Point Standard is most widely accepted attempt to standardize interpretation of such numbers (Every desktop or server computer sold since ~1997 follows these conventions)

single precision:

3130	23	22 0
S Ex	xponent	Significand
1 bit	8 bits	23 bits

- $(-1)^S \times (1 + Significand) \times 2^{(Exponent-127)}$
 - Double precision identical, except with exponent bias of 1023 (half, quad similar)