University Cote d'Azur

Polytech Nice Sophia

Department Engineering of Electronic Systems

Labs IoT Design

Fabrice MULLER

≇ : Fabrice.Muller@univ-cotedazur.fr

Contents

Ι	Io'	Γ Framework	1
1	Frai	mework	3
	1.1	Espressif IoT Development Framework	3
	1.2	Visual Studio Code with ESP-IDF	10
2	Deb	ougging with Visual Studio Code	13
	2.1	Principle	13
	2.2	Wiring ESP-PROG JTAG board	13
	2.3	Create the Lab	13
	2.4	First run for Debug	15
	2.5	Debugging	15
	2.6	Debugging Walk through	15
3	Wo	rking with C and IDF framework	19
	3.1	Useful functions (Lab3-1)	19
	3.2	Understanding the structures (Lab3-2)	22
	3.3	Refactoring code (Lab3-3)	25
	3.4	Dynamic allocation (Lab3-4)	28
	3.5	Linked list with pointers (Lab3-5)	30
4	IDF	Configuration and Components	33
	4.1	IDF Configurations (Lab4-1)	33
	4.2	IDF Components (Lab4-2)	36
II	Ic	oT Architecture	39
1			41
	1.1	,	41
	1.2	System Time (Lab1-2)	43

2	Me	mory	47
	2.1	Flash & SRAM Memories (Lab2-1)	47
	2.2	The sections	50
	2.3	Flash Memory - Custom partition table (Lab2-2)	53
	2.4	Storing files directly in flash memory (Lab2-3)	56
	2.5	Non Volatile Storage memory (Lab2-4)	58
	2.6	SPI Flash File System (Lab2-5)	62
3	Ger	neral Purpose Input/Output (GPIO)	67
	3.1	GPIO Output (Lab3-1)	
	3.2	GPIO Input (Lab3-2)	68
	3.3	Advanced configuration for GPIO (Lab3-3)	69
	3.4	Exercise - Display state of the push button	70
4	Inte	errupt with a General Purpose Input/Output (GPIO)	71
	4.1	Polling and Interrupt mode	71
	4.2	Polling mode (Lab4-1)	71
	4.3	Interrupt mode with GPIO (Lab4-2)	72
II	т 1	FreeRTOS	7 5
11	.1 1	rreenios	70
1	Tas	k & Scheduling	77
	1.1	Task scheduling on one core (Lab1-1)	
	1.2	Task scheduling on two cores (Lab1-2)	
	1.3	Approximated/Exactly periodic task (Lab1-3)	
	1.4	Task handler and dynamic priority (Lab1-4, Optional work)	90
2	Me	ssage Queue & Interrupt service	93
	2.1	Single Message Queue (Lab2-1)	93
	2.2	Message Queue with time out (Lab2-2)	96
	2.3	Blocking on single Queue (Lab2-3, Optional work)	96
	2.4	Using message queue with interrupts (Lab2-4)	99
3	Sen	naphore & Mutex	L 01
	3.1	Specification of the application	101
	3.2	First Task synchronization (Lab3-1)	104
	3.3	Task synchronization with 2 semaphores (Lab3-2)	106
	3.4	Mutual Exclusion (Lab3-3)	112
4	Dir		119
	4.1	Direct task notification (Lab4-1)	119
	4.2	Direct task notification with a event value (Lab4-2)	121

5	Application	123
	5.1 Specification of the application	123
	5.2 Implementation of the application (Lab5)	126
I	V Appendix	129
A	ESP32 Board	131
$\mathbf{R}_{\mathbf{c}}$	eferences	133

Part I IoT Framework

Framework

Lab Objectives

- Understand the Espressif IoT Development Framework.
- Run a first program.
- Create an GitHub repository.
- Use the Microsoft Visual Studio Code with a dedicated ESP32 project template.

1.1 Espressif IoT Development Framework

We will start by understanding the structure of the Espressif IDF framework using an example provided by Espressif.

1.1.1 Quick install of Espressif IoT Development Framework 4.3

We are going to install version 4.3 of Espressif IoT Development Framework. The complete documentation is available online from this link. if you have difficulty to install it, go to the **Get Started** section otherwise, open a terminal and follow the script below:

• Install prerequisites

```
esp32:~$ sudo apt-get install git wget flex bison gperf python3 python3-pip python3-setuptools cmake ninja-build ccache libffi-dev libssl-dev dfu-util libusb-1.0-0
```

• Get ESP-IDF

LAB 1

• Set up the tools

```
esp32:~$ cd ~/esp/esp-idf
esp32:~$ ./install.sh
```

• Set the rights for USB driver and debug tools

```
esp32:~$ sudo usermod -a -G dialout $USER
esp32:~$ sudo usermod -a -G uucp $USER
esp32:~$ sudo usermod -a -G plugdev $USER
esp32:~$ sudo cp ~/.espressif/tools/openocd-esp32/v0.10.0-esp32-20210401/
openocd-esp32/share/openocd/contrib/60-openocd.rules /etc/udev/rules.d/
```

- Add the environment
 - Open .bashrc file.

```
esp32:~$ gedit ~/.bashrc
```

— Copy this line below at the end of the file.

```
. $HOME/esp/esp-idf/export.sh
```

• Reboot the computer

```
esp32:~$ reboot
```

• Open a terminal. verify the environment. You should see the lines for the environment configuration of Espressif IoT Development Framework as below:

```
Setting IDF_PATH to '/home/esp32/esp/esp-idf'
Detecting the Python interpreter
Checking "python" ...
Python 3.6.9
"python" has been detected
Adding ESP-IDF tools to PATH...
Using Python interpreter in /home/esp32/.espressif/python_env/idf4.3_py3.6
   _env/bin/python
Checking if Python packages are up to date...
Python requirements from /home/esp32/esp/esp-idf/requirements.txt are
   satisfied.
Added the following directories to PATH:
 /home/esp32/esp/esp-idf/components/esptool_py/esptool
  /home/esp32/.espressif/python_env/idf4.3_py3.6_env/bin
 /home/esp32/esp/esp-idf/tools
Done! You can now compile ESP-IDF projects.
Go to the project directory and run:
 idf.py build
```

You are now ready to use the Espressif IoT Development Framework!

1.1.2 Creation of GitHub repository for Labs

We will have many Labs. Thus, we are going to create a GitHub repository *labs* in the *esp* folder that will contain all the Labs.

Firstly, in the WEB interface of GitHub (open with Google Chrome or another navigator), you have to create a new repositories in GitHub, for example « labs » (use the same name of your labs folder, normally « labs »). **Configure your GitHub in private access** with a *README.md* file as shown the figure 1.1




FIGURE 1.1 – Create a GitHub repository.

Secondly, you should create a personal access token to use in place of a password to access of your GitHub folder. Follow the instructions to generate a token.

Thirdly, in a terminal, follow the steps to clone your new GitHub repositories in your computer :

1. You start cloning your « labs » repository to the computer. To obtain the URL of your repository, copy the repository URL located on GitHub webpage. The example below shows you the principle when you have to replace <your owner> by your GitHub owner.

```
esp32:~/$ cd ~/esp
esp32:~/esp$ git clone https://github.com/<your owner>/labs
```

2. You can now configure your name and email address for GIT in the new « labs » repository.

```
esp32:~/esp$ cd labs
esp32:~/esp/labs$ git config --global user.name "your name"
esp32:~/esp/labs$ git config --global user.email "your email address"
```

3. You could enter this command to avoid typing your *username* and *token* each time in Visual Studio Code.

```
esp32:~/esp/labs$ git config credential.helper store
```

You have information for configuring GIT for your new project.

1.1.3 First look of the first example

Take the example « hello_world » which displays the string « hello world! » and characteristics of the ESP32 board on the console. The example is located in the following directory :

```
esp32:~$ cp -R ~/esp/esp-idf/examples/get-started/hello_world ~/esp/labs/
hello_world
esp32:~$ cd ~/esp/labs/hello_world
```

The compilation is done from a Python script called *idf.py*. This script is located in ~/esp/esp-idf/tools/ and added in the path.

```
esp32:~/esp/labs/hello_world$ which idf.py
/home/esp32/esp/esp-idf/tools/idf.py

esp32:~/labs/hello_world$ env | grep esp-idf
IDF_TOOLS_EXPORT_CMD=/home/esp32/esp/esp-idf/export.sh
PWD=/home/esp32/esp/labs/hello_world
IDF_TOOLS_INSTALL_CMD=/home/esp32/esp/esp-idf/install.sh
IDF_PATH=/home/esp32/esp/esp-idf
PATH=/home/esp32/esp/esp-idf/components/esptool_py/esptool:/home/esp32/esp/esp-idf/
    components/espcoredump:/home/esp32/esp/esp-idf/components/partition_table/:/
    home/esp32/.espressif/tools/xtensa-esp32-elf/esp-2019r2-8.2.0/xtensa-esp32-elf/
    bin:/home/esp32/.espressif/tools/esp32ulp-elf/2.28.51.20170517/esp32ulp-elf-
    binutils/bin:/home/esp32/.espressif/tools/openocd-esp32/v0.10.0-esp32-20190313/
    openocd-esp32/bin:/home/esp32/.espressif/python_env/idf4.0_py3.6_env/bin:/home/
    esp32/esp/esp-idf/tools:/home/esp32/.local/bin:/usr/local/sbin:/usr/local/bin:/
    usr/sbin:/usr/bin:/sbin:/bin:/usr/games:/usr/local/games:/snap/bin
```

To display the help of the Python script, just type the name of the command as below. We will mainly use the following commands: build, flash, monitor, menuconfig,

fullclean, size ...

```
esp32:~/esp/labs/hello_world$ idf.py
Checking Python dependencies...
Python requirements from /home/esp32/esp/esp-idf/requirements.txt are satisfied.
Usage: /home/esp32/esp/esp-idf/tools/idf.py [OPTIONS] COMMAND1 [ARGS]... [COMMAND2
   [ARGS]...]...
 ESP-IDF build management
Options:
 -b, --baud INTEGER
                                  Baud rate. This option can be used at most once
   either globally, or
                                  for one subcommand.
 -p, --port TEXT
                                  Serial port. This option can be used at most once
    either globally,
                                  or for one subcommand.
Commands:
 all
                         Aliases: build. Build the project.
                         Delete build output files from the build directory.
 clean
 flash
                         Flash the project.
 fullclean
                         Delete the entire build directory contents.
                         Run "menuconfig" project configuration tool.
 menuconfig
                         Display serial output.
 monitor
                         Print basic size information about the app.
 size
 size-files
                         Print per-source-file size information.
```

The C source files are usually located in the « main » folder. We see below the « hello_world_main.c » file. The other files will be studied later.

```
esp32:~/esp/labs/hello_world$ 11 main

total 20
drwxr-xr-x 2 esp32 esp32 4096 avril 2 15:31 ./
drwxr-xr-x 4 esp32 esp32 4096 mai 26 10:07 ../
-rw-r--r-- 1 esp32 esp32 85 avril 2 15:31 CMakeLists.txt
-rw-r--r-- 1 esp32 esp32 146 avril 2 15:31 component.mk
-rw-r--r-- 1 esp32 esp32 1232 avril 2 15:31 hello_world_main.c
```

1.1.4 Building the first example

The generation of the executable in this specific case is called **cross-compilation** because the program will not be performed on the computer but on the ESP32 board. We build the executable from the following command.

```
esp32:~/esp/labs/hello_world$ idf.py build
[59/62] Linking C static library esp-idf/spi_flash/libspi_flash.a
[60/62] Linking C static library esp-idf/main/libmain.a
[61/62] Linking C executable bootloader.elf
[62/62] Generating binary image from built executable
esptool.py v2.8
Generated /home/esp32/esp/labs/hello_world/build/bootloader/bootloader.bin
[820/820] Generating binary image from built executable
esptool.py v2.8
Generated /home/esp32/esp/labs/hello_world/build/hello-world.bin
Project build complete. To flash, run this command:
/home/esp32/.espressif/python_env/idf4.0_py3.6_env/bin/python ../../../components/
   esptool_py/esptool/esptool.py -p (PORT) -b 460800 --before default_reset --
   after hard_reset write_flash --flash_mode dio --flash_size detect --flash_freq
   40m 0x1000 build/bootloader/bootloader.bin 0x8000 build/partition_table/
   partition-table.bin 0x10000 build/hello-world.bin
or run 'idf.py -p (PORT) flash'
```

A new « build » folder appears. In this folder, you can see the « hello-world.elf » which will be flashed in the ESP32 board.

```
esp32:~/esp/labs/hello_world$ ll
total 56
                              26 10:07 ./
drwxr-xr-x 4 esp32 esp32 4096 mai
drwxr-xr-x 74 esp32 esp32 4096 mai
                              26 10:27 build/
                     234 avril 2 15:31 CMakeLists.txt
-rw-r--r-- 1 esp32 esp32
-rw-r--r-- 1 esp32 esp32
                              2 15:31 Makefile
                      183 avril
-rw-r--r-- 1 esp32 esp32
                      170 avril 2 15:31 README.md
         1 esp32 esp32 25463 mai
                              26 10:26 sdkconfig
-rw-r--r--
esp32:~/esp/labs/hello_world$ cd build
-rw-r--r-- 1 esp32 esp32 147232 mai
                              26 10:27 hello-world.bin
-rwxr-xr-x 1 esp32 esp32 2451528 mai
                              26 10:27 hello-world.elf*
                              26 10:27 hello-world.map
rw-r--r-- 1 esp32 esp32 1541555 mai
```

```
esp32:~/esp/labs/hello_world/build$ cd ..
```

1.1.5 Running the first example on ESP32 board

You find details of the ESP32-PICO-KIT board in the Getting Started Guide. To run the program on the board, follow the procedure below :

• Connect the ESP32 card to the computer via USB (cf. figure 1.2)




FIGURE 1.2 – ESP32-PICO-KIT board connections.

• Identify the USB serial port (usually /dev/ttyUSB0)
esp32:~/esp/labs/hello_world\$ ls /dev/ttyUSB*
/dev/ttyUSB0

• Flash the board and push the BOOT button to launch the programming

```
esp32:~/esp/labs/hello_world$ idf.py -p /dev/ttyUSBO flash
esptool.py -p /dev/ttyUSBO -b 460800 --before default_reset --after
   hard_reset write_flash --flash_mode dio --flash_freq 40m --flash_size 2MB
    0x8000 partition_table/partition-table.bin 0x1000 bootloader/bootloader.
   bin 0x10000 hello-world.bin
esptool.py v2.8
Serial port /dev/ttyUSB0
{\tt Connecting.....}
Detecting chip type... ESP32
Chip is ESP32-PICO-D4 (revision 1)
Compressed 147232 bytes to 76527...
Wrote 147232 bytes (76527 compressed) at 0x00010000 in 1.7 seconds (effective
    675.4 kbit/s)...
Hash of data verified.
Leaving...
Hard resetting via RTS pin...
Done
```

• Monitor console messages sent by the program running on the ESP32 card. To exit monitoring, typing « Ctrl+AltGr+| »

```
esp32:~/esp/labs/hello_world$ idf.py -p /dev/ttyUSBO monitor
...
I (294) spi_flash: flash io: dio
W (294) spi_flash: Detected size(4096k) larger than the size in the binary
    image header(2048k). Using the size in the binary image header.
I (304) cpu_start: Starting scheduler on PRO CPU.
I (0) cpu_start: Starting scheduler on APP CPU.
Hello world!
This is ESP32 chip with 2 CPU cores, WiFi/BT/BLE, silicon revision 1, 2MB
    embedded flash
Restarting in 10 seconds...
Restarting in 9 seconds...
Restarting in 8 seconds...
```

1.2 Visual Studio Code with ESP-IDF

In order to develop applications in a user-friendly way, we use Microsoft Visual Studio Code throughout these Labs. Moreover, we use a Visual Studio Code project template located in GitHub: https://github.com/fmuller-pns/esp32-vscode-project-template.

To use the template:

• Go to your repository where we will create the first lab named « part1 iot framework ».

```
esp32:~$ cd labs
esp32:~/labs$ mkdir part1_iot_framework
esp32:~/labs$ cd part1_iot_framework
```

• Clone the template project named « Visual Studio Code Template for ESP32 »

```
esp32:~/labs/part1_iot_framework$ git clone https://github.com/fmuller-pns/esp32-vscode-project-template.git
Cloning into 'esp32-vscode-project-template'...
remote: Enumerating objects: 30, done.
remote: Counting objects: 100% (30/30), done.
remote: Compressing objects: 100% (23/23), done.
remote: Total 30 (delta 8), reused 23 (delta 4), pack-reused 0
Unpacking objects: 100% (30/30), done.
```

• List working directory

```
esp32:~/labs/part1_iot_framework$ 11

total 12

drwxr-xr-x 3 esp32 esp32 4096 mai 26 16:17 ./

drwxr-xr-x 24 esp32 esp32 4096 mai 26 16:16 ../

drwxr-xr-x 5 esp32 esp32 4096 mai 26 16:18 esp32-vscode-project-template/
```

• Rename the folder.

```
esp32:~/labs/part1_iot_framework$ mv esp32-vscode-project-template
lab1_framework
```

• Delete .git folder of the new project « lab1_framework ». Be careful, do not delete the .git folder located in the « labs » folder.

```
esp32:~/labs/part1_iot_framework$ cd lab1_framework
esp32:~/labs/part1_iot_framework/lab1_framework$ rm -fR .git
```

• Open Visual Studio Code for the new project.

```
esp32:~/labs/part1_iot_framework/lab1_framework$ code
```

- Follow the section Getting Started to run the program on the board.
- Change the message in the app main() function located in the main.c file.
- Build and run the program.
- You must commit and push the modification in GitHub. Follow the section Using GitHub with Visual Studio Code to do it.

Tip: Using a script to create an ESP32 project

We provide a script file *create_esp32_prj.sh* in Labs folder. You have to copy the contains at the end of the *.bashrc* file.

• Edit the .bashrc file.

```
esp32:~/labs/part1_iot_framework/lab1_framework$ gedit ~/.bashrc
```

- Copy the contents of *create esp32 prj.sh* file to the end of *.bashrc* file.
- Close the terminal
- Open a new terminal and check if the function now exists. You normally have an error because you must pass the name of the project.

```
esp32:~$ esp32-new-project
Error: add the name of the project
Example: esp32-new-prj-template <my_project>
```

Now, you are ready to use Visual Studio Code with ESP-IDF for other projects!

Debugging with Visual Studio Code

Lab Objectives

- Understand the principle of the on-chip debugger.
- Debug a program with Visual Studio Code.

2.1 Principle

Figure 2.1 illustrates the operating principle for debugging the ESP32 processor. Debugging is generally done using a debugging tool which will be GDB (GNU Project Debugger). GDB communicates with Visual Studio Code and OpenOCD (Open On-Chip Debugger). OpenOCD communicates with the ESP-PROG JTAG board from Espressif Systems which is connected to the ESP32-PICO-D4 board via a JTAG communication (Joint Test Action Group, Industry standard IEEE 1149.1) and to the computer via an USB communication. This ESP-PROG JTAG card acts as a gateway between the ESP32-PICO-D4 board and OpenOCD board.

2.2 Wiring ESP-PROG JTAG board

Figure 2.2 shows how to wire the JTAG communication. You have 4 wires for the TAP (Test Access Port), respectively Test Data In (TDI), Test Mode Select (TMS), Test Clock (TCK), Test Data Out (TDO). Do not forget to connect the GND wire.

2.3 Create the Lab

We will create the « lab2 debug » project and run Visual Studio Code as below :




FIGURE 2.1 – Debugging principle.

11	1014	1/0	ADC2_CH6, TOUCH6, RTC_GPIO16, MTMS, HSPICLK, HS2_CLK, SD_CLK, EMAC_TXD2
12	1012	1/0	ADC2_CH5, TOUCH5, RTC_GPIO15, MTDI (See 4), HSPIQ, HS2_DATA2, SD_DATA2, EMAC_TXD3
13	1013	1/0	ADC2_CH4, TOUCH4, RTC_GPIO14, MTCK, HSPID, HS2_DATA3, SD_DATA3, EMAC_RX_ER
14	1015	1/0	ADC2_CH3, TOUCH3, RTC_GPIO13, MTDO, HSPICSO HS2_CMD, SD_CMD, EMAC_RXD3




FIGURE 2.2 - Wiring ESP-PROG JTAG board.

1. Create the lab

```
esp32:~/../part1_iot_framework$ cd lab2_debug
esp32:~/../part1_iot_framework/lab2_debug$ rm -fR .git
esp32:~/../part1_iot_framework/lab2_debug$ code .
```

2. Overwrite the « main.c » file by the provided code of the « main.c » file in the « lab2 esp32 debug » folder.

2.4 First run for Debug

The procedure to start the debugger is explained in the Visual Studio Code project template located in GitHub.

2.5 Debugging

2.5.1 Execution of the program

- 1. Run the program.
- 2. What does this program do?

2.6 Debugging Walk through

1. Indicate a breakpoint at the line below. To do this, click to the right of the line number to display a red dot

FIGURE 2.3 – Wiring ESP-PROG JTAG board.

- 2. What does this program do?
- 3. Run the debugger to the breakpoint (cf. figure 2.4)
- 4. Examine the situation at the breakpoint: variables, call stacks, watch, breakpoints.
- 5. Click on Step into command until entering the loop of the factorial function.
- 6. Examine the new situation: variables, call stacks, watch, breakpoints.
- 7. Click on Step into command to run step by step.




Figure 2.4 – Debugging with Visual Studio Code.

- 8. Click on Step out command to exit of the factorial function.
- 9. Click on *Continue till next break* command. The program is executed until the end because there is only 1 breakpoint defined.
- 10. Add a second breakpoint in the loop of the factorial function.
- 11. Click on Restart command.
- 12. Click on *Continue till next break* command. You are normally on the second breakpoint (loop of the factorial function)
- 13. Examine the new situation: variables, call stacks, watch, breakpoints.
- 14. Click on *Continue till next break* command. You will be on the second iteration of the loop.
- 15. Examine the new situation: variables, call stacks, watch, breakpoints.
- 16. Unvalidate the breakpoint that is in the loop. Click on the red dot or uncheck the correct breakpoint in the breakpoint view.
- 17. Click on Continue till next break command. The program runs until the end.

Now you know how to debug a program!

Working with C and IDF framework

Lab Objectives

- Useful functions: usleep, random, sprintf, strcpy, malloc, ESP LOG ...
- Preprocessor commands (#define, #ifdef, #include ...)
- Master useful keywords like static, const, extern ...
- Define a structure, an enumeration and an union. Use designated initializer. Define structures as function arguments, access structure members.
- Refactor program with header files.
- Use dynamic allocation.
- Define IDF components.
- Use GitHub and Doxygen.

3.1 Useful functions (Lab3-1)

3.1.1 Create the Lab

We will create the «lab3-1 useful functions» and run Visual Studio Code as below:

1. Create the lab

```
esp32:~$ cd ~/labs
esp32:~/labs$ cd part1_iot_framework
esp32:~/../part1_iot_framework$ git clone https://github.com/fmuller-pns/
    esp32-vscode-project-template.git
esp32:~/../part1_iot_frameworks$ mv esp32-vscode-project-template lab3-1
    _useful_functions
esp32:~/../part1_iot_framework$ cd lab3-1_useful_functions
esp32:~/../part1_iot_framework/lab3-1_useful_functions$ rm -fR .git
esp32:~/../part1_iot_framework/lab3-1_useful_functions$ code .
```

2. Overwrite the « main.c » file by the provided code of the « lab3-1 main.c » file.

3.1.2 Understanding the program

The entry point in IDF Framework is the $app_main()$ function (we will see later, it is more like a task). Remember that in the classic C program, the entry point is the main() function. We are not interested in the keyboardInput() function at this time.

- 1. Answer the following questions:
 - What is #include? Web help
 - What is #define? Web help
- 2. Find out on the Web how to use these functions:
 - printf()
 - usleep()
 - ESP_LOGE(), ESP_LOGW(), ESP_LOGI(), ESP_LOGD(), ESP_LOGV(), Web help
 - esp_log_level_set()
- 3. Complete the program except the getTemperature() function that we will see later.
- 4. Launch the program and analyze the result.

 Tip: Remember that the full help is in the section Getting Started to run the program on the board.

3.1.3 Behavior of the temperature function code

- 1. Find out on the Web how to use these functions:
 - esp random(), Web help

- abs()
- 2. What does the getTemperature() function return as a result?
- 3. Write the behavior of the *getTemperature()* function that returns a random temperature value between the offset and a maximum value.
- 4. Launch the program and analyze the result.

3.1.4 keyboardInput() function

We will need to enter values or strings throughout the Labs. The following function meets this need.

- 1. Find out on the Web how to use these functions:
 - memset()
 - getchar(), Web help
 - strlen()
 - atoi()
 - ESP_OK, ESP_ERROR_CHECK, Web help
- 2. In the app_main function, add this code below just before the while loop.

```
char str[10];
printf("Enter offset : ");
ESP_ERROR_CHECK ( keyboardInput(str, 10) );
offset = atoi(str);
```

3. Build the project. What is wrong? correct the problem.

- 4. What does this code do?
- 5. Launch the program and analyze the result.

3.2 Understanding the structures (Lab3-2)

3.2.1 Create the new Lab

We will create the « lab3-2-1 working with c » and run Visual Studio Code as below :

1. Create the Lab

```
esp32:~$ cd ~/labs
esp32:~/labs$ cd part1_iot_framework
esp32:~/../part1_iot_framework$ git clone https://github.com/fmuller-pns/
    esp32-vscode-project-template.git
esp32:~/../part1_iot_framework$ mv esp32-vscode-project-template lab3-2-1
    _working_with_c
esp32:~/../part1_iot_framework$ cd lab3-2-1_working_with_c
esp32:~/../part1_iot_framework/lab3-2-1_working_with_c$ rm -fR .git
esp32:~/../part1_iot_framework/lab3-2-1_working_with_c$ code .
```

2. Overwrite the « main.c » file by the provided code of the « lab3-2-1_main.c » file.

3.2.2 Working on the program

- 1. Answer the following questions:
 - What is a structure? Web help

- What is an union? Web help
- What is an enumerate? Web help

- What is a typedef? Web help
- What are these keywords used for?

```
— static Web help
```

- const Web help
- what is a designated initializer? Web help
- 2. Declare and initialize a sensorSet variable (with a designated initializer) In the app main() function. The variable is a SensorSetStruct structure. The values are:
 - Temperature name = "TEMP"
 - Temperature type = FLOAT
 - Temperature value = 0.0
 - Pressure name = "PRES"
 - Pressure type = INT
 - Pressure value = 0
- 3. Launch the program and analyze the result.

Tip: Remember that the full help is in the section Getting Started to run the program on the board.

- 4. Add a breakpoint in the $app_main()$ function, at line where we call updateAndDis-playSensorValues() function.
- 5. Launch the program in debug mode and watch the sensorSet variable at each iteration.

3.2.3 Function arguments

We will pass the two Update() and Display() default functions through parameters of the updateAndDisplaySensorValues() function as below:

1. Duplicate the « lab3-2-1_working_with_c » folder to « lab3-2-2_working_with_c »
 esp32:~/../part1_iot_framework\$ cp -r lab3-2-1_working_with_c lab3-2-2
 _working_with_c
 esp32:~/../part1_iot_framework\$ cd lab3-2-2_working_with_c
 esp32:~/../part1_iot_framework/lab3-2-2_working_with_c\$ idf.py fullclean
 esp32:~/../part1_iot_framework/lab3-2-2_working_with_c\$ code .

- 2. Modify behavior of the *updateAndDisplaySensorValues()* function to use function arguments.
- 3. Modify the call of the updateAndDisplaySensorValues() function.
- 4. Launch the program and analyze the result.
- 5. Add a breakpoint in the $app_main()$ function, at line where we call updateAndDis-playSensorValues() function.
- 6. Launch the program in debug mode and watch the sensorSet variable at each iteration.

3.2.4 Structure members

We will now directly declare the Update() and Display() functions in the SensorSetStruct structure as below:

- 2. Add the two structure members to the SensorSetStruct structure.
- 3. Modify the updateAndDisplaySensorValues() function behavior.

4. Add the default functions (i.e. defaultUpdateSensorValues() and defaultPrintSensor-Values()) to the designated initializer in the app_main() function.

- 5. Launch the program and analyze the result.
- 6. Add a breakpoint in the $app_main()$ function, at line where we call updateAndDis-playSensorValues() function.
- 7. Launch the program in debug mode and watch the sensorSet variable at each iteration.
 - What are the address of the *Update* and *Display* fields of the *SensorSetStruct* structure?
 - What do these 2 addresses correspond to?
 - In what memory are the functions stored?
- 8. What is the interest of declaring these functions in the structure?

3.3 Refactoring code (Lab3-3)

All the code is in one file. It is recommended to refactor the code for better readability, flexibility and usability. We are going to move sensor functions into separate files. We usually have the header file and the source file which contains the function code.

3.3.1 Refactoring code

- 2. Create two new blank files: sensors.h and sensors.c
- 3. In the sensors.c
 - Include header files in the sensors.c (#include ...)
 - Move TAG constant
 - Move defaultUpdateSensorValues(), defaultPrintSensorValues(), updateAndDisplaySensorValues() functions
 - Move sensorSet variable and rename it defaultSensorSet as below :

```
struct SensorSetStruct defaultSensorSet = {
    ...
};
```

- 4. What are the *extern* keyword used for?
- 5. In the sensors.h
 - Add conditional macros. Why does we do that?

```
#ifndef _SENSORS_H_
#define _SENSORS_H_
...
#endif
```

- Move enumeration, structures and types
- Declare the 3 prototype functions : defaultUpdateSensorValues(), defaultPrintSensorValues(), updateAndDisplaySensorValues()
- 6. the main.c file becomes very small. The only function is $app \quad main()$.
 - Modify the code of these function as below:

```
void app_main(void) {
  int i;
  while (1) {
    ESP_LOGI(TAG, "DEFAULT Functions - SENSORS");
    for (i=0; i<5; i++) {
        // Wait for 1 sec.
        usleep(1000000);
        updateAndDisplaySensorValues(&defaultSensorSet);
    }
  }
}</pre>
```

• Do not forget to put this line in the right place to reference function and so on.

```
#include "sensors.h"
```

7. What does the app main() function exactly do?

8. Build the code. Why is there an error on the defaultSensorSet variable?

9. In the *sensors.h*, add this line. What does the line do?

```
extern struct SensorSetStruct defaultSensorSet;
```

10. Launch the program and analyze the result.

3.3.2 Reference custom functions

- 2. Overwrite the provided code of the « lab3-3-2 main.c » file in the « main.c » file.
- 3. Explain the code of the app main() function, among others:
 - The use of updateSensorValues() and printSensorValues() functions
 - The global behavior

- 4. Launch the program and analyze the result.
- 5. What's wrong with this code if we're interested in the defaultSensorSet variable?
- 6. What is the solution? Do not code the solution.

3.4 Dynamic allocation (Lab3-4)

3.4.1 Create the Lab

We will create the «lab3-4 memory allocation» and run Visual Studio Code as below:

2. Overwrite the « main.c » file by the provided code of the « lab3-4_main.c file.

3.4.2 Understanding the program

- 1. Answer the following questions:
 - What is the *sizeof* keyword? Web help
 - What is a pointer? Web help
 - How does arithmetic work for pointers? Web help
 - What is an array of pointers? Web help
- 2. Find out on the Web how to use these functions:
 - malloc(), calloc(), free(), Web help

• memcpy(), strlen(), strcpy(), Web help

- sprintf(), Web help
- esp get free heap size(), Web help
- 3. Create a new function createDefaultSensorSet() at the end of the sensors.c file. This function returns a copy of the defaultSensorSet global variable already defined in the same file.

```
struct SensorSetStruct * createDefaultSensorSet() {
    // Declare a local variable named sensorSet which will be return
    later

    // Allocate a memory space for the sensorSet variable

    // Check that there was no allocation error

    // Copy the default structure (i.e. defaultSensorSet global
    variable) in the sensorSet variable
}
```

4. Modify in the sensors.h file the name field. We use

```
typedef struct SensorStruct
{
   char *name; // char name[10];
   enum SensorValueType type;
   union SensorValueUnion value;
} Sensor;
```

- 5. Understand the behavior of $app_main()$ function.
- 6. Build. Adapt the code to remove compilation errors.
- 7. Add a breakpoint at the line below:

```
ESP_LOGI(TAG, "DEFAULT Functions - SENSORS");
```

- 8. Launch the program in debug mode and watch defaultSensorSet and customSensorSet variables.
- 9. Launch the program till the end of the execution (about 12 sec.) and analyze the result.

- What is the size of the SensorSetStruct structure?
- Interpret the evaluations of $h_i h_{i+1}$ printed at the end of the program

3.5 Linked list with pointers (Lab3-5)

3.5.1 Create the Lab

We will create the « lab3-5 _ linked _ list » and run Visual Studio Code as below :

1. Create the lab

```
esp32:~$ cd ~/labs
esp32:~/labs$ cd part1_iot_framework
esp32:~/../part1_iot_framework$ git clone https://github.com/fmuller-pns/
    esp32-vscode-project-template.git
esp32:~/../part1_iot_frameworks$ mv esp32-vscode-project-template lab3-5
    _linked_list
esp32:~/../part1_iot_framework$ cd lab3-5_linked_list
esp32:~/../part1_iot_framework/lab3-5_linked_list$ rm -fR .git
esp32:~/../part1_iot_framework/lab3-5_linked_list$ code .
```

- 2. Overwrite the « main.c » file by the provided code of the « lab3-5 main.c file.
- 3. Copy provided « lab3-5_sensors.c » and « lab3-5_sensors.h » files and rename it : « sensors.c » and « sensors.h ».

3.5.2 Understanding the program

- 1. Answer the following questions:
 - What is the linked list? Web help

2. Explain the SensorStruct and SensorSetStruct types in the sensor.h file.

LAB 3 31

3. Explain the behavior of the *createDefaultSensorSet()* function (main steps) by adding comments in the code.

4. Explain the behavior of the *freeSensorSet()* function (main steps) by adding comments in the code.

- 5. Understand the behavior of *updateSensorValues()* and *printSensorValues()* functions.
- 6. Understand the behavior of app main() function.
- 7. Add a breakpoint a the line below:

```
ESP_LOGI(TAG, "DEFAULT Functions - SENSORS");
```

- 8. Launch the program in debug mode and watch defaultSensorSet and customSensorSet variables. Check that the addresses of the pointers are different for the 2 variables.
- 9. Launch the program till the end of the execution and analyze the result.
 - What is the size of the *SensorSetStruct* structure? Why is it smaller than in the previous « lab3-4_memory_allocation »?
 - Interpret the evaluations of $h_i h_{i+1}$ printed at the end of the program.

LAB 3 32

10. What is the advantage of this linked list version over the previous one in « lab3- $4_$ memory_allocation » ?

IDF Configuration and Components

Lab Objectives

- Define an IDF Configuration
- Create an IDF Components

4.1 IDF Configurations (Lab4-1)

The objective is to configure the « lab3-5_linked_list » lab by using the configuration menu available in the framework. For this we are going to create a new lab « lab4-1_menuconfig ».

4.1.1 Create the Lab

1. Duplicate the « lab3-5_linked_list » folder to « lab4-1_menuconfig »

```
esp32:~/../part1_iot_framework$ cp -r lab3-5_linked_list lab4-1_menuconfig esp32:~/../part1_iot_framework$ cd lab4-1_menuconfig esp32:~/../part1_iot_framework/lab4-1_menuconfig$ idf.py fullclean esp32:~/../part1_iot_framework/lab4-1_menuconfig$ code .
```

- 2. Overwrite the « main.c » file by the provided code of the « lab4-1_main.c » file. Do not forget to rename it to « main.c »).
- 3. Copy the «lab4-1_Kconfig.projbuild » provided file to main folder. Do not forget to rename it to «Kconfig.projbuild »).

4.1.2 Manipulate configuration menu

When the program starts to run, a warning appears repeatedly. The objective is to remove this warning by using the configuration menu.

1. Run the program.

```
esp32:~/../part1_iot_framework/lab4-1_menuconfig$ idf.py -p /dev/ttyUSB0
    flash monitor
...
I (292) spi_flash: flash io: dio
W (292) spi_flash: Detected size(4096k) larger than the size in the binary
    image header(2048k). Using the size in the binary image header.
I (302) cpu_start: Starting scheduler on PRO CPU.
I (0) cpu_start: Starting scheduler on APP CPU.
```

- 2. Look for the following warning. This is due to a bad default configuration. Indeed, the ESP32-PICO-D4 board embeds 4MiB of flash memory instead of 2MiB.
- 3. Open the *sdkconfig* file and search the «CONFIG_ESPTOOLPY_FLASHSIZE_2MB» and «CONFIG_ESPTOOLPY_FLASHSIZE» parameters. We would rather have the parameter «CONFIG_ESPTOOLPY_FLASHSIZE_4MB» defined!
- 4. Run the menu config

```
esp32:~/../part1_iot_framework/lab4-1_menuconfig$ idf.py menuconfig
```

- 5. Go to « Serial flasher config » / « Flash size ». Press Return, Select 4MB by press Spacebar and then exit with saving.
- 6. Open the *sdkconfig* file and search the « CONFIG_ESPTOOLPY_FLASHSIZE_2MB » and « CONFIG_ESPTOOLPY_FLASHSIZE_4MB » parameters. The configuration is now correct. We will restart the program.

```
esp32:~/../part1_iot_framework/lab4-1_menuconfig$ idf.py -p /dev/ttyUSB0 flash monitor
```

7. What do you see?

4.1.3 Customizing menu configuration

- 1. Answer the following question:
 - What represent the « Kconfig.projbuild »? Web help 1, Web help 2
- 2. Explain the content of the « Kconfig.projbuild » configuration file.

- What is the name of the custom menu?
- What is the type of CONSTANT and CUSTOM_FUNCTIONS parameters?
- 3. Explain the role of the CONFIG_CONSTANT and CONFIG_CUSTOM_FUNCTIONS configuration value located in the main.c file.
- 4. Run the configuration menu and activate the CUSTOM_FUNCTIONS esp32:~/../part1_iot_framework/lab4-1_menuconfig\$ idf.py menuconfig
- 5. Open the sdkconfig file and check the CUSTOM FUNCTIONS parameter
- 6. Run the program and check if the modification has been taken into account.

```
esp32:~/../part1_iot_framework/lab4-1_menuconfig$ idf.py -p /dev/ttyUSB0 flash monitor
```

- 7. We would like to display a title editable via configuration menu.
 - Add the «INFORMATION_TITLE» parameter of type *string*. The default title will be «My Title».
 - Add a help thanks to the *help* keyword (*help* hello!)
 - Run the configuration menu and change the default title (for example « Sensor Information »)

```
esp32:~/../part1_iot_framework/lab4-1_menuconfig$ idf.py menuconfig
```

- Modify the code. The line of code that displays the title is at the start of the printSensorValues() function.
- Run the program and verify.
- 8. We want to change the delay (currently 1 sec.) via configuration menu.
 - Add the « UPDATE_DELAY » parameter of type *int*. The unit will be in ms. The default value will be « 1000 » (1 sec.).
 - We want the values to be between 1 second and 5 seconds. The *range* keyword can do it (*range* min_value max_value).
 - Run the configuration menu and change the default value (for example 1.2 sec.)
 - Modify the 2 lines of the code where the usleep() function is called.
 - Run the program and verify.

4.1.4 Default configuration

If you don't want to specify a full *sdkconfig* configuration, it is possible to override some key values from the ESP-IDF default configuration. So you can create a file *sdkconfig.defaults* in the project root directory (Web help). The syntax is the same as the *sdkconfig* file.

- 1. Create a *sdkconfig.defaults* file in Visual Studio Code.
- 2. We will define by default the size of the flash memory (4MiB) which will avoid the warning that we saw in section 4.1.2. Add these lines in the file:

```
# ESP32 with 4MB flash size
CONFIG_ESPTOOLPY_FLASHSIZE_4MB=y
CONFIG_ESPTOOLPY_FLASHSIZE="4MB"
```

- 3. Delete the sdkconfig file.
- 4. Run the configuration menu to verify the new default size of the flash.
- 5. Build the project
 - Verify the sdkconfig file
 - Run and verify if the warning is not present.
- 6. Add a default custom configuration for user parameters.
 - CUSTOM FUNCTIONS : true
 - UPDATE DELAY: 1.5 second
 - INFORMATION TITLE : =- Informations -=
 - RANDOM VALUE : ONLY RANDOM
- 7. Delete the sdkconfig file.
- 8. Run the configuration menu to verify the new default parameters.
- 9. Run the program and verify.

4.2 IDF Components (Lab4-2)

The sensors.h and sensors.c files could be put in library in order to have a more reusable code structuring. So, we are going to create a IDF component (Web help). Indeed, it is recommended grouping most developments into components instead of putting them all in main directory.

For this we are going to create a new lab « lab4-2 idf components ».

4.2.1 Create the Lab

1. Duplicate the « lab4-1_menuconfig » folder to « lab4-2_idf_components »

```
esp32:~/../part1_iot_framework$ cp -r lab4-1_menuconfig lab4-2_idf_components
esp32:~/../part1_iot_framework$ cd lab4-2_idf_components
esp32:~/../part1_iot_framework/lab4-2_idf_components$ idf.py fullclean
esp32:~/../part1_iot_framework/lab4-2_idf_components$ code .
```

4.2.2 Create the IDF Component

We are going to create a sensorsManagement component which contains sensor.h and sensor.c files.

- 1. Create a components folder.
- 2. In this folder, create a sensorsManagement folder that corresponds to sensorsManagement component.
- 3. Move sensor.c files to sensorsManagement folder.
- 4. In the sensorsManagement folder, create a include folder.
- 5. Move sensor.h files to sensorsManagement folder.
- 6. We need to configure the component using the *CMakeLists.txt* and *component.mk* files. Theses 2 files may contain variable definitions to control the build process of the component.
 - CMakeLists.txt file is used for CMake (Web help).
 - component.mk file is used for Make (Web help). The minimal component.mk file is an empty file!
 - Copy the « lab4-2_CMakeLists.txt » provided file to sensorsManagement folder. Do not forget to rename it to « CMakeLists.txt »).
 - Copy also the «lab4-2_component.mk» provided file to sensorsManagement folder. Do not forget to rename it to «component.mk»).
- 7. Explain the content of the *CMakeLists.txt* file (Web help).
- 8. Build and run the program.

4.2.3 Customizing menu configuration for the IDF Component

In the *main* folder, we have added a *Kconfig.projbuild* file to configure the program. In the case of an IDF component, the file is called *Kconfig*.

- 1. Create a blank *Kconfig* file in the *sensors Management* component.
- 2. We will create 2 parameters, TEMP_SENSOR_NAME (default value = "TEMPE-RATURE") and PRES_SENSOR_NAME (default value = "PRESSURE") which will be the default value of the *name* fields of the *defaultSensorSet* static variable defined in *sensors.c* file. The name of the configuration menu will call "sensors Management".
 - Write the code in the *Kconfig* file.
 - Modify the *sensors.c* file in order to use these 2 parameters.
- 3. Run configuration menu and change the default value of the 2 parameters located in the *components* directory.

esp32:~/../part1_iot_framework/lab4-2_idf_components\$ idf.py menuconfig

4. Run the program and check display.

Part II IoT Architecture

ESP32 Architecture

Lab Objectives

- How to detect the configuration of the ESP32 architecture.
- Understanding of the role of different memories.
- Programming a simple component : GPIO (General Purpose Input/Output).
- Understanding the interrupts.

1.1 Architecture (Lab1-1)

We will focus on the various components of the ESP32 architecture and their configuration. Each component can be configured using the configuration menu that we studied previously (cf. section 4.1). We can access this information from functions provided by ESP-IDF that we will discover in this Lab.

1.1.1 Create the Lab

We will create the « part2_architecture » folder, then create the « lab1-1_architecture » lab and run Visual Studio Code as below :

1. Create the lab.

```
esp32:~$ cd ~/labs
esp32:~/labs$ mkdir part2_architecture
esp32:~/labs$ cd part2_architecture
esp32:~/../part2_architecture$ git clone https://github.com/fmuller-pns/esp32
    -vscode-project-template.git
esp32:~/../part2_architecture$ mv esp32-vscode-project-template lab1-1
    _architecture
esp32:~/../part2_architecture$ cd lab1-1_architecture
```

```
esp32:~/../part2_architecture/lab1-1_architecture$ rm -fR .git
esp32:~/../part2_architecture/lab1-1_architecture$ code .
```

2. Overwrite the « main.c » file by the provided code of the « lab1-1_main.c » file.

1.1.2 Understanding the program

- 1. Run the program.
- 2. Answer the following questions:
 - What is the CPU clock and its current frequency? See in provided Documentation/ ESP32/ESP32_datasheet.pdf, search CPU Clock"
 - What is the number of CPU cores?
 - What is the name of CPU cores? Web help
 - What is the APB (Advanced Peripheral Bus) clock and its current frequency? Web help
 - What is the XTAL clock frequency?
 - What is the RTC (Real-Time Clock) and its current frequency? Web help
- 3. Study the fields of the $esp_chip_info_t$ structure. (To help you, put the cursor on the name of the structure and press F12)

4. Study the $spi_flash_get_chip_size()$ function. Go to $esp_spi_flash.h$ file to find out information

- 5. Complete the program to print Flash memory information (external/internal and size), Wifi and Bluetooth (Classic/LE) using $esp_chip_info_t$ structure and spi flash get chip size() function.
- 6. Run the program and verify the information. What is the size of the flash memory?
- 7. The ESP32-PICO-D4 board embeds 4MiB flash memory. Change the value as specify in section 4.1.2.
- 8. Run the program and verify the flash memory size.
- 9. Complete the program to print MAC (Media Access Control) address from the $esp_efuse_mac_get_default()$ function. Go to $esp_system.h$ file to find out information. We want to display the address in this format: XX-XX-XX-XX-XX, X represents a hexadecimal number (for example, MAC address can be: d8-a0-1d-5c-c9-10). To print hexadecimal number, watch the example below (Web help):

```
int a = 0x45;
printf(" Print a = %02x\n", a); // Result: Print a = 45
```

- 10. Run the program. What is the MAC address?
- 11. Complete the program to known if the OCD Debug mode is active from the $esp_cpu_in_ocd_debug_mode()$ function. Go to cpu.h file.
- 12. Run the program without connecting the JTAG and after trying to connect the JTAG and run again the program.

1.2 System Time (Lab1-2)

It is generally important in an IoT architecture to have a time reference. This system time is implemented from an Real-Time Clock (RTC). This time system will make it possible to tag a sensor measurement, to measure a time or a latency, to trigger a measurement or quite simply to obtain the time. Moreover, we had already studied the usleep() function which allows to wait for a certain duration. Note that this card does not keep the current time

when it is off. We will see later how to update the time from an internet connection. First, we create a new lab:

- 1. Create the «lab1-2_rtc» lab, change memory flash size (4MiB) and run Visual Studio Code.
- 2. Overwrite the « main.c » file by the provided code of the « lab1-2-1 main.c » file.

1.2.1 System time - gettimeofday() function

The first solution is to use the *gettimeofday()* function.

- 1. Answer the following questions:
 - What is the gettimeofday() function and the timeval structure? Web help

- What is the *ets_delay_us()* function? (To help you, put the cursor on the name of the function and press *F12*)
- 2. What does the value 197130 of tv sec field correspond to?
- 3. Display tv_n times (n=1,2,3 and 4), i.e. tv_sec and tv_usec fields. Also display $tv_{n+1} tv_n$ time differences. Note that to display a long type, use the %ld specifier. Web help long a = 123456789; printf(" Print a = %ld\n", a); // Result: Print a = 123456789
- 4. Run the program. Record the different times and interpret the results.

1.2.2 System time - <time.h> library

You can also use the standard *time.h* library.

1. Insert (do not overwrite!) at the end of the *app_main* function the provided code of the « lab1-2-2 code.c » file.

- 2. Answer the following questions:
 - Study the time(), $localtime_r()$, mktime() functions and the tm structure Webhelp, also press F12 on the name to obtain help in Visual Studio Code.

- What is the *strftime()* function? Web help
- 3. Run the program and interpret the results.

1.2.3 Application - CPU Frequency and performance

We want to check the influence of the processor frequency on a piece of code below.

```
// Code to evaluate
volatile uint64_t i;
for (i=0; i<5000000; i++) {
}</pre>
```

- 1. What does the keyword *volatile* mean? Web help
- 2. Evaluate the performance in time (in μs) of this piece of code according to the frequencies of the CPU (Freq = 80MHz, 160Mhz, 240Mhz).
 - Help you from *gettimeofday()* function.
 - Change the frequency using the configuration menu, cf. section 4.1.2 (menu: config Component config/ESP32-Specific).

Write the frequency and time found.

3. Interpret the result, Time = F(Freq).

Memory

Lab Objectives

- Utility of a memory mapping.
- Understanding the role of different memories.
- Understanding where the instructions and data are stored.
- Correctly manage the stack.

2.1 Flash & SRAM Memories (Lab2-1)

The figure 2.1 illustrates the interesting memories. The complete document is in Documentation/ESP32/ESP32_datasheet.pdf, chapter « Functional Description ».

The Flash memory is an external memory which stores permanent data (write and read access). A data can be a program (instructions) or a data (variables, arrays ...). The size depends on the board. The ESP32-PICO-D4 board embeds 4MiB flash memory as we saw previously.

The ESP32 SRAM (Static Random Access Memory) is an internal memory (on-chip SRAM) which stores volatile data (write and read access) and instructions, i.e. when you power off the board, the data is no longer present in the SRAM. This size is 520 KiB.

We have 8 KiB of RTC FAST SRAM (can be used for data storage) and 8 KiB of RTC SLOW SRAM (can be accessed by the co-processor during the Deep-sleep mode). We will see these memories later.

First, we create a new lab:

1. Create the «lab2-1 iram dram» lab from «esp32-vscode-project-template» GitHub

Category	Target	Start Address	End Address	Size
Embedded Memory	Internal ROM 0	0x4000_0000	0x4005_FFFF	384 KB
	Internal ROM 1	0x3FF9_0000	0x3FF9_FFFF	64 KB
	Internal SRAM 0	0x4007_0000	0x4009_FFFF	192 KB
	Internal SRAM 1	0x3FFE_0000	0x3FFF_FFFF	- 128 KB
		0x400A_0000	0x400B_FFFF	
	Internal SRAM 2	0x3FFA_E000	0x3FFD_FFFF	200 KB
	RTC FAST Memory	0x3FF8_0000	0x3FF8_1FFF	8 KB
		0x400C_0000	0x400C_1FFF	
	RTC SLOW Memory	0x5000_0000	0x5000_1FFF	8 KB
External Memory	External Flash	0x3F40_0000	0x3F7F_FFFF	4 MB
		0x400C_2000	0x40BF_FFFF	11 MB+248 KB
	External RAM	0x3F80_0000	0x3FBF_FFFF	4 MB

FIGURE $2.1 - Mapping \ table$.

repository, change memory flash size (4MiB for ESP32-PICO-D4 board) and run Visual Studio Code.

- 2. Overwrite the « main.c » file by the provided code of the « lab2-1_main.c » file.
- 3. Answer the following questions:
 - What does the heap_caps_get_free_size() function return with a MAL-LOC_CAP_EXEC, MALLOC_CAP_8BIT and MALLOC_CAP_32BIT argument? (To help you, put the cursor on the name of the function and press F12) and Web help

- What does heap_caps_get_largest_free_block() function return?
- 4. Run the program and extract these lines to your console. The values are not necessarily identical.

```
I (0) cpu_start: App cpu up.
I (235) heap_init: Initializing. RAM available for dynamic allocation:
I (242) heap_init: At 3FFAE6E0 len 00001920 (6 KiB): DRAM
I (248) heap_init: At 3FFB30E8 len 0002CF18 (179 KiB): DRAM
I (254) heap_init: At 3FFE0440 len 00003AE0 (14 KiB): D/IRAM
I (261) heap_init: At 3FFE4350 len 0001BCB0 (111 KiB): D/IRAM
I (267) heap_init: At 400899F4 len 0001660C (89 KiB): IRAM
...
DRAM run executable code = 220464 Bytes (215 KiB)
```

```
DRAM run executable code 32 bit = 389552 Bytes (380 KiB)
IRAM = 91624 bytes (89 KiB)
DRAM (Total) = 297928 Bytes (290 KiB)
DRAM Free Heap Size : 297928 Bytes (290 KiB)
DRAM (Largest free block) = 169088 Bytes (165 KiB)
```

5. What is an IRAM and DRAM? Web help

6. Find the values that we have displayed (except the line « DRAM run executable code 32 bit ») in the program according to the lines starting with « heap_init : » and which are displayed by the kernel. For example, the line « IRAM = 91624 bytes (89 KiB) » corresponds to the line « heap_init : At 400899F4 len 0001660C (89 KiB) : IRAM ».

7. Create an Excel Sheet (in your project folder) with 3 columns: Memory, Size (Byte), Size (KiB) as shown in figure 2.2.

	Α	В	С
1		Size (Byte)	Size (KiB)
2	IRAM		
3	DRAM		
4			
5	Used static DRAM		
6	Used static IRAM		
7			
8	CPU Cache		
9	reserved		
10	padding		
11			
12	TOTAL	0	0
13			

FIGURE 2.2 – Memory size.

8. Complete the 2 values for « IRAM » and « DRAM (Total) ».

9. Each core has 32KiB cache memory, so we have 64KiB reserved for cache. Add this information in the « CPU Cache » line.

10. Set « Reserved » line is 8KiB.

2.2 The sections

The program is divided into sections. Each section contains a part of the program. We will study the main sections of a program.

2.2.1 The main sections

1. Summarizes the use of the following 3 sections: .bss, .data and .rodata. Web help

2. Run this command below.

esp32:~/../part2_architecture/lab2-1_iram_dram\$ idf.py size

3. The Used static DRAM and IRAM is the size of the program after compilation (static keyword), respectively for the Data section and Instructions section. Add these values in the Excel sheet. What is the total size?

- 4. Complete the padding line to obtain the 520KiB (SRAM memory size). Now it is right!
- 5. Run this new command below. What is the result?

esp32:~/../part2_architecture/lab2-1_iram_dram\$ idf.py size-files

6. identify the name of each columns.

7. To filter the code of the main.c file, run this command below.

```
esp32:~/../part2_architecture/lab2-1_iram_dram$ idf.py size-files | grep " main\|Total"
```

- 8. What is the size of .data and .bss section for DRAM?
- 9. Add 2 variables before the app_main() function.

```
uint32_t value = 12;
uint8_t table[1000];
void app_main(void) {
```

10. Run again the command below. What is the result? Why?

```
esp32:~/../part2_architecture/lab2-1_iram_dram$ idf.py size-files | grep main
```

- 11. Initialize the *table* with the *value* variable. Run again the command. What is the result? Why?
- 12. Move the *value* and *table* variables inside the $app_main()$ function. Run again the command below. What is the result? Why?

2.2.2 The stack section

The stack section is a section which is used to save local data declared in a function or a task, to save the return addresses during a function call or to save the context of an interrupt. The size reserved for the stack is therefore very large so as not to overflow. We are going to take an interest in this issue.

- 1. What does uxTaskGetStackHighWaterMark() function return?
- 2. Add these 2 lines at the end of the app main() function.

```
int stackmem = uxTaskGetStackHighWaterMark(NULL);
printf("Stack space (app_main task) = %d Bytes (%.2f KiB)\n",
    stackmem, ((float)stackmem/1024.0));
char buffer [5000];
```

- 3. Run the program and get the size of the stack.
- 4. In which section is the buffer declared?
- 5. Add this line to use the buffer. What does this memset() function do?

```
memset(&buffer,1,sizeof(buffer));
printf("End of initialisation\n");
```

- 6. Run the program. What is the problem?
- 7. Suggest 2 solutions to solve the problem.

2.2.3 Exercise: where are the strings?

When using the printf() function, we usually define the string within the function as below:

```
printf("Hello!\n");
```

In order to display the size of the string, we will write the code in this way at the end of app_main function:

```
char *mess = "Hello, where are the string?, length = %d\n";
printf(mess, strlen(mess));
```

We want to know in which section the strings are located.

- 1. Run the program. What is the length of the string?
- 2. Run the command below and note the section values (in Bytes).

```
esp32:~/../part2_architecture/lab2-1_iram_dram$ idf.py size-files | grep "
main\|Total"
```

- 3. Delete the start of the string: "Hello, ".
- 4. Run again the program. What is the new length of the string?
- 5. Find out the new section values (in Bytes).
- 6. In which section the strings are located? Justify.
- 7. Declare constant the mess variable.
- 8. In which section the string are located? Justify.

```
const char *mess = ...
```

9. What is the conclusion?

2.3 Flash Memory - Custom partition table (Lab2-2)

The objective is to learn how to customize the partition table for next labs. Indeed, a flash memory for ESP32 can contain multiple apps, as well as many different kinds of data: calibration data, file-systems, parameter storage, OTA app, etc.

First, we create a new lab:

1. Create the new « lab2-2_partitions » lab from « esp32-vscode-project-template » GitHub repository, change memory flash size (4MiB) and run Visual Studio Code.

2. Build the program.

```
esp32:~/../part2_architecture/lab2-2_partitions$ idf.py build
```

2.3.1 Customizing the partition table

The goal is to understand how to configure a partition table.

- 1. The partition-table.bin file (located at ./build/partition_table contains the partition table but in a binary format. To generate a readable format, Python scripts exist in the component « partition_table » located in ~/esp/esp-idf/components/partition_table.
 - Open a new terminal.
 - Go to the directory and list it.

```
esp32:~/../part2_architecture/lab1-2_partitions$ cd ~/esp/esp-idf/
    components/partition_table
esp32:~/../components/partition_table$ 11
```

In this directory, you have a gen_esp32part.py script to generate a CSV (Comma-separated values) format. You can open it with Visual Code Studio and Excel/Sheet. You have also a partitions_singleapp.csv file which is a template for customize the partition table. However, another solution is to generate the CSV file from the built project.

2. Check if the partition-table.bin file exists.

```
esp32:~/../part2_architecture/lab2-2_partitions$ 11    build/partition_table
```

3. Generate the partition table (CSV format) from the built project:

```
esp32:~/../part2_architecture/lab2-2_partitions$ gen_esp32part.py build/
partition_table/partition-table.bin my_partitions.csv
```

- 4. Open the *my_partitions.csv* file from Visual Studio Code. You have (SubType column):
 - data, nvs: Non Volatile Storage (NVS) will see later. For example, it is used to store per-device PHY calibration data, to store WiFi data, etc.
 - data, phy: for storing PHY initialisation data. By default, PHY initialisation data is compiled into the app itself.
 - app, factory: it is the default app partition (type app). The partition of app type have to be placed at offsets aligned to 0x10000 (64Ki).

More documentation can be found here.

- 5. You must now specify the custom partition table in the configuration.
 - Run menuconfig

```
esp32:~/../part2_architecture/lab2-2_partitions$ idf.py menuconfig
```

• Go to Partition Table menu

- Go to Partition Table (...)
- Go to Custom partition table CSV
- Go to Custom partition CSV file and change the filename : my_partitions.csv
- Save and Exit
- 6. Verify the generated sdkconfig file. Search these lines:

```
CONFIG_PARTITION_TABLE_CUSTOM=y
CONFIG_PARTITION_TABLE_CUSTOM_FILENAME="my_partitions.csv"
CONFIG_PARTITION_TABLE_FILENAME="my_partitions.csv"
```

7. Build the project to check if there is no error.

2.3.2 Partition table with Over-The-Air (OTA)

The goal is to generate a partition table to use the OTA feature (OTA documentation). The OTA update mechanism allows a device to update itself based on data received while the normal firmware is running (for example, over WiFi or Bluetooth). This will be studied in a future lab.

- 1. You must now specify the custom partition table in the configuration.
 - Run menuconfig

```
esp32:~/../part2_architecture/lab2-2_partitions$ idf.py menuconfig
```

- Go to Partition Table menu
- Go to Partition Table (...)
- Go to Factory app, two OTA definitions
- Save and Exit
- 2. Build the project. What is the problem? Correct it.
- 3. Generate the partition table (CSV file): my partitions ota.csv

```
esp32:~/../part2_architecture/lab2-2_partitions$ gen_esp32part.py build/
partition_table/partition-table.bin my_partitions_ota.csv
```

- 4. Open the $my_partitions_ota.csv$ file from Visual Studio Code. You have another lines (SubType column):
 - ota, data: the OTA data partition specifies which OTA app slot partition should be booted next.
 - ota 0,app : OTA slot 0, version X of the program
 - ota 1,app : OTA slot 1, version Y of the program
- 5. You must now specify the new custom OTA partition table in the configuration.
 - Run menuconfig
 esp32:~/../part2_architecture/lab1-2_partitions\$ idf.py menuconfig
 - Go to Partition Table menu

- Go to Partition Table (...)
- Go to Custom partition table CSV
- Go to Custom partition CSV file and change the filename : my_partitions_ota.csv
- Save and Exit
- 6. Verify the generated sdkconfig file. Search these lines:

```
CONFIG_PARTITION_TABLE_CUSTOM=y
CONFIG_PARTITION_TABLE_CUSTOM_FILENAME="my_partitions_ota.csv"
CONFIG_PARTITION_TABLE_FILENAME="my_partitions_ota.csv"
```

7. Build the project to check if there is no error.

Now we are able to specify our own partition table for next labs!

2.3.3 Quiz

- 1. What is the use of a partition table? For what memory?
- 2. What elements are specified in this partition table file?
- 3. What is the partition table file format?
- 4. Where do we specify the partition table file? In what way?
- 5. What does OTA mean? What is it used for?

2.4 Storing files directly in flash memory (Lab2-3)

Sometimes you have a file with some binary or text data that you would like to reference to your program. It is precisely possible to store data from files which are referenced by variables in our program directly in flash memory. These data are generally read-only data (images, html documents, default configuration, etc.).

In this lab, we will store binary and text files in the flash memory and display them from within the program.

First, we create a new lab:

1. Create the « lab2-3_files_directly_in_flash » lab, change memory flash size (4MiB) and run Visual Studio Code.

- 2. Copy provided *files* folder to the *main* folder of your new lab.
- 3. Overwrite the « main.c » file by the provided code of the « lab2-3 main.c » file.
- 1. Build the program.
- 2. What is the problem?
- 3. To solve it, first of all, it is necessary to add the variable *EMBED_TXTFILES* or *EMBED_FILES* in the main/CMakeList.txt file (more documentation) as below:

```
idf_component_register(
    SRC_DIRS "."
    INCLUDE_DIRS "."
    EMBED_TXTFILES "files/index.html" "files/note.txt"
    EMBED_FILES "files/polytech.png"
)
```

4. If the project will become a component, it is recommended to reference file in the main/component.mk file as below:

```
COMPONENT_EMBED_TXTFILES := files/index.html
COMPONENT_EMBED_TXTFILES += files/note.txt
COMPONENT_EMBED_FILES := files/polytech.png
```

- 5. What is the difference between *EMBED_TXTFILES* or *EMBED_FILES* ((documentation for help))?
- 6. Build the program.
- 7. What is the first character of the *note.txt* file? What is the length of the file?
- 8. Open the *note.txt.S* assembler file located in *build* folder. Explain the link between the declaration in the *main.c* file and the *note.txt.S* file by helping you from the previous question.

To use a file referenced in flash memory, you must declare in the program a variable. From the (documentation) and main.c file, answer the following questions

- 1. What is the type of declaration for a variable in the program?
- 2. How do you define the start, end and length symbol name of a file in assembler (directive asm())?

3. In which section are the variables declared?

4. Run the program.

Now, we would like to create a new text file which contents my identity.

- 1. Create a text file (« my_identity.txt »).
- 2. Edit the file and add your identity.
- 3. Add code at the end of the app main function to display the identity.
- 4. Test your program.

2.5 Non Volatile Storage memory (Lab2-4)

The figure 2.3 illustrates the steps for using Non Volatile Storage (NVS).

- Initialize flash memory.
- Open a namespace and get a storage handle. The default NVS partition is the one that is labeled « nvs » in the partition table.
- Read and Write values.
- Commit to ensure writing any pending changes to non-volatile storage.
- Close the storage handle and free any allocated resources.

2.5.1 First step with the NVS memory (Lab2-4-1)

1. Create the « lab2-4-1_nvs » lab from « esp32-vscode-project-template » GitHub repository, change memory flash size (4MiB for ESP32-PICO-D4 board) and run Visual Studio Code.




FIGURE 2.3 – Non Volatile Storage programming steps.

- 2. Overwrite the « main.c » file by the provided code of the « lab2-4-1 _ main.c » file.
- 3. Add comments in the *app_main* function to find the different steps.
- 4. Build the program.
- 5. Before running the program, we will make sure the *nvs* partition is blank. Thus, we will add a directive (*erase flash*) to the usually used command.

```
esp32:~/../part2_architecture/lab2-4-1_nvs$ idf.py -p /dev/ttyUSB0
erase_flash flash monitor
```

- 6. What is the message info?
- 7. Push the reset button. What is the new message info?
- 8. It is possible to modify the code without erasing values.
 - Add a message at the start of the app main() function, using the printf() function.
 - Run the program with usually command.
 esp32:~/../part2_architecture/lab2-4-1_nvs\$ idf.py -p /dev/ttyUSB0 flash monitor
 - What is the message info?
 - Push the reset button. What is the new message info and the value? Conclusion?

It is also possible to erase all contents of the default NVS partition labeled « nvs » from the $nvs_flash_erase()$ function. You also can just erase one partition from the $nvs_flash_erase_partition()$ function.

2.5.2 Customizing the NVS memory partition (Lab2-4-2)

In the previous section 2.5.1, we used the default « nvs » partition to write simple values. In this lab, we will learn how to use our own « nvs » partition using the partition table that we are going to modify. This will allow us to have more flexibility in terms of the memory size of our partition.

- 1. Duplicate the « lab2-4-1 _nvs » folder to « lab2-4-2 _custom _nvs ».
- 2. Generate the partition table (CSV format) from the built project as we did in a previous lab (cf. section 2.3.1).

```
esp32:~/../part2_architecture/lab1-2_partitions$ gen_esp32part.py build/
partition_table/partition-table.bin my_partitions.csv
```

- 3. Open the $my_partitions.csv$ file. What is the size in KiB of the default « nvs » partition?
- 4. Declare at the end of the $my_partitions.csv$ file a new partition named « my_nvs » (type: data, subtype: nvs) with a size of 1MiB. Do not specify offset and flag.
- 5. Reference the my_partitions.csv file in sdkconfig file from the menuconfig command. Refer to section 2.3.1 if necessary.
- 6. We need to initialize our own partition « my_nvs » and open it. It is necessary to modify the functions of the first 2 steps of the previous lab.
 - Study the following 2 functions: $nvs_flash_init_partition()$ and $nvs_open_from_partition()$. What is the difference compared to the functions of the previous lab?
 - Modify the code in the $app_main()$ function. You can declare a const value for the partitino name as below:

```
const char *MY_NVS = "my_nvs";
```

7. Run the program.

2.5.3 Statistics for NVS

We want to get statistics on partitions.

1. Add the following code at the end of the function:

```
nvs_stats_t nvsStats;
nvs_get_stats(MY_NVS,&nvsStats);
```

- 2. Study the fields of the nvs stats t structure.
- 3. What is a namespace? Web help
- 4. What is the name of the namespace in our code?
- 5. Add code to print the information.
- 6. Run the program and comment on the values.
- 7. Modify the name of the namespace « my storage », for example « my storage 2 ».
- 8. Run the program and comment on the values.

2.5.4 Exercise - Storing complex structure in the NVS

We will take the Lab Refactoring code of the Working with C and IDF framework in the IoT Framework in order to store in the flash memory the last values of the SensorSetStruct structure.

- 1. Duplicate the « lab3-3-1_c_header_files » (cf. Refactoring code) folder to « lab2-4-3_complex_data_nvs ».
- 2. Generate the partition table (CSV format) from the built project as we did in a previous lab (cf. section 2.3.1).
- 3. Declare a new partition named « my_nvs » with a size of 2MiB in the my partitions.csv file and reference it in sdkconfig file (use menuconfig).

- 4. Answer the following questions::
 - how to use the $nvs_get_blob()$ and $nvs_set_blob()$ functions? Web help
 - What is a key parameter in these functions? Web help
 - What is the maximum length of the key parameter? Web help
- 5. Use the $app_main()$ function from the previous lab (i.e. Customizing the NVS memory partition (Lab2-4-2)) and adapt the $app_main()$ function to store the defaultSensorSet variable instead of the value variable.
- 6. Run the program and verify.

2.6 SPI Flash File System (Lab2-5)

We studied in a previous lab (cf. Storing files directly in flash memory (Lab2-3)) the possibility of adding files directly to flash memory via variables. We will use another solution to access files through the SPI Flash File System (SPIFFS). This solution can store a full directory into SPI Flash memory.

2.6.1 Flash SPIFFS with code

- 1. Create the «lab2-5-1_spiffs » lab from «esp32-vscode-project-template » GitHub repository, change memory flash size (4MiB for ESP32-PICO-D4 board) and run Visual Studio Code.
- 2. Overwrite the « main.c » file by the provided code of the « lab2-5-1 main.c » file.
- 3. Copy the *spiffs dir* folder to the *main* folder.
- 4. Answer the following questions:
 - What does the *spiffs_dir* folder contain?
 - Study the following 3 functions: fopen(), fgets(), fclose() used in the readFile() function. (To help you, put the cursor on the name of the function and press F12) and Web help

- Study the fields of the $esp_vfs_spiffs_conf_t$ structure. (To help you, put the cursor on the name of the function and press F12) and Web help
- Study the $esp_vfs_spiffs_register()/esp_vfs_spiffs_unregister()$ functions. Web help
- What does the $esp_spiffs_info()$ function do? Web help
- Study the following 3 functions: opendir(), readdir(), stat() used in the app_main() function. Web help

- 5. Study the behavior of the readFile() function by adding comments in the code.
- 6. Study the behavior of the $app_main()$ function by adding comments in the code.
- 7. Build the project and run it. What is the error?
- 8. Generate the partition table (CSV format) from the built project as we did in a previous lab (cf. section 2.3.1).

```
esp32:~/../part2_architecture/lab2-5-1_spiffs$ gen_esp32part.py build/
partition_table/partition-table.bin my_partitions.csv
```

9. Open the $my_partitions.csv$ file. and declare at the end of the $my_partitions.csv$ file a new partition named « $my_storage$ » (type : data, subtype : spiffs) with a size of 1MiB. Do not specify offset and flag.

10. Reference the $my_partitions.csv$ file in sdkconfig file from the menuconfig command. Refer to section 2.3.1 if necessary.

11. The easiest is to invoke *spiffsgen.py* (generation of the *spiffs_dir.bin*) file directly from the build system by calling *spiffs_create_partition_image()* function in the *CMake* file located in *main* folder (more information.

```
spiffs_create_partition_image(my_storage ../spiffs_dir
FLASH_IN_PROJECT)
```

12. Run the program and comment on the console display.

2.6.2 Updating only SPIFFS partition

It is possible to update a spiffs partition without flashing the code. In this section, we will change the content of a file without flashing the program code but just flashing the my storage partition.

- 1. Change the text of the *note.txt* file located in the spiffs_dir/doc folder.
- 2. The first step is to generate the *spiffs dir.bin*) file as below:

```
esp32:~/../part2_architecture/lab2-5-1_spiffs$ $IDF_PATH/components/spiffs/
spiffsgen.py 0x100000 spiffs_dir spiffs_dir.bin
```

3. To ensure that the value of the offset for the $my_storage$ partition, launch the command below. What is the offset of $my_storage$ partition?

```
esp32:~/../part2_architecture/lab2-5-1_spiffs$ gen_esp32part.py build/
partition_table/partition-table.bin
```

4. Now, we can flash the partition as below after replacing the OFF- $SET\ MY\ STORAGE$ by the offset of $my_storage$ partition:

```
esp32:~/../part2_architecture/lab2-5-1_spiffs$ $IDF_PATH/components/
esptool_py/esptool/esptool.py --chip esp32 --port /dev/ttyUSB0
write_flash -z OFFSET_MY_STORAGE spiffs_dir.bin
```

5. Just display now the console without flashing the code!

```
esp32:~/../part2_architecture/lab2-5-1_spiffs$ idf.py monitor
```

6. What do you remark?

2.6.3 Exercise - SPIFFS partition

- 1. Append to the end of the app_main function the reading of the index.html file.
- 2. Build and run the program.

2.6.4 Analyze a full example

- 1. Copy "spiffs" folder located in \$IDF_PATH/examples/storage to a new lab « lab2-5-2_spiffs-full-example » without opening Visual Studio Code.
- 2. Copy .vscode folder of the previous project (lab2-5-1_spiffs)
- 3. Open Visual Studio Code.
- 4. Change flash size to 4MiB with menuconfig.
- 5. Examine the code.
- 6. Run the program.

.

General Purpose Input/Output (GPIO)

Lab Objectives

• Understanding of GPIO as output and input.

3.1 GPIO Output (Lab3-1)

We want to blink a red LED every second. To do this, we will use the GPIO12 output. The figure 3.1 illustrates the schematic.




FIGURE 3.1 – Schematic for GPIO and Led.

- 1. We want a current of around 1mA. The $V_{ref} \approx 1.9V$ for the Led and the output voltage of the GPIO is $\approx 3.3V$, What is the nearest value of the standardized resistor to use?
- 2. What is the pin number of the ESP32-PICO-D4 for RTC_GPIO12 (cf. Appendix Pin description of ESP32-PICO-D4 board.)?

3. Create the «lab3-1_gpio_output » lab from «esp32-vscode-project-template » GitHub repository, change memory flash size (4MiB for ESP32-PICO-D4 board) and run Visual Studio Code.

- 4. Overwrite the « main.c » file by the provided code of the « lab3-1_main.c » file.
- 5. Answer the following questions:
 - Study the following function : $gpio_pad_select_gpio()$ from « gpio.h » file in Visual Studio Code.
 - Study the following function : $gpio_set_direction()$. What are the possible modes for the GPIO? Web help
 - Study the following function: gpio set level(). Web help
- 6. Perform the wiring on the board.
- 7. Run the program.

3.2 GPIO Input (Lab3-2)

We now want to blink the red led every second and if the push button is not pressed. The detection of the pressed button is also each second. If this is pressed, the led remains in the current state and we scan the push button continuously without waiting for a second. To do this, we are going to add a RTC_GPIO13 input which will make it possible to recover the state of the push button as shown in the figure 3.2. The pullup resistor is directly included in the GPIO pin.

- 1. Duplicate the « lab3-1_gpio_output » folder to « lab3-2_gpio_input » for the new lab.
- 2. What is the pin number of the ESP32-PICO-D4 for RTC_GPIO13 (cf. Appendix Pin description of ESP32-PICO-D4 board.)?
- 3. Study the following function: gpio pullup en(). Web help
- 4. Declare the PIN PUSH BUTTON constant.




FIGURE 3.2 – Schematic for GPIO, Led and push button.

- 5. Complete the code in the app main() function.
 - Before the infinite loop for initialization of the GPIO pin.
 - In the loop to take into account the new behavior with push button.
- 6. Perform the wiring on the board (cf. push button documentation in the Documentation/push_button_datasheet.pdf).
- 7. Run the program.

3.3 Advanced configuration for GPIO (Lab3-3)

We will study a more efficient solution to configure the GPIO by using a $gpio_config_t$ structure.

- 1. Duplicate the « lab3-2_gpio_input » folder to « lab3-3_advanced_gpio_cfg » for the new lab.
- 2. Study the fields of the *gpio config t* structure. Web help
- 3. Taking the example of the code below, modify the app_main function.

```
/* GPIO outputs */
gpio_config_t config_out;
config_out.intr_type = ???
config_out.mode = ???
config_out.pin_bit_mask = (1ULL << PIN_LED);
gpio_config(&config_out);

/* GPIO inputs */
gpio_config_t config_in;</pre>
```

```
config_in.intr_type = ???
config_in.mode = ???
config_in.pull_down_en = ??
config_in.pull_up_en = ??
config_in.pin_bit_mask = ??
gpio_config(&config_in);
```

4. Run the program.

3.4 Exercise - Display state of the push button

We want to display the state of the push button. To do this, we add a yellow led connected to the RTC_GPIO14 pin.

- 1. Duplicate the « lab3-3_advanced_gpio_cfg » folder to « lab3-4 exercise button state » for the new lab.
- 2. Adapt the code.
- 3. Run the program.

Interrupt with a General Purpose Input/Output (GPIO)

Lab Objectives

- Polling mode versus interrupt mode.
- Understanding the Watchdog.
- Understanding the principle of an interrupt.
- Programming an interrupt.

4.1 Polling and Interrupt mode

In order to show the advantages of interrupt mode compared to polling mode, we are going to code an application in both modes. We will count the number of times the push button is pressed and use the state of bit 0 of the counter as an indicator for displaying the yellow LED. This led should flash with each press. We use the push button connected to the RTC_GPIO13 input pin and the yellow led connected to the RTC_GPIO12 output pin as in the lab Advanced configuration for GPIO (Lab3-3).

4.2 Polling mode (Lab4-1)

- 1. Duplicate the lab Advanced configuration for GPIO (Lab3-3) to « lab4-1_gpio_polling_mode ».
- 2. Overwrite the « main.c » file by the provided code of the « lab4-1 main.c » file.
- 3. Complete the code, add comments to better understanding the app_main function.
 - When is the *count* variable incremented? Rising edge or falling edge of the push button? Why?

LAB 4 72

- What does the *pressNumber* variable represent?
- 4. Complete the program helping you
- 5. Build.
- 6. What is a watchdog? (Web help)
- 7. Run the program.
- 8. Is there a problem? Copy the first line of the error.
- 9. What is a task watchdog? (Web help)
- 10. The solution is to disable the Idle0 task watchdog. Change it from menuconfig. (Web help).
- 11. Open the sdkconfig file and check the «CONFIG_ESP_TASK_WDT_CHECK_IDLE_TASK_CPU0» parameters is right.
- 12. Run the and button until countis program press greater than 200. Is there new problem? Why?
- 13. How to correct the problem? Modify the code to correct the problem.
- 14. Run the program.

4.3 Interrupt mode with GPIO (Lab4-2)

1. Duplicate the lab « lab4-1_gpio_polling_mode » to « lab4-2_gpio_interrupt_mode ».

LAB 4 73

- 2. Overwrite the « main.c » file by the provided code of the « lab4-2 main.c » file.
- 3. Answer the following questions:
 - Study the following function : $gpio_install_isr_service()$. Web help
 - Study the following function : gpio_isr_handler_add(). Web help
 - What is the $IRAM_ATTR$ attribute on the $gpio_switch_isr_handler()$ function? why do we use this attribute? Web help

- Why count variable is volatile?
- Why use a tmpCount variable?
- 4. Open the *sdkconfig* file and check the «CONFIG_ESP_TASK_WDT_CHECK_IDLE_TASK_CPU0» parameters is always right.
- 5. Run the program and press button until *count* is greater than 200. Is there problems? Why?
 - First problem.
 - Second problem.
- 6. To solve one of the problem, we add a delay (100ms) at the beginning of the $gpio_switch_isr_handler()$ function. We also disable and enable interrupt to avoid re-entering in the interrupt function when it is not finished.

```
// disable the interrupt
gpio_intr_disable(PIN_PUSH_BUTTON);
// Waiting for signal is 1 again
do {
```

LAB 4 74

```
ets_delay_us(1000);
} while(gpio_get_level(PIN_PUSH_BUTTON) == 1);

// Previous code
int pinLedNumber = (int)args;
count++;
gpio_set_level(pinLedNumber, (count % 2));

// re-enable the interrupt
gpio_intr_enable(PIN_PUSH_BUTTON);
```

- 7. Run the program. Now there is only one problem.
- 8. The solution is to disable the interrupt watchdog. Change it from menuconfig. (Web help).
- 9. Open the sdkconfig file and check the « CONFIG ESP INT WDT » parameters is right.
- 10. Run the program. No more errors.
- 11. It is possible to use a sdkconfig.defaults in the lab Default configuration as below.
- 12. Copy the provided « sdkconfig.defaults » file to the project.

```
# ESP32 with 4MB flash size
CONFIG_ESPTOOLPY_FLASHSIZE_4MB=y
CONFIG_ESPTOOLPY_FLASHSIZE="4MB"

# Disabled watchdog for interrupt and task
CONFIG_ESP_TASK_WDT_CHECK_IDLE_TASK_CPU0=n
CONFIG_ESP_INT_WDT=n
```

- 13. Delete the *sdkconfig* file (old config).
- 14. Build and run the program. The new *sdkconfig* file is generated taking into account default parameters.

Part III FreeRTOS

Task & Scheduling

Lab Objectives

- Creating, suspending and deleting a task.
- Understanding the scheduling of tasks and priority effect.
- Multi-cores scheduling
- Using Idle task.
- Task handler

1.1 Task scheduling on one core (Lab1-1)

The entry point of an application is the $app_main()$ function. This function is actually a task of priority 1. We will usually create the other application tasks from the $app_main()$ task. We will create an application with 2 tasks (including $app_main()$ task), then 3 tasks running on 1 core in order to understand the behavior of the scheduler.

1.1.1 Preparation

Answer the following questions:

• Study the parameters of the following function : xTaskCreate() and vTaskDelete(). Web help

- Study the following function : uxTaskPriorityGet(). Web help
- Study the following function : vTaskDelay(). Web help
- What do they do the following macros in the provided « my_helper_fct.h » file? DISPLAY() and DISPLAYB().
- Task 1 is an instance of the vTaskFunction() in the provided code of the « lab1-1 main.c » file. Is that true?
- Open the provided « lab1-1_sdkconfig.defaults » file. What does the CONFIG FREERTOS UNICORE parameter correspond to? Web help
- What is the tick period in ms? see the CONFIG_FREERTOS_HZ parameter and Web help

1.1.2 Understanding the task scheduling

- 1. Create the « lab1-1_1_core_sched » lab from « esp32-vscode-project-template » GitHub repository.
- 2. Overwrite the « main.c » file by the provided code of the « lab1-1_main.c » file.
- 3. Copy the provided « my_helper_fct.h » file to the « main » folder.
- 4. Copy the provided « lab1-1_sdkconfig.defaults » file to the project folder and rename « sdkconfig.defaults ».
- 5. Build and run the program.
- 6. Trace in the figure 1.1 the behavior of the $app_main()$ and $Task\ 1$ tasks until 160 ticks.
- 7. Why the app main() task does not run?

8. Create a new instance $Task\ 2$ of the vTaskFunction() with the same priority of $Task\ 1$, i.e. priority=5.




FIGURE 1.2 – Scheduling of 3 tasks.

- 9. Run the program. Comment on the behavior.
- 10. We are now going to suspend the scheduler with 2 functions when creating the tasks.

```
void app_main(void) {
    ...
  vTaskSuspendAll();
  // Task creation ...
    ...
  xTaskResumeAll();
    ...
```

- 11. Run the program.
- 12. For this scenario, trace in the figure 1.2 the behavior of the $app_main()$, $Task\ 1$ and $Task\ 2$ tasks until 160 ticks.
- 13. Comment on the behavior. Why the $app_main()$ task does not run?
- 14. Change the priority=6 for the Task 2. Run the program and comment on the behavior for this scenario.
- 15. We are now going to add delay on vTaskFunction() after the simulation of computation time.

```
void vTaskFunction(void *pvParameters) {
...
for (;; ) {
   DISPLAY("Run computation of %s", pcTaskName);

   /* Delay for simulating a computation */
   for (ul = 0; ul < mainDELAY_LOOP_COUNT; ul++){
   }

   // Add Delay of 300 ms
   DISPLAY("Delay of %s", pcTaskName);
   vTaskDelay(300 / portTICK_PERIOD_MS);
   ...</pre>
```

16. Trace in the figure 1.3 the behavior of the $app_main()$, $Task\ 1$ and $Task\ 2$ tasks until 160 ticks.

1.1.3 Using trace information

It is possible to get information about the tasks of the application using the vTaskList() function (Web help).

1. Copy the code provided in the «lab1-1_add_vtasklist.c» file to print trace information as below. Note that size of the buffer is approximately 40 bytes per task.

- 2. The 2 first parameters are compulsory to use the vTaskList() function. The last parameter is used to print the code id. We active the 3 parameters. 2 solutions:
 - Using the menuconfig command and go to Component config/FreeRTOS/Enable FreeRTOS trace facility, Enable FreeRTOS stats formatting functions and Enable display of xCoreID in vTaskList.
 - Add these lines below in the «sdkconfig.defaults» file (provided in lab1-1_config_trace_information.txt file) and delete the «sdkconfig» to take into account the modifications.

```
# Trace facility to extract trace information
CONFIG_FREERTOS_USE_TRACE_FACILITY=y
CONFIG_FREERTOS_USE_STATS_FORMATTING_FUNCTIONS=y
CONFIG_FREERTOS_VTASKLIST_INCLUDE_COREID=y
```

3. Run the program. Copy the trace information. The *stack* column is the amount of free stack space in bytes there has been since the task was created.




FIGURE 1.4 – Scheduling of 3 tasks with task delay.

- 4. How many tasks are there?
- 5. What is the highest priority task?
- 6. What does the main task correspond to?
- 7. What is the role of the $ipc\theta$ task? Web help
- 8. What is the role of the esp timer task? Web help
- 9. What is the role of the Tmr Svc task? Web help 1 and Web help 2
- 10. What is the role of the *IDLE0* task? What is its priority? Web help
- 11. The default stack size is 4000 bytes. Change the constant $STACK_SIZE = 1400$ bytes. What is the problem? Change the size to the nearest hundredth to avoid the problem.

1.1.4 Idle and Tick Task Hooks

An idle task hook is a function that is called during each cycle of the idle task. To use them, we will modify the configuration.

1. Add the two hook functions provided in the « lab1-1_add_idle_hook.c » file.

```
bool vApplicationIdleHook ( void ){
  DISPLAY ("IDLE");
  return true;
}
```

```
void vApplicationTickHook ( void ){
}
```

2. Why are there 2 hook functions? What is the difference? Web help 1 and Web help 2

- 3. The first parameter is compulsory to use the hooks functions. The second parameter adjusts the stack size depending on the behavior of the hook functions. 2 solutions :
 - Using the menuconfig command and go to Component config/FreeRTOS/Use FreeRTOS legacy hooks.
 - Add these lines below in the « sdkconfig.defaults » file (provided in *lab1-1_config_idle_hook.txt* file) and delete the « sdkconfig » to take into account the modifications.

```
# allows add hook functions
CONFIG_FREERTOS_LEGACY_HOOKS=y
CONFIG_FREERTOS_IDLE_TASK_STACKSIZE=4096
```

- 4. Run the program. What do you see for the *Idle* and *app main* tasks?
- 5. Modify the task delay of vTaskFunction() function to 400ms instead of 100ms. What do you see for *Idle* and *app_main* tasks? Conclusion?
- 6. Trace in the figure 1.4 the behavior of tasks until 160 ticks.

1.2 Task scheduling on two cores (Lab1-2)

the ESP32 has 1 or 2 cores. It is possible to choose on which core the task should be mapped or to let the scheduler choose. At the end of this Lab, we will see another solution to use the *idle* task without using the configuration but an API.

- 1. Create the «lab1-2_2_cores_sched» lab from «esp32-vscode-project-template» GitHub repository.
- 2. Overwrite the « main.c » file by the provided code of the « lab1-2 main.c » file.
- 3. Copy the provided « my helper fct.h » file to the « main » folder.
- 4. Copy the provided « lab1-2_sdk config.defaults » file to the project folder and rename « sdk config.defaults » .

5. Study the following function: xTaskCreatePinnedToCore(). Web help

1.2.1 Task scheduling scenarios

We are going to test different scheduling scenarios according to the cores on which the tasks will be executed. In order to facilitate the different scenarios to be executed, we will use the preprocessor macros as below:

```
//#define DIFF_PRIORITY

#define PINNED_TO_CORE 0x00

// 0x00: Task 1: Core 0, Task 2: Core 0

// 0x01: Task 1: Core 0, Task 2: Core 1

// 0x10: Task 1: Core 1, Task 2: Core 0

// 0x11: Task 1: Core 1, Task 2: Core 1

//#define IDLE_HOOKS

//#define TASK_DELAY
```

You must run the 4 scenarios, copy the trace till 160 ticks (1600 ms) and comment it.

- Uncomment $DIFF_PRIORITY$ to have the priority(Task 1) = 5 and priority(Task 2) = 6.
- Scenario nº 1 : Task 1 : Core 0, Task 2 : Core 0

• Scenario nº 2 : Task 1 : Core 0, Task 2 : Core 1

 \bullet Scenario nº 3 : Task 1 : Core 1, Task 2 : Core 0

 \bullet Scenario nº 4 : Task 1 : Core 1, Task 2 : Core 1.

For the last scenario $n^{\circ} 5$, we are going to add a task on *core* θ using task mapping of scenario $n^{\circ} 4$.

- 1. Add a Task 3 on core 0 with priority = 1.
- 2. Trace in the figure 1.5 the behavior of the tasks until 160 ticks.




FIGURE 1.5 – Scheduling on 2 cores with 4 tasks.

1.2.2 Idle Task Hook from API (Optional work)

The disadvantage of configuring the hook functions from the configuration menu is the declaration of the 2 functions while generally the vApplicationIdleHook() function is the only useful function. Thus, it is possible to use an API which allows adding only the vApplicationIdleHook() function.

- 1. Uncomment the *IDLE_HOOKS* preprocessor macro. We use the previous scenario no 5.
- 2. Study the following function: esp register freertos idle hook for cpu(). Web help
- 3. Run the program and comment the behavior. What do you notice about the execution of the *IDLE1* task?
- 4. Uncomment the TASK DELAY preprocessor macro.
- 5. Run the program and comment the new behavior, in particular the *IDLE1* task.

1.3 Approximated/Exactly periodic task (Lab1-3)

In some applications it is important to have tasks with an exact period. We will compare the use of the TaskDelay() function which allows you to wait for a certain time and the TaskDelayUntil() function which allows you to adjust the delay according to the time spent.

- 1. Duplicate the « lab1-2 2 cores sched » folder to « lab1-3 periodic task ».
- 2. Check that you have uncommented the $DIFF_PRIORITY$, $IDLE_HOOKS$ and $TASK_DELAY$ preprocessor macros.
- 3. Set the $PINNED_TO_CORE$ macro to 0x00 to run all tasks on PRO_CPU (Core 0).
- 4. Change the behavior of the vTaskFunction() task as below.

```
#ifdef TASK_DELAY
   /* Approximated/Periodic Delay */
#ifdef PERIODIC_TASK_DELAY
   DISPLAY("Periodic Delay of %s", pcTaskName);
   vTaskDelayUntil(&xLastWakeTime, pdMS_TO_TICKS(300));
#else
   DISPLAY("Approximated Delay of %s", pcTaskName);
   vTaskDelay(pdMS_TO_TICKS(300));
#endif
#endif
```

- 5. What does it do the following macro pdMS TO TICKS()?
- 6. Study the vTaskDelayUntil() function. Web help
- 7. Run the program and comment the behavior. What is the interval/period of Tasks 1,2 and 3? To compute time, use the tick number from the display of « Run computation of Task X » (X = 1,2 or 3) comment.
- 8. Uncomment the PERIODIC TASK DELAY preprocessor macro.
- 9. Build the project and correct the compilation error if necessary.
- 10. Run the program at least up to 400 ticks and comment the behavior. What is the interval/period of Tasks 1,2 and 3? What is the problem?

11. Change the $mainDELAY_LOOP_COUNT$ constant to 0x1FFFF. What is the interval/period of Tasks 1,2 and 3? Comment the new behavior.

1.4 Task handler and dynamic priority (Lab1-4, Optional work)

During the execution of the application, it is sometimes useful to modify the priority of a task or any other actions. To do this, it is necessary to get the handler of the task on which we have to operate these actions.

- 1. Create the « lab1-4_task_handler_priority » lab from « esp32-vscode-project-template » GitHub repository.
- 2. Overwrite the « main.c » file by the provided code of the « lab1-4_main.c » file.

3.	Copy the provided « $my_helper_fct.h$ » file to the « $main$ » folder.
4.	Copy the provided « lab1-4_sdk config.defaults » file to the project folder and rename « sdk config.defaults ».
5.	Study the $uxTaskPriorityGet()$ and $vTaskPrioritySet()$ functions. Web help
6.	Study the $vTaskGetRunTimeStats()$ function. What parameters should be configured
	in sdkconfig file or from graphical menu config? Web help
7.	Explain the use of the handler. In what tasks? Why?
8.	Run the program. What is the problem?
9.	How are you going to correct the problem?
10.	Run the program after code modification and comment the scenarios.

11. Comment also the statistics.

Message Queue & Interrupt service

Lab Objectives

- Using message queue API.
- Using message queue with interrupts

2.1 Single Message Queue (Lab2-1)

We want to create 3 tasks. The functions implementing the tasks will be named Task1() (priority=2, periodic: 500ms, running on the $Core\ 1$), Task2() (priority=2, running on the $Core\ 0$) and Task3() (priority=3, running on the $Core\ 0$) respectively. Task1() will send a number (using a message queue object) to the Task2(). Each task displays string to the terminal with DISPLAY() or DISPLAYI() macros.

- 1. Create the < lab2-1_single_msg_queue > lab from < esp32-vscode-project-template > GitHub repository.
- 2. Copy the provided « my helper fct.h » file to the « main » folder.
- 3. Copy the provided « lab2-1_sdk config.defaults » file to the project folder and rename « sdk config.defaults » .
- 4. Append the content of add includes.c file to the start of the main.c file.
- 5. Study the following function : xQueueSend(), xQueueReceive(). Web help 1, Web help 2
- 6. Write the 3 tasks with empty body.

7. Declare the 3 tasks on the $app_main()$ function (Best practice : use constants for priorities, stack size, ...).

- 8. Add the message queue (depth is 5) in the program. The type of the message is uint32 t.
- 9. Write the behavior of the tasks as below:
 - Task 3 blocks for 100ms, displays string to the terminal and then simulates a computation of 20ms (2 ticks).

```
// Task blocked during 100 ms
DISPLAY(...);
vTaskDelay(pdMS_TO_TICKS(100));
DISPLAY(...);
// Compute time : 2 ticks or 20 ms
COMPUTE_IN_TICK(2);
```

• The Task 1 should be periodic with a periodicity of 500ms. It posts in a message queue to the Task 2, check the result of the post (Failed or posted message), simulates a computation of 40ms (4 ticks) and wait for next period. Note that the write function in the queue should not be blocking.

```
// Post
uint32_t result = xQueueSend(...);
// Check result
if (result) ...
// Compute time : 4 ticks or 40 ms
COMPUTE_IN_TICK(4);
// block periodically : 500ms
vTaskDelayUntil(...);
```

• Task 2 waits for a message through the message queue, displays the task number and message received and then simulates a computation of 30ms (3 ticks).

```
// Wait for message
...
// display task number and message
DISPLAY(...);
// Compute time : 3 ticks or 30 ms
COMPUTE_IN_TICK(3);
```

- Don't forget to create a message queue.
- 10. Build and run the program.
- 11. Trace in the figure 2.1 the behavior of the 3 tasks until 160 ticks.
- 12. What is the period of the task 2?




FIGURE 2.1 – Message queue and 3 tasks.

2.2 Message Queue with time out (Lab2-2)

The concept of timeout only applies to blocking system calls. When a task is blocked, it will wake up (go to the ready state) automatically after a period of time called Timeout, even if the expected event has not happened.

- Duplicate the « lab2-1_single_msg_queue » folder to « lab2-2_single_msg_queue_timeout ».
- Force Task 2 to wake up every 300ms using the Timeout associated with the xQueue-Receive() function as below.

```
static const char* TAG = "MsgTimeOut";
...
if (xQueueReceive(...)) {
  DISPLAYI(TAG, "Task 2, mess = %d", value);
  COMPUTE_IN_TICK(3);
}
else {
  DISPLAYE(TAG, "Task 2, Timeout!");
  COMPUTE_IN_TICK(1);
}
```

- Build and run the program.
- Trace in the figure 2.3 the behavior of the 3 tasks until 160 ticks.

2.3 Blocking on single Queue (Lab2-3, Optional work)

We want to illustrate the problems of writing/reading queue messages and the impact on the scheduling of tasks. The figure 2.2 illustrates the application. All tasks run on the Core 0. The message queue contains items of integer type.




FIGURE 2.2 – Blocking on single queue.




FIGURE 2.3 – Message queue with timeout and 3 tasks.

2.3.1 Blocking on Queue Reads

1. Create the « lab2-3_single_msg_queue_blocked » lab from « esp32-vscode-project-template » GitHub repository.

- 2. Copy the provided « my helper fct.h » file to the « main » folder.
- 3. Copy the provided « lab2-3_sdkconfig.defaults » file to the project folder and rename « sdkconfig.defaults ».
- 4. Overwrite the « main.c » file by the provided code of the « lab2-1 main.c » file.
- 5. Complete the code. For the moment, initialize the constants as below:

```
const uint32_t SENDER_TASK_PRIORITY = 3;
const uint32_t RECEIVER_TASK_PRIORITY = 3;
const uint32_t MESS_QUEUE_MAX_LENGTH = 10;
const uint32_t SENDER_TASK_NUMBER = 3;
const uint32_t RECEIVER_TASK_NUMBER = 3;
```

- 6. Build and run the program.
- 7. Explain the behavior.
- 8. Modify the priority of receiver task to 5 and run the program.
- 9. Explain the new behavior.
- 10. Modify the priority of *sender task* to 5 and the priority of *receiver task* to 3. Run the program.
- 11. Explain the new behavior.

2.3.2 Blocking on Queue Writes

- 1. Modify the priority of sender task to 5 and the priority of receiver task to 3.
- 2. Modify the capacity of the message queue to 2 (i.e. $MESS\ QUEUE\ MAX\ LENGTH=2)$

- 3. Explain the problem.
- 4. How to correct the problem by adjusting the priority of tasks?

2.4 Using message queue with interrupts (Lab2-4)

The figure 2.4 illustrates the application we want to achieve. When we press the push button, it will trigger on falling edge an interrupt $(Push_button_isr_handler())$ that will send a message containing the GPIO pin number of push button to the vCounterTask() task. If the button is not pressed after 5 seconds, a message is displayed indicating that the button must be pressed to trigger an interrupt. A simple way is to use the timeout of the message queue received function. All tasks run on the $Core\ \theta$. We will take over the lab Interrupt mode with GPIO (Lab4-2) to configure GPIO and to install interrupt service.




FIGURE 2.4 – Interrupt application with message queue.

- 1. Create the «lab2-4_single_msg_queue_interrupt » lab from «esp32-vscode-project-template » GitHub repository.
- 2. Overwrite the « main.c » file by the provided code of the « lab2-4 main.c » file.
- 3. Copy the provided « my helper fct.h » file to the « main » folder.
- 4. Copy the provided « lab2-4_sdkconfig.defaults » file to the project folder and rename « sdkconfig.defaults ».
- 5. Study the following function: xQueueSendFromISR(). Web help

- 6. Study the following function: uxQueueMessagesWaiting(). Web help
- 7. Configure the GPIO for the push button (RTC GPIO13).
- 8. Write the creation of the message queue (item size = 5) and the vCounterTask() task in the $app_main()$ function.
- 9. Complete the body of the *Push_button_isr_handler()* by following the comments. Declare an *isrCount* global variable to count each trigger of interrupt. The argument of the *Push_button_isr_handler()* interrupt is the GPIO pin number of push button.
- 10. Write the installation of interrupt service in the $app_main()$ function.
- 11. Write the body of vCounterTask() task by following the comments in the source code.
- 12. Perform the wiring on the board. Refer to the documentation ESP32-PICO-D4 Pin Layout.pdf.
- 13. Build and run the program.
- 14. When is the message "number of items" displayed? why?
- 15. Explain how to correct the problem? more than one solution is possible.

16. Change the program according to your solution. Build and run the program.

Semaphore & Mutex

Lab Objectives

- Using semaphore API.
- Using Mutex

3.1 Specification of the application

We want to implement the functional structure (cf. figure 3.1) using FreeRTOS.




FIGURE 3.1 – Functional description.

The behavioral description of tasks is presented below in algorithm form. *Table* is an array of integer values that can represent a signal, such as a ramp. Its size is a constant (TABLE_SIZE) which can be modified during the tests. During initialization, it takes the

```
values [0,1,2,..., TABLE\_SIZE-1]. Use TABLE_SIZE = 400.
Do not forget to use the pdMS\_TO\_TICKS(iTime\ time) macro to convert time in millisecond to tick number.
```

3.1.1 Timer task

This is a task that performs a TaskDelay() and generates the synchronization (semaphore) via Clk. The function computeTime() simulates a execution time in millisecond.

```
Task Timer is
    Properties: Priority = 5
Out    : Clk is event

Cycle :
    waitForPeriod(250 ms);
    computeTime(20 ms);
    print("Task Timer : give sem");
    notify(Clk);
    end
end
```

Algorithm 1: Timer algorithm.

3.1.2 IncTable task

It is a temporary action activated by Clk. An constNumber is passed by the parameters of the task. Every 5 activations, the task increments by the constNumber for each element of Table. We simulate a computation time by the computeTime() pseudo function. Its functional behavior is as follows:

```
Task IncTable is
   Properties: Priority = 4
              : Clk is event
   In
              : Table is array[0 to TABLE SIZE-1] of integer
   ActivationNumber := 0;
   Cycle Clk:
      if ActivationNumber = 0 then
         for index := 0 to TABLE SIZE-1 do
            Table[index] := Table[index] + constNumber;
         end
         computeTime(50 ms);
         ActivationNumber := 4;
         ActivationNumber := ActivationNumber - 1;
      end
   end
end
                     Algorithm 2: IncTable algorithm.
```

3.1.3 DecTable task

```
Its functional behavior is as follows:

Task DecTable is

Properties: Priority = 4

In : Clk is event

In/Out : Table is array[0 to TABLE_SIZE-1] of integer

Cycle Clk:

for index := 0 to TABLE_SIZE-1 do

Table[index] := Table[index] - 1;

end

computeTime(50 ms);

end

end
```

Algorithm 3: DecTable algorithm.

3.1.4 Inspector task

It is a task which constantly checks the consistency of the Table and displays an error message when an inconsistency is found in the Table (exit on the program, use exit(1) function). For this, it takes the first value of the Table as a reference (reference = Table[0]) and checks each element of Table in accordance with its reference (Table[index] = reference + index). When the Table has been fully browsed, the cycle begins again (a new reference is

taken and the Table is checked again). Its functional behavior is as follows:

```
Task Inspector is
   Properties: Priority = 4
               : Table is array[0 to TABLE SIZE-1] of integer
   ActivationNumber := 0;
   Cycle:
      print("Task Inspector is checking.");
      reference := Table[0];
      error := false;
      for index := 1 to TABLE SIZE-1 do
         smallComputeTime(100 us);
         if Table[index] \neq (reference + index) then
             error := true;
          end
      end
      print("Task Inspector ended its checking.");
      if error = true then
          print(TAG, "Consistency error in the Table variable.");
         exit();
      end
   end
end
```

Algorithm 4: Inspector algorithm.

3.2 First Task synchronization (Lab3-1)

Firstly, we will only implement the Timer, DecTable and IncTable tasks as well as the Clk and Table relationships. The computeTime() function can be implemented by the COM-PUTE IN TICK() macro (1 tick = 10ms) and the print() function by DISPLAY() macro.

3.2.1 Writing the application

- 1. Create the « lab3-1_one_sem_clk » lab from « esp32-vscode-project-template » GitHub repository.
- 2. Copy the provided « lab3-1_sdkconfig.defaults » file to the project folder and rename « sdkconfig.defaults ».
- 3. Copy the provided « my_helper_fct.h » file to the « main » folder.
- 4. Overwrite the « main.c » file by the provided code of the « lab3-1 main.c » file.
- 5. Write the program with the behavior of these 3 tasks and 1 semaphore (*xSemClk*) using the algorithms proposed above. All the tasks are created on the *Core_0*. Below is a creation reminder for a semaphore.

```
/* Creating Binary semaphore */
SemaphoreHandle_t xSemClk;
xSemClk = xSemaphoreCreateBinary();
/* Using semaphore */
xSemaphoreGive(xSemClk);
xSemaphoreTake(xSemClk, portMAX_DELAY);
```

6. Build the program without running it.

3.2.2 Scenarios with one clock semaphore

We will perform scenarios described in the Table 3.1 in order to identify problems and improve the program later. The task priority of Timer is 5 and run on $Core_{-}0$.

Scenario	IncTable task	DecTable task
1	Prio(4), Core(0)	Prio(4), Core(0)
2	Prio(3), Core(0)	Prio(4), Core(0)
3	Prio(4), Core(0)	Prio(4), Core(1)
4	Prio(3), Core(0)	Prio(4), Core(1)

Table 3.1 – Scenarios for task synchronization.

Scenario 1: Run the program, copy the console, trace in the figure 3.2 the behavior of the 3 tasks until 160 ticks and explain the problem.

Scenario 2: Run the program, copy the console and explain the problem.

Scenario 3: Run the program, copy the console and explain the problem.

Scenario 4: Run the program, copy the console and explain the problem.

3.3 Task synchronization with 2 semaphores (Lab3-2)

We identified different issues in the previous section. We will perform again the scenarios described in the Table 3.1.

- 1. Duplicate the « lab3-1_one_sem_clk » folder to « lab3-2_two_sem_clk ».
- 2. Correct the clock program to send 2 separate semaphores (xSemIncTab and xSemDec-Tab) to IncTable and DecTable tasks.

Scenario 1: Run the program, copy the console, trace in the figure 3.3 the behavior of the 3 tasks until 160 ticks and explain the behavior.





FIGURE 3.2 – Scenario 1 : Priority(DecTable=4, IncTable=4), Core(DecTable=0, IncTable=0).



Scenario 3: Run the program, copy the console, trace in the figure 3.5 the behavior of the 3 tasks until 160 ticks and explain the behavior.

Scenario 4: Run the program, copy the console and explain the behavior.




FIGURE 3.3 – Scenario 1 : Priority(DecTable=4, IncTable=4), Core(DecTable=0, IncTable=0).




FIGURE 3.4 – Scenario 2: Priority(DecTable=4, IncTable=3), Core(DecTable=0, IncTable=0).




FIGURE 3.5 – Scenario 3: Priority(DecTable=4, IncTable=4), Core(DecTable=1, IncTable=0).

3.4 Mutual Exclusion (Lab3-3)

We now add the *Inspector* task. We will perform the program with the task priorities described in the Table 3.2.

Timer task	IncTable task	DecTable task	Inspector task
Prio(5), Core(0)	Prio(3), Core(0)	Prio(3), Core(0)	Prio(4), Core(0)

Table 3.2 – Task priorities with mutex.

- 1. Duplicate the « lab3-2_two_sem_clk » folder to « lab3-3_mutex ».
- 2. Add the *Inspector* task.
- 3. Run the program, copy the console and explain the behavior. What is the problem?

- 4. Correct the problem of initialization.
- 5. Run the program, copy the console and explain the behavior. What is the problem?

- 6. Choose a new priority of the *Inspector* task to solve the problem.
- 7. Run the program, copy the console until 40 ticks, trace in the figure 3.6 the behavior of the 3 tasks until 40 ticks and explain the behavior.

8. Modify the *Inspector* task by adding a *Mutex* to manage access to the critical area. Below is a creation reminder for a Mutex.

```
/* Mutex */
SemaphoreHandle_t xSemMutex;
xSemMutex = xSemaphoreCreateMutex();
/* Using Mutex */
xSemaphoreGive(xSemMutex);
xSemaphoreTake(xSemMutex, portMAX_DELAY);
```

9. Run the program, copy the console, trace in the figure 3.7 the behavior of the 3 tasks until 40 ticks and explain the behavior and the effect of the Mutex.

10. Change the priority of *Inspector* task to 4. Run the program, copy the console until 40 ticks. What is the problem?

11. We decide to change the *Inspector* task to *Core_1*. Run the program, copy the console until 40 ticks. What is the problem?

12. We now decide to add a delay of 2 ticks after giving the mutex (using vTaskDelay() function). Run the program, copy the console, trace in the figure 3.8 the behavior of the 3 tasks and Mutex until 90 ticks and explain the behavior.




FIGURE 3.6 - Program with Task inspector.




FIGURE 3.7 – Program with Task inspector on the Core_0 and Mutex.




FIGURE 3.8 – Program with Task inspector on the Core_1 and Mutex.

Direct task notification

Lab Objectives

- Using task notification instead of semaphore.
- Using event group for a notification.

4.1 Direct task notification (Lab4-1)

A direct to task notification is an event sent directly to a task, rather than indirectly to a task via an intermediary object such as a queue, event group or semaphore. The direct to task notification is faster than using an intermediary objects and has a RAM Footprint benefits.

- \bullet Duplicate the « lab3-2_two_sem_clk » folder to « lab4-1_two_notifications_clk ».
- Answer the following questions:
 - Study the parameters of the xTaskNotifyGive() function. Web help
 - Study the parameters of the ulTaskNotifyTake() function. Web help
- Replace the two separate semaphores (i.e. notification of the *IncTable* and *DecTable* tasks) by a the *direct to task notification* mechanism. For the *ulTaskNotifyTake()* function, we set the first parameter *xClearCountOnExit* to *TRUE*. Print the return value (pending event counter) of *ulTaskNotifyTake()* function for each task.

•	Run	the	program	and	explain	the	behavior.
---	-----	-----	---------	-----	---------	-----	-----------

- In the *Timer* task, add a new *give()* notification to *IncTable* task. So, you have 2 notifications in a row to the *IncTable* task.
- Run the program and explain the behavior.

• We set now the first parameter xClearCountOnExit to FALSE for the ulTaskNotify-Take() function. What is the difference of behavior regarding to the previous question?

LAB 4 121

4.2 Direct task notification with a event value (Lab4-2)

To illustrate the principle, we are going to modify the algorithm of the *Timer* task. Its functional behavior is as follows:

```
Task Timer is
   Properties: Priority = 5, ACTION = eSetBits
   Out
              : Clk is event
   Cycle:
      waitForPeriod(250 ms);
      computeTime(20 ms);
      print("Task Timer : Notify Give (count=\%d)", count);
      // IncTable task notifications
      notify(incTableHandler, (0x01 « count), eSetBits);
      notify(incTableHandler, (0x02 « count), ACTION);
      // DecTable task notification
      notify(decTableHandler, (0x01 « count), eSetValueWithoutOverwrite);
      // counter modulo 4
      count = (count + 1)
   end
```

Algorithm 5: New Timer algorithm.

- 1. Duplicate the « lab4-1_two_notifications_clk » folder to « lab4-2 two notifications clk2 ».
- 2. Answer the following questions:

end

- Study the parameters of the xTaskNotify() function. Web help
- Study the parameters of the xTaskNotifyWait() function. Web help
- 3. Modify the code of *Timer* task.
 - The ACTION property can be a constant value and can take the eSetBits, eSet-ValueWithoutOverwrite or eSetValueWithOverwrite value.
 - We set by default the ACTION property to eSetBits.
 - What is the best value of the first parameter (ulBitsToClearOnEntry) of the xTask-NotifyWait() function?

- We set the second parameter (ulBitsToClearOnExit) of the xTaskNotifyWait() function to 0.
- 4. Run the program, copy the console until 107 ticks and explain the behavior, in particular the pending counter value in each 2 tasks.

5. We set the *ACTION* property to *eSetValueWithoutOverwrite*. Run the program, copy the console until 107 ticks and explain the behavior.

6. We set the ACTION property to eSetValueWithOverwrite. Run the program, copy the console until 107 ticks and explain the behavior.

Application

Lab Objectives

- Use the knowledge previously seen on freertos services
- Using GPIO
- Using Interrupt

5.1 Specification of the application

We want to implement the functional structure depicted in figure 5.1.

5.1.1 Scan task

The task is activated on ScanH event. It acquires the value of the Value variable, compares it to high and low thresholds. Value being a theoretical output of a Digital/Analog converter not available for this Lab. It is possible to simulate its evolution by a random generation made by ScanH when activated.

The rand() function allows you to generate a number between 0 and RAND_MAX. So you just need, by rule of three, to bring the result between 0 and 100 and to set the low threshold at 15 and the threshold at 85.

If one of the thresholds is exceeded, a message of *High alarm* or *Low alarm* type is sent to the *Mess* queue, accompanied by the threshold value of *Value* variable. Otherwise, the value of *Value* variable is assigned to *Sample Value*.

```
static const uint32_t VALUE_MAX = 100;
static const uint32_t LOW_TRIG = 15;
static const uint32_t HIGH_TRIG = 85;
```




Figure 5.1 - Functional description.

```
int iValue = rand() / (RAND_MAX / VALUE_MAX);
if (iValue < LOW_TRIG) {
     // Low Alarm
}
else if (iValue > HIGH_TRIG) {
     // High Alarm
}
else {
     // No Alarm
}
```

5.1.2 Monitoring task

The task is activated on MonitoringH event. It sends messages of Monitoring type in the Mess queue. These messages contain the value of the variable Sample Value. Thus, the structure of Mess queue can be described as follows:

```
typedef enum typeInfo { Alarm, Monitoring };
typedef struct
{
   enum typeInfo xInfo;
   int xValue;
} typeMessage;
```

5.1.3 Timer task

The Timer task generates a periodic H event of 10ms.

5.1.4 Divider task

The Divider task performs a division of H event by 5 to generate ScanH event and a division by 18 to generate MonitoringH event.

5.1.5 User task

The task is activated by the keyboard. It allows the user to print a packet of characters on the terminal (called *Packet Edition*). These characters are edited by packet, the end of a packet corresponding to the character @ (for example, a packet is « it is an example@ » as depicted Listing 5.1). When entering a character packet (*Packet Edition* mode), the *Output* function should not display its messages on the terminal and the *PacketEditionLed* is set to 1 (the green led is ON). After entering the character @ (end of *Packet Edition* mode), it can display as many messages as necessary, until the user enters the next character. The characters can be entered using the *getch()* function. An example of use is depicted below:

```
/* Scan keyboard every 50 ms */
while (car != '@') {
  car = getch();
  if (car != 0xff) {
    printf("%c", car);
    }
  vTaskDelay(pdMS_TO_TICKS(50));
}
```

Another solution for exiting *Packet Edition* mode is to press the push button that triggers an interrupt (named *Button interrupt*). This interrupt sends an event (semaphore) to the *User* task so that it can exit *Packet Edition* mode.

5.1.6 Output task

The task displays a formatted message of the *Mess* queue as depicted in the terminal in Listing 5.1. When the message is an alarm, the *AlarmLed* must be set to 1 (the red led is ON).

Listing 5.1 – Console example of the application

```
13:0> Monitoring: Value = 69

203:0> Monitoring: Value = 55

393:0> Monitoring: Value = 20

583:0> Monitoring: Value = 84

613:0> Alarm: Value = 6

733:0> Alarm: Value = 87

773:0> Monitoring: Value = 85
```

```
853:0>
        Alarm: Value = 98
913:0>
        Alarm: Value = 8
963:0>
       Monitoring: Value = 15
973:0>
        Alarm: Value = 90
1033:0> Alarm: Value = 10
1093:0> Alarm: Value = 92
1153:0> Monitoring: Value = 50
1213:0> Alarm: Value = 87
1343:0> Monitoring: Value = 69
User mode
hello !@
End User mode
2393:0> Alarm: Value = 3
2393:0> Monitoring: Value = 15
2393:0> Alarm: Value = 9
```

5.2 Implementation of the application (Lab5)

- 1. Create the « lab5_application » lab from « esp32-vscode-project-template » GitHub repository.
- 2. Copy the provided « my_helper_fct.h » file to the « main » folder.
- 3. Overwrite the « main.c » file by the provided code of the « lab5 main.c » file.
- 4. Create a « sdkconfig.defaults » file with right parameters.
- 5. Write the program for *Timer*, *Divider*, *Scan* and *Monitoring* tasks. The capacity of *Mess* queue is 5. The tasks are mapped on different cores referenced in the figure 5.1.
- 6. Build to check that is no compilation error.

In order to validate the behavior of the application and to clearly highlight the management of Mess queue, we can proceed as below:

- 1. Validate the functional structure with only the *Timer*, *Divider*, *Scan* and *Monito-ring* tasks. Check that after a number of message submissions corresponding to the maximum capacity of the *Mess* queue, the *Monitoring* and *Scan* tasks are blocked.
- 2. Wire the 2 leds on the board.
- 3. Add the *Output* task. We will check that the *Monitoring* and *Scan* tasks are no longer blocked. Only the *Output* task can be blocked on an empty *Mess* queue. Check the behavior of the red led.
- 4. Add the *User* task without using interrupt. Note that the *getch()* function also uses the terminal as the *printf()* function. You must protect the simultaneous write on the terminal. Check the application and green led behaviors.
- 5. Wire the push button on the board.

6. Add the *button interrupt* function and check the behavior. The name of the *give()* function is different when called from an interrupt (Web help).

Part IV Appendix

ANNEXE A

ESP32 Board




FIGURE A.1 – Pin description of ESP32-PICO-D4 board.

	References