FBW A320NEO CHECKLIST

(For Simulation Purposes Only)



BEFORE START	
COCKPIT PREPCOM	MPLETED (BOTH)
GEAR PINS and COVERS	REMOVED
SIGNS	ON/AUTO
ADIRS	NAV
FUEL QUANTITY	KG.LB
TO DATA	SET
BARO REF	SET (BOTH)
WINDOWS/DOORS	.CLOSED (BOTH)
BEACON	ON
THR LEVERS	IDLE
PARKING BRAKE	AS RQRD

AFTER START	
ANTI ICE	AS RQRD
ECAM STATUS	CHECKED
PITCH TRIM	% SET
PITCH TRIM	ZERO

BEFORE TAKEOFF	
FLIGHT CONTROLS	CHECKED (BOTH)
FLT INST	CHECKED (BOTH)
BRIEFING	
FLAP SETTING	
V1. VR. V2/FLX TEMP	(BOTH)
	SEŤ
ECAM MEMO	TO NO BLUE
- AUTO BRK MAX	
- SIGNS ON	
- CABIN READY	
- SPLRS ARM	
- FLAPS TO	
- TO CONFIG NORM	CONFIDNED (DOTI)
TAKEOFF RWY	
CABIN CREW	
	TA OR TA/RA
ENG MODE SEL	AS RQRD
PACKS	AS RQRD

AFTER TAKEOFF / CLIMB	
LDG GEAR	UP
FI ΔPS	RETRACTED
PACKS	ON
BARO REF	

APPROACH	
BRIEFING	CONFIRMED
ECAM STATUS	CHECKED
SEAT BELTS	ON
BARO REF	SET (BOTH)
MINIMUM	SET (BOTH)
SEAT BELTSBARO REFBINIMUMBINIMUMBINIMUMBINIMUM	AS RQRD

LANDING		
CABIN CREW	ADVISED	
A/THR	SPEED/OFF	
AUTOBRAKE	AS RQRD	
ECAM MEMO	LDG NO BLUE	
- LDG GEAR DN		
- SIGNS ON		
- CABIN READY		
- SPLRS ARM		
- FLAPS SET		

AFTER LANDING	
FLAPS	RETRACTED
SPOILERS	DISARMED
APU	
RADAR	OFF
PREDICTIVE WINDSHEAR	SYSTEM OFF

PARKING	
APU BLEED	ON
ENGINES	OFF
SEAT BELTS	OFF
EXT LT	AS RQRD
FUEL PUMPS	
PARK BRK and CHOCKS	AS RQRD
Consider HEAVY RAIN	

SECURING THE AIRCRAFT	
ADIRS	OFF
OXYGEN	OFF
APU BLEED	OFF
EMER EXIT LT	OFF
SIGNS	OFF
APU AND BAT	OFF
Consider COLD WEATHER	

