

02/07/20, 4:36 pm

provide easy and practical examples that anyone can understand. This is the Linux Device Driver Tutorial Part 23 – Spinlock in Linux Kernel Part 1.

Apple Music Turns 5 as It Continues Rivalry With Spotify

Post Contents [hide]

- 1 Prerequisites
- 2 Introduction
- 3 SpinLock
- 4 SpinLock in Linux Kernel Device Driver
 - 4.1 Initialize
 - 4.1.1 Static Method
 - 4.1.2 Dynamic Method
 - 4.2 Approach 1 (Locking between User context)
 - 4.2.1 Example
 - 4.3 Approach 2 (Locking between Bottom Halves)
 - 4.4 Approach 3 (Locking between User context and Bottom Halves)
 - 4.4.1 Example
 - 4.5 Approach 4 (Locking between Hard IRQ and Bottom Halves)
 - 4.5.1 Example
 - 4.6 Approach 5 (Alternative way of Approach 4)
 - 7 Approach 6 (Locking between Hard IROs)

X

5.2.1 Share this:

5.2.2 Like this:

5.2.3 Related

Prerequisites

In the example section, I had used Kthread to explain Mutex. If you don't know what is Kthread and How to use it, then I would recommend you to explore that by using below link.

- 1. Kthread Tutorial in Linux Kernel
- 2. Mutex Tutorial in Linux Kernel

Introduction

In our previous tutorial, we have understood the use of Mutex and its Implementation. If you have understood Mutex then Spinlock is also similar. Both are used to protect a shared resource from being modified

X

In the Mutex concept, when the thread is trying to lock or acquire the Mutex which is not available then that thread will go to sleep until that Mutex is available. Whereas in Spinlock it is different. The spinlock is a very simple single-holder lock. If a process attempts to acquire a spinlock and it is unavailable, the process will keep trying (spinning) until it can acquire the lock. This simplicity creates a small and fast lock.

Like Mutex, there are two possible states in Spinlock: **Locked** or **Unlocked**.

SpinLock in Linux Kernel Device Driver

If the kernel is running on a uniprocessor and CONFIG_SMP, CONFIG_PREEMPT aren't enabled while compiling the kernel then spinlock will not be available. Because there is no reason to have a lock when no one else can run at the same time.

But if you have disabled **CONFIG_SMP** and enabled **CONFIG_PREEMPT** then spinlock will simply disable preemption, which is sufficient to prevent any races.

Initialize

We can initialize Spinlock in Linux kernel in two ways.

X

Static Method

You can statically initialize a Spinlock using the macro given below.

```
DEFINE_SPINLOCK(etx_spinlock);
```

The macro given above will create a **spinlock_t** variable in the name of **etx_spinlock** and initialize to **UNLOCKED STATE**. Take a look at the expansion of **DEFINE SPINLOCK** below.

#define DEFINE_SPINLOCK(x)

 $spinlock_t x = SPIN LOCK UNLOCKED(x)$

Dynamic Method

If you want to initialize dynamically you can use the method as given below.

```
1 spinlock_t etx_spinlock;
2 spin_lock_init(&etx_spinlock);
```

You can use any one of the methods.

After initializing the spinlock, there are several ways to use spinlock to lock or unlock, based on where the spinlock is used; either in user context or interrupt context. Let's look at the approaches with these situations.

Approach 1 (Locking between User context)

If you share data with user context (between Kernel Threads), then you can use this approach.

Lock:

2

spin lock(spinlock t *lock)

Χ

spin_trylock(spinlock_t *lock)

Locks the spinlock if it is not already locked. If unable to obtain the lock it exits with an error and do not spin. It **returns** non-zero if it obtains the lock otherwise returns zero.

Unlock:

```
spin_unlock(spinlock_t *lock)
```

It does the reverse of the lock. It will unlock which is locked by the above call.

Checking Lock:

```
spin_is_locked(spinlock_t *lock)
```

This is used to check whether the lock is available or not. It **returns** non-zero if the lock is currently acquired. otherwise returns zero.

Example

```
//Thread 1
2 int thread_function1(void *pv)
3 {
4
       while(!kthread_should_stop()) {
5
           spin_lock(&etx_spinlock);
6
           etx_global_variable++;
           printk(KERN_INFO "In EmbeTronicX Thread Function1 %lu\n", etx_global_variable
7
8
           spin_unlock(&etx_spinlock);
9
           msleep(1000);
10
       return 0;
11
12 -}
13
      hread 2
        thread function2(void *pv)
```

```
23 }
24 return 0;
25 }
```

Approach 2 (Locking between Bottom Halves)

If you want to share data between two different Bottom halves or the same bottom halves, then you can use the Approach 1.

Approach 3 (Locking between User context and Bottom Halves)

If you share data with a bottom half and user context (like Kernel Thread), then this approach will be useful.

Lock:

```
spin_lock_bh(spinlock_t *lock)
```

It disables soft interrupts on that CPU, then grabs the lock. This has the effect of preventing softirqs, tasklets, and bottom halves from running on the local CPU. Here the suffix 'bh' refers to "Bottom Halves".

Unlock:

```
spin unlock bh(spinlock t *lock)
```

It will release the lock and re-enables the soft interrupts which are disabled by the above call.

Example

```
1 //Thread
2 int thread_function(void *pv)
3 2{
4     while(!kthread_should_stop()) {
5         spin_lock_bh(&etx_spinlock);
6     etx_global_variable++;
```

Approach 4 (Locking between Hard IRQ and Bottom Halves)

If you share data between Hardware ISR and Bottom halves then you have to disable the IRQ before lock. Because the bottom halves processing can be interrupted by a hardware interrupt. So this will be used in that scenario.

Lock:

```
spin_lock_irq(spinlock_t *lock)
```

This will disable interrupts on that cpu, then grab the lock.

Unlock:

spin_unlock_irq(spinlock_t *lock)

It will release the lock and re-enables the interrupts which are disabled

X

```
1 /*Tasklet Function*/
  void tasklet fn(unsigned long arg)
3
4
           spin_lock_irq(&etx_spinlock);
5
           etx global variable++;
6
           printk(KERN INFO "Executing Tasklet Function : %lu\n", etx global variable);
7
           spin_unlock_irq(&etx_spinlock);
8 }
10 //Interrupt handler for IRQ 11.
11 static irqreturn_t irq_handler(int irq,void *dev_id) {
12
           spin_lock_irq(&etx_spinlock);
13
           etx_global_variable++;
14
           printk(KERN_INFO "Executing ISR Function : %lu\n", etx_global_variable);
15
           spin_unlock_irq(&etx_spinlock);
16
           /*Scheduling Task to Tasklet*/
17
           tasklet_schedule(tasklet);
18
           return IRQ_HANDLED;
19 }
```

Approach 5 (Alternative way of Approach 4)

If you want to use a different variant rather than using spin_lock_irq() and spin_unlock_irq() then you can use this approach.

Lock:

```
spin lock irqsave( spinlock t *lock, unsigned long flags );
```

This will save whether interrupts were on or off in a **flags** word and grab the lock.

Unlock:

```
spin_unlock_irqrestore( spinlock_t *lock, unsigned long flags );
```

This will release the spinlock and restores the interrupts using the **flags** argument.

2

pproach 6 (Locking between Hard IRQs)

X

programming

This code snippet explains how to create two threads that access a global variable (etx_gloabl_variable). So before accessing the variable, it should lock the spinlock. After that, it will release the spinlock. This example is using Approach 1.

Driver Source Code

```
#include <linux/kernel.h>
2 #include <linux/init.h>
3 #include <linux/module.h>
4 #include <linux/kdev t.h>
5 #include <linux/fs.h>
6 #include <linux/cdev.h>
7 #include <linux/device.h>
8 #include<linux/slab.h>
                                      //kmalloc()
9 #include<linux/uaccess.h>
                                      //copy to/from user()
10 #include <linux/kthread.h>
                                      //kernel threads
11 #include <linux/sched.h>
                                      //task_struct
12 #include <linux/delay.h>
14 DEFINE SPINLOCK(etx spinlock);
15 //spinlock_t etx_spinlock;
16 unsigned long etx_global_variable = 0;
17
18 dev t dev = 0;
19 static struct class *dev class;
20 static struct cdev etx_cdev;
21
22 static int __init etx_driver_init(void);
23 static void __exit etx_driver_exit(void);
24
25 static struct task struct *etx thread1;
26 static struct task struct *etx thread2;
27
28 /************** Driver Fuctions **************/
29 static int etx open(struct inode *inode, struct file *file);
30 static int etx_release(struct inode *inode, struct file *file);
31 static ssize_t etx_read(struct file *filp,
                 char __user *buf, size_t len,loff_t * off);
33 static ssize_t etx_write(struct file *filp,
                 const char *buf, size_t len, loff_t * off);
34
35
   36
37 int thread_function1(void *pv);
  int thread_function2(void *pv);
38
     nt thread_function1(void *pv)
```


```
49
                printk(KERN_INFO "Spinlock is locked in Thread Function1\n");
50
            }
51
            etx_global_variable++;
52
            printk(KERN INFO "In EmbeTronicX Thread Function1 %lu\n", etx global variab
53
            spin_unlock(&etx_spinlock);
54
            msleep(1000);
55
        }
56
        return 0;
57
    }
58
59
    int thread_function2(void *pv)
60
        while(!kthread_should_stop()) {
61
62
            spin_lock(&etx_spinlock);
            etx_global_variable++;
63
            printk(KERN_INFO "In EmbeTronicX Thread Function2 %lu\n", etx_global_variab
64
65
            spin_unlock(&etx_spinlock);
66
            msleep(1000);
67
68
        return 0;
    }
69
70
    static struct file_operations fops =
71
72
    {
                             = THIS MODULE,
73
             .owner
74
            .read
                            = etx_read,
75
             .write
                            = etx_write,
76
            .open
                             = etx_open,
77
             .release
                             = etx_release,
78
    };
79
    static int etx_open(struct inode *inode, struct file *file)
80
81
    {
            printk(KERN_INFO "Device File Opened...!!!\n");
82
83
            return 0;
84
    }
85
86
    static int etx_release(struct inode *inode, struct file *file)
87
    {
            printk(KERN_INFO "Device File Closed...!!!\n");
88
89
            return 0;
90
    }
91
92
    static ssize_t etx_read(struct file *filp,
93
                     char __user *buf, size_t len, loff_t *off)
94
    {
95
            printk(KERN_INFO "Read function\n");
96
97
            return 0;
98
99
    static ssize t etx write(struct file *filp,
100
                     const char __user *buf, size_t len, loff_t *off)
1012 {
102
            printk(KERN INFO "Write Function\n");
            return len;
```


```
112
113
            printk(KERN INFO "Major = %d Minor = %d \n", MAJOR(dev), MINOR(dev));
114
115
             /*Creating cdev structure*/
116
            cdev_init(&etx_cdev,&fops);
117
118
             /*Adding character device to the system*/
119
            if((cdev_add(&etx_cdev,dev,1)) < 0){</pre>
120
                 printk(KERN_INFO "Cannot add the device to the system\n");
121
                 goto r_class;
122
            }
123
124
             /*Creating struct class*/
125
            if((dev_class = class_create(THIS_MODULE, "etx_class")) == NULL){
                 printk(KERN_INFO "Cannot create the struct class\n");
126
127
                 goto r_class;
128
            }
129
             /*Creating device*/
130
131
            if((device_create(dev_class,NULL,dev,NULL,"etx_device")) == NULL){
132
                 printk(KERN_INFO "Cannot create the Device \n");
133
                 goto r_device;
134
            }
135
136
137
            /* Creating Thread 1 */
            etx_thread1 = kthread_run(thread_function1, NULL, "eTx Thread1");
138
139
             if(etx_thread1) {
                 printk(KERN_ERR "Kthread1 Created Successfully...\n");
140
141
             } else {
                 printk(KERN_ERR "Cannot create kthread1\n");
142
143
                  goto r_device;
144
145
146
             /* Creating Thread 2 */
147
             etx_thread2 = kthread_run(thread_function2, NULL, "eTx Thread2");
148
            if(etx_thread2) {
149
                 printk(KERN_ERR "Kthread2 Created Successfully...\n");
150
             } else {
151
                 printk(KERN_ERR "Cannot create kthread2\n");
152
                  goto r_device;
153
154
            //spin_lock_init(&etx_spinlock);
155
156
            printk(KERN_INFO "Device Driver Insert...Done!!!\n");
157
        return 0;
158
159
160 r_device:
161
            class destroy(dev class);
162 r_class:
163
            unregister chrdev region(dev,1);
164
            cdev del(&etx cdev);
165
             return -1;
```


```
175
            unregister_chrdev_region(dev, 1);
            printk(KERN INFO "Device Driver Remove...Done!!\n");
176
177 }
178
179 module_init(etx_driver_init);
180 module_exit(etx_driver_exit);
181
182 MODULE LICENSE("GPL");
183 MODULE_AUTHOR("EmbeTronicX <embetronicx@gmail.com>");
184 MODULE_DESCRIPTION("A simple device driver - Spinlock");
185 MODULE_VERSION("1.18");
MakeFile
1 obj-m += driver.o
3 KDIR = /lib/modules/$(shell uname -r)/build
6
      make -C $(KDIR) M=$(shell pwd) modules
7
8 clean:
      make -C $(KDIR) M=$(shell pwd) clean
In our next part of the tutorial, we will see another variant of the
spinlock (Reader/writer spinlocks).
                                   Article Rating
                                 ****
Share this:
                               in SHARE
(F) Share 10
                                           🖶 Print

    WhatsApp

                         Tweet
                                                                      Share
              Post
                                  Email
                                             1
Like this:
Loading...
                                                                                  Χ
```







_



X