
How to upgrade MERCUSYS Wireless N Router

Notice:

 Please verify the hardware version of your device for the firmware version. Wrong firmware upgrading may damage your device and void the warranty.





After you downloaded the firmware from MERCUSYS website, please use decompression software such as WinZIP or WinRAR to extract the firmware file to a folder, the firmware is usually named as XXXX.bin;

Do NOT upgrade the firmware via wireless connection unless the device does not have cable connection;

Do NOT turn off the power or cut down the Ethernet cable during upgrade process;

It's recommended that users stop all Internet Applications on the computer, or simply disconnect Internet line from the device before upgrade.


Please write down all current settings as a backup and enter them manually after upgrading. Internet Explorer(IE) is the recommended web browser for upgrading firmware.

Step 1 Log into the **MERCUSYS** device by typing http://mwlogin.net/ in the address bar of the web browser (such as Internet Explorer, Firefox), as shown below. Please input the password you preset.



Note: Some of routers are using http://192.168.1.1 or http://192.168.0.1 as the default management address. Please check it on the bottom label.

Step 2 Click **Advanced->System Tools ->Firmware Upgrade**, click the **Browse** button to choose the firmware you already extracted in the folder



Step 3 Click the **Upgrade** button. The device will reboot automatically after the upgrading has been finished. Please wait about 3 minutes.

Step 4 Check the lower right corner of the webpage, verify that the router's firmware has been upgraded.



Step 5 It is recommended that restoring the device to factory default to make the new functions take effect; Click **System Tools**->**Factory Defaults**, Click **Restore** Button

Factory Default Restore



Click the button to restore all the settings to their default values.

Step 6 After restoring factory default, please login to the management page with the default access address such as http://mwlinklogin.net and re-enter the settings you have written down before upgrading.