

Preventive Maintenance Program Guide

Preventive Maintenance · All Machine Types

Doc ID	PM-GEN-001
Version	2.2
Effective Date	2026-02-10
Owner	Maintenance Department
Scope	CNC Milling, Press Line, Assembly Line — all plants

1. Purpose

This guide establishes the preventive maintenance (PM) cadence for all production equipment to reduce unplanned downtime, particularly high-severity codes DT-01 (Hydraulic System Failure) and DT-08 (Spindle/Bearing Failure), which together account for the largest share of major downtime hours.

2. PM Frequency by Machine Type

Machine Type	Daily	Weekly	Monthly	Quarterly
CNC Milling	Coolant level check, chip removal	Spindle vibration check	Tool changer calibration	Bearing/spindle inspection
Press Line	Hydraulic pressure log, oil level	Hose/seal visual inspection	Full hydraulic oil sample analysis	Cylinder seal replacement (as scheduled)
Assembly Line	Conveyor tracking check	Torque tool spot-check	Sensor/limit switch inspection	Full conveyor bearing lubrication

3. Escalation Rule

Any PM finding that indicates imminent failure (e.g. abnormal vibration, oil discoloration, hydraulic pressure drift beyond $\pm 10\%$ of nominal) must be logged immediately in the CMMS and escalated to the shift supervisor for corrective work order, per Plant_Maintenance_Policy section 4.

4. Related Documents

- Lubrication_Schedule.pdf — detailed lubricant type and interval by component
- Inspection_Checklist.pdf — pre-shift, weekly, and monthly checklist forms
- Error_Code_Handbook.pdf — downtime code reference used to trend PM effectiveness