


Assignment 4:

Objective:

- Configure a **DHCP server on router**
- Automatically assign IP addresses to clients
- Set DNS, gateway, and lease time

CREATE A SIMPLE NETWORK



CONFIGURE ROUTER INTERFACE:

```
Router>en
Router#conf t
Enter configuration commands, one per line.  End with CNTL/Z.
Router(config)#int Gig0/0/0
Router(config-if)#ip add 192.168.10.1 255.255.255.0
Router(config-if)#no shut
```

CREATE DHCP POOL:

```
Router(config)#ip dhcp pool xyz
Router(dhcp-config)#network 192.168.10.0 255.255.255.0
Router(dhcp-config)#default-router 192.168.10.1
Router(dhcp-config)#dns-server 1.2.3.4
Router(dhcp-config)#ex
Router(config)#ex
```

DISABLE BOOTP and CONFIGURE CLIENTS