




Trouble : LCD screen is not bright


Solution method:

- 1、 Confirm whether the power supply is normal ;
- 2、 Confirm the LCD screen on the EXP1, EXP2 port is connected with the EXP1, EXP2 port on the motherboard, and no loose or poor contact




(Main board power indicator light, power supply is normal)

(LCD screen)




(Motherboard)




Trouble : Rotation button can not be up and down the selection menu

(By rotating the button on the left side of the pointer
can be up and down the selection menu)



(Normal figure)

(No response to the left pointer by the rotation button)



(Abnormal figure)

(Solution method) :

(Confirm that the EXP2 interface is properly connected, and that there is no contact with the bad phenomenon) ;

(LCD screen)



(Motherboard)

