Step:1

Please connect your modem with Ethernet cable. Open the internet browser and type 192.168.1.1, give username and password as "admin"

Following window shall be displayed:



Device Info Advanced Setup Wireless Diagnostics Management

Easy Installation

Configure the user name and password of PPPoE.

Advance Settings

Add, Edit, or Remove to configure WAN interfaces.

Note: Refresh or Re-login can back to this page

Step:2




WAN Info

Device Info Summary WAN Statistics Route ARP DHCP Advanced Setup Wireless Diagnostics Management

Port/VPI/VCI	VLAN Mux	Con. ID	Category	Service	Interface	Protocol	Igmp	QoS	State	Status	IP Address
0/0/103	Off	1	UBR	pppoe_0_0_103_2	ppp_0_0_103_1	PPPoE	Disabled	Disabled	Enabled	PPP Down	
0/8/81	Off	1	UBR	pppoe_0_8_81_2	ppp_0_8_81_1	PPPoE	Enabled	Disabled	Enabled	Up	39.47.28.5
0/0/102	Off	1	UBR	br_0_0_102	nas_0_0_102	Bridge	N/A	Disabled	Enabled	Up	3
0/0/35	Off	1	UBR	br_0_0_35	nas_0_0_35	Bridge	N/A	Enabled	Enabled	Up	


^{1.} The record for which IP address is shown in the last column is the active WAN profile of the modem. Or Authentication failure message will be displayed in the same column


Step:3



Device Info	ATM PVC Configuration This screen allows you to configure an ATM PVC identifier (PORT and VPI and VCI) and select a service category. Otherwise choose an existing interface by selecting the checkbox to enable it.
Advanced Setup WAN LAN NAT	VPI: [0-255] 0 VCI: [32-65535] 35
Security Quality of Service Routing	VLAN Mux - Enable Multiple Protocols Over a Single PVC
DNS DSL	Service Category: UBR Without PCR 🔻
Port Mapping IPSec	Enable Quality Of Service
Certificate Wireless	Enabling packet level QoS for a PVC improves performance for selected classes of applications. QoS cannot be set for CBR and Realtime VBR. QoS consumes system resources; therefore the number of PVCs will be reduced. Use Advanced Setup/Quality of Service to assign priorities for the applications.
Diagnostics Management	Enable Quality Of Service
	Back Next

Step:5





Step:7



Device Info Advanced Setup

WAN

LAN NAT

Security

Quality of Service

Routing

DNS

Port Mapping

IPSec

Certificate

Wireless

Diagnostics

Management

WAN Setup - Summary

Make sure that the settings below match the settings provided by your ISP.

PORT / VPI / VCI:	0 / 0 / 35			
Connection Type:	Bridge			
Service Name:	br_0_0_35			
Service Category:	UBR			
IP Address:	Not Applicable			
Service State:	Enabled			
NAT:	Disabled			
Firewall:	Disabled			
IGMP Multicast:	Not Applicable			
Quality Of Service:	Enabled			

Click "Save" to save these settings. Click "Back" to make any modifications.

NOTE: You need to reboot to activate this WAN interface and further configure services over this interface.



