Estação	SN	Máquina	Berço	Data	Resultado	Parâmetros
FCT	94011800551900	TPVMAO115	В3	2025-02-27 19:46:05	FAIL	ReadMSN
FCT	94011800544076	TPVMAO115	В3	2025-02-27 19:12:19	FAIL	ReadMSN
FCT	94011800558184	TPVMAO115	В3	2025-02-27 16:45:04	FAIL	TP50_low_U15
FCT	94011800558184	TPVMAO115	В3	2025-02-27 16:39:01	FAIL	TP50_low_U15
FCT	94011800551812	TPVMAO115	В3	2025-02-27 16:36:56	FAIL	TP50_low_U15
FCT	94011800558512	TPVMAO115	В3	2025-02-27 16:33:11	FAIL	TP120_V
FCT	94011800559068	TPVMAO115	В3	2025-02-27 11:58:16	FAIL	TP182-TP191_V
FCT	94011800559068	TPVMAO115	В3	2025-02-27 11:58:16	FAIL	TP182-TP191_T
FCT	94011800559068	TPVMAO115	В3	2025-02-27 11:58:16	FAIL	TP194-TP191_V
FCT	94011800559068	TPVMAO115	В3	2025-02-27 11:58:16	FAIL	TP194-TP191_T
FCT	94011800542492	TPVMAO115	В3	2025-02-27 11:56:04	FAIL	TP182-TP191_V
FCT	94011800542492	TPVMAO115	В3	2025-02-27 11:56:04	FAIL	TP182-TP191_T
FCT	94011800542492	TPVMAO115	В3	2025-02-27 11:56:04	FAIL	TP194-TP191_V
FCT	94011800542492	TPVMAO115	В3	2025-02-27 11:56:04	FAIL	TP194-TP191_T
FCT	94011800552936	TPVMAO115	В3	2025-02-24 23:35:35	FAIL	TP120_V
FCT	94011800550024	TPVMAO115	В3	2025-02-24 20:32:30	FAIL	TP120_V
FCT	94011800551700	TPVMAO115	В3	2025-02-24 20:29:45	FAIL	TP120_V
FCT	94011800550024	TPVMAO115	В3	2025-02-24 20:28:25	FAIL	TP120_V
FCT	94011800552340	TPVMAO115	В3	2025-02-24 20:16:12	FAIL	TP194-TP191_V
FCT	94011800552340	TPVMAO115	В3	2025-02-24 20:16:12	FAIL	TP194-TP191_T
FCT	94011800552340	TPVMAO115	В3	2025-02-24 20:16:12	FAIL	TP182-TP191_V
FCT	94011800552340	TPVMAO115	В3	2025-02-24 20:16:12	FAIL	TP182-TP191_T
FCT	94011800551976	TPVMAO115	В3	2025-02-24 19:51:59	FAIL	TP182-TP191_V
FCT	94011800551976	TPVMAO115	В3	2025-02-24 19:51:59	FAIL	TP182-TP191_T
FCT	94011800551976	TPVMAO115	В3	2025-02-24 19:51:59	FAIL	TP194-TP191_V
FCT	94011800551976	TPVMAO115	В3	2025-02-24 19:51:59	FAIL	TP194-TP191_T
FCT	94011800552112	TPVMAO115	В3	2025-02-24 19:34:52	FAIL	TP182-TP191_V
FCT	94011800552112	TPVMAO115	В3	2025-02-24 19:34:52	FAIL	TP182-TP191_T
FCT	94011800552112	TPVMAO115	В3	2025-02-24 19:34:52	FAIL	TP194-TP191_V

FCT	94011800552112	TPVMAO115	В3	2025-02-24 19:34:52	FAIL	TP194-TP191_T
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	TP161
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	TP42
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	TP156
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	TP120_V
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	TP120_F
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	ReadMSN
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	HwVer
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	TP38
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	TP61
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	TP230
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	TP9
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	SwVerFix
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	DefaultCalValRVGain
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	CALCMD_UPDATE
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	SwVer
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	MeterTypeSel_1
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	MeterType
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	TP182-TP191_T
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	TP194-TP191_V
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	TP50_high_1
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	TP50_high_2
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	Modem
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	TP182-TP191_V
FCT	94011800463334	TPVMAO115	В3	2025-02-24 16:45:11	FAIL	TP194-TP191_T
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	TP38
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	TP61
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	TP230
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	TP9
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	TP42

FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	TP156
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	TP161
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	TP120_V
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	TP120_F
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	ReadMSN
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	HwVer
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	SwVer
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	SwVerFix
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	DefaultCalValRVGain
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	CALCMD_UPDATE
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	MeterTypeSel_1
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	MeterType
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	Modem
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	TP182-TP191_V
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	TP182-TP191_T
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	TP194-TP191_V
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	TP194-TP191_T
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	TP50_high_1
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	TP50_low_U14
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	TP50_high_2
FCT	94011800466456	TPVMAO115	В3	2025-02-24 15:37:14	FAIL	TP50_low_U15
FCT	94011800466448	TPVMAO115	В3	2025-02-24 15:32:25	FAIL	TP189_low
FCT	94011800466448	TPVMAO115	В3	2025-02-24 15:32:25	FAIL	TP189_high
FCT	94011800466448	TPVMAO115	В3	2025-02-24 15:32:25	FAIL	TP50_low_U15
FCT	94011800466448	TPVMAO115	В3	2025-02-24 15:32:25	FAIL	TP50_low_U14
FCT	94011800466448	TPVMAO115	В3	2025-02-24 15:32:25	FAIL	TP50_high_2
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	TP61
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	TP38
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	TP9
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	TP230
						•

FCT	94011800440881	TPVMAO115	B3	2025-02-24 14:59:39	FAIL	TP156
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	TP161
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	TP42
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	TP120_V
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	ReadMSN
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	HwVer
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	TP120_F
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	TP194-TP191_T
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	TP182-TP191_T
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	TP194-TP191_V
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	Modem
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	TP182-TP191_V
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	SwVer
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	SwVerFix
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	DefaultCalValRVGain
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	CALCMD_UPDATE
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	MeterTypeSel_1
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	MeterType
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	TP50_high_2
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:59:39	FAIL	TP50_high_1
FCT	94011800451112	TPVMAO115	В3	2025-02-24 14:48:07	FAIL	TP120_V
FCT	94011800440881	TPVMAO115	В3	2025-02-24 14:37:27	FAIL	MeterType
FCT	94011800465992	TPVMAO115	В3	2025-02-24 14:32:13	FAIL	TP50_low_U15
FCT	94011800463332	TPVMAO115	В3	2025-02-24 14:30:39	FAIL	TP50_high_2
FCT	94011800463332	TPVMAO115	В3	2025-02-24 14:30:39	FAIL	TP189_high
FCT	94011800463332	TPVMAO115	В3	2025-02-24 14:30:39	FAIL	TP50_low_U15
FCT	94011800451112	TPVMAO115	В3	2025-02-24 14:04:43	FAIL	TP120_V
FCT	94011800438448	TPVMAO115	В3	2025-02-24 11:42:52	FAIL	MeterTypeSel_1