


# Experimental Methods Lecture 24

November 16<sup>th</sup>, 2020

- Critical noise parameters for a 2-port device • Noise at input  $V_n^{in} = V_n + I_n Z_s$
- Before proceeding further let's give a few important definitions:
- 1. Noise energy or temperature  $E_n(\omega) = k_B T_n(\omega) = \sqrt{S_{V_n V_n}(\omega)} S_{I_n I_n}(\omega)$
- 2. Noise Resistance  $R_n(\omega) = \sqrt{S_{V_n V_n}(\omega)/S_{I_n I_n}(\omega)}$
- 3. Noise cross-coherence  $\rho_{n}(\omega) = S_{V,I}(\omega) / \sqrt{S_{V,V}(\omega)S_{I,I}(\omega)}$
- Inverting these definitions 1. Voltage PSD:  $S_{V_n V_n}(\omega) = k_B T_n(\omega) R_n(\omega)$
- 2. Current PSD  $S_{I_n I_n}(\omega) = k_B T_n(\omega) / R_n(\omega)$
- 3. Voltage-current cross spectrum  $S_{V_n I_n}(\omega) = k_B T_n(\omega) \rho_n(\omega)$



#### Minimizing noise by impedance matching



• Total noise PSD at input, at a given frequency 
$$S_{V_{n}^{in}V_{n}^{in}}(\omega) = k_{B}T_{n}(\omega) \left[ R_{n}(\omega) + \left| Z_{s}(\omega) \right|^{2} / R_{n}(\omega) + 2 \operatorname{Re} \left\{ Z_{s}(\omega) \rho_{n}(\omega) \right\} \right]$$

Can be minimized by adjusting  $R_n$ 

$$\partial S_{V_n^{in}V_n^{in}}(\omega) / \partial R_n(\omega) = k_B T_n(\omega) \left[ 1 - \left| Z_s(\omega) \right|^2 / R_n^2(\omega) \right] = 0$$

- That gives  $R_n(\omega) = |Z_s(\omega)|$ 
  - When this condition is fulfilled the contribution of voltage noise and of current noise become equal and the PSD becomes

$$S_{V_{n}^{in}V_{n}^{in}}(\omega) = 2k_{B}T_{n}(\omega)\left[\left|Z_{s}(\omega)\right| + Re\left\{Z_{s}(\omega)\rho_{n}(\omega)\right\}\right]$$

• Or, for uncorrelated generators

S<sub>V<sup>in</sup>V<sup>in</sup></sub> 
$$(\omega) = 2k_B T_n(\omega) |Z_s(\omega)|$$

Watch out! This is not Nyquist law, and T<sub>n</sub> is not T

#### Noise figure and matched source



• From the PSD

$$S_{V_{n}^{in}V_{n}^{in}} = k_{B}T_{n} \left[ R_{n} + \left| Z_{s} \right|^{2} / R_{n} + 2 Re \left\{ Z_{s} \rho_{n} \right\} \right] + 2k_{B}TRe \left\{ Z_{s} \right\}$$


• We define the noise figure as the ratio, *measured in decibels*, between the total noise PSD and that of the thermal noise alone

$$F = 20 \text{Log}_{10} \left\{ \frac{k_{\text{B}} T_{\text{n}} \left[ R_{\text{n}} + \left| Z_{\text{s}} \right|^{2} / R_{\text{n}} + 2 \text{Re} \left\{ Z_{\text{s}} \rho_{\text{n}} \right\} \right] + 2 k_{\text{B}} T \text{Re} \left\{ Z_{\text{s}} \right\}}{2 k_{\text{B}} T \text{Re} \left\{ Z_{\text{s}} \right\}} \right\}$$
• That is 
$$F = 20 \text{Log}_{10} \left\{ 1 + \frac{T_{\text{n}}}{T} \left[ \frac{R_{\text{n}}}{2 \text{Re} \left\{ Z_{\text{s}} \right\}} + \frac{\left| Z_{\text{s}} \right|^{2}}{2 R_{\text{n}} \text{Re} \left\{ Z_{\text{s}} \right\}} + \frac{\text{Re} \left\{ Z_{\text{s}} \rho_{\text{n}} \right\}}{\text{Re} \left\{ Z_{\text{s}} \right\}} \right] \right\}$$

- For uncorrelated noise sources this figure has a minimum when
- Whose value is  $F_{\min} = 20 \text{Log}_{10} \left\{ 1 + \frac{T_n}{T} \right\}$

## The meaning of noise energy. One example: charge detector

- A charge detector consisting of a lossy capacitor read out by a low noise amplifier. I<sub>th</sub> is the Nyquist current noise generator associated with R. We will assume V<sub>n</sub> and I<sub>n</sub> to be uncorrelated.
- The signal at input consists of a single charge e. That is, the signal consists of a current impulse  $I(t)=e\delta(t)$
- What is the minimum measurable value of e, given the amplifier noise temperature and resistance?



AA 2020-2021

S. Vitale

#### Charge uncertainty



• Thus,

$$\sigma_e = \sqrt{2S_{Io}\tau}$$

And

$$S_{I_{n,e}I_{n,e}}(\omega) = \left(S_{I'_{n}I'_{n}} + \frac{S_{V_{n}V_{n}}}{R^{2}}\right) \left(1 + \frac{S_{V_{n}V_{n}}C^{2}}{S_{I'_{n}I'_{n}} + \frac{S_{V_{n}V_{n}}}{R^{2}}}\omega^{2}\right)$$

• with

$$S_{I_{n,e}I_{n,e}}(\omega) = S_{Io}(1 + \tau^2 \omega^2)$$

• Then

$$\sigma_{e} = \sqrt{2\left(S_{I_{n}^{\prime}I_{n}^{\prime}} + \frac{S_{V_{n}V_{n}}}{R^{2}}\right)\sqrt{\frac{S_{V_{n}V_{n}}C^{2}}{S_{I_{n}^{\prime}I_{n}^{\prime}} + \frac{S_{V_{n}V_{n}}}{R^{2}}}} = \sqrt{2C}\left(S_{V_{n}V_{n}}\left(S_{I_{n}^{\prime}I_{n}^{\prime}} + \frac{S_{V_{n}V_{n}}}{R^{2}}\right)\right)^{\frac{1}{4}}$$

- Now take the limit for  $R \to \infty$  (low dissipations)
- Then

$$\sigma_e \to \sqrt{2C\sqrt{S_{V_nV_n}S_{I_n'I_n'}}} = \sqrt{2\ Ck_BT_n'}$$

#### The noise energy



• In conclusion

$$\sigma_e = \sqrt{2 \ C k_B T_n'}$$

• Now suppose that a charge  $\sigma_e$  is deposited on the capacitor. This will get an energy

$$E = \frac{1}{2}C\sigma_e^2 = k_B T_n'$$

- This is the crucial result: the minimum detectable energy is the noise energy of the amplifier
- Notice that if  $T \to 0$   $T'_n \to T_n$  as the thermal noise becomes negligible




#### Total noise at input

Total equivalent current noise through Z

$$S_{I_{n}I_{n}} = S_{Io}(1 + \omega^{2}\tau^{2})$$

$$S_{Io} = \frac{2k_{B}T}{R} + \frac{k_{B}T_{n}}{R_{n}} + \frac{k_{B}T_{n}R_{n}}{R^{2}} \quad \tau^{2} = C^{2}R_{n}^{2} \frac{T_{n}/R_{n}}{\frac{2T}{R} + \frac{T_{n}}{R_{n}} + \frac{T_{n}R_{n}}{R^{2}}}$$

• For  $R \to \infty$   $S_{Io} \to \frac{k_B T_n}{R_n}$   $\tau \to C R_n$ 



AA 2020-2021

#### charge detector



- The template.
  - The (unit-amplitude) signal


$$f(\omega) = Z(\omega)$$

- Noise

$$S_{V_iV_i}(\omega) = S_{I'_nI'_n}|Z(\omega)|^2 + S_{V'_nV'_n}$$

Template

$$h(\omega) = \frac{\sigma_e^2 Z(\omega)}{S_{I'_n I'_n} |Z(\omega)|^2 + S_{V'_n V'_n}} = \frac{\sigma_e^2}{S_{Io} (1 + \omega^2 \tau^2)} \frac{Z(\omega)}{|Z(\omega)|^2}$$



#### Example: charge detector




Continuing

$$h(\omega) = \frac{\sigma_e^2 Z(\omega)}{S_{I'_n I'_n} |Z(\omega)|^2 + S_{V'_n V'_n}} = \frac{\sigma_e^2}{S_{Io} (1 + \omega^2 \tau^2)} \frac{Z(\omega)}{|Z(\omega)|^2}$$
$$= \frac{\sigma_e^2}{S_{Io} (1 + \omega^2 \tau^2)} \frac{1}{Z(\omega)^*} = \frac{\sigma_e^2}{S_{Io} R} \frac{1 - i\omega RC}{1 + \omega^2 \tau^2}$$

• Remember  $\sigma_e^2 = 2S_{Io}\tau$  then

$$h(\omega) = \frac{2\tau}{R} \frac{1 - i\omega RC}{1 + \omega^2 \tau^2}$$



### The optimum template



• The filter template:

$$h(\omega) = \frac{2\tau}{R} \frac{1 - i\omega RC}{(1 + \omega^2 \tau^2)}$$

• Fourier transform:


$$\frac{2\tau}{(1+\omega^2\tau^2)} \to e^{-\frac{|t|}{\tau}}$$

$$\frac{2\tau i\omega RC}{(1+\omega^2\tau^2)} \text{ is the Fourier transform of } RC\frac{d}{dt}\left(e^{-\frac{|t|}{\tau}}\right) \to -\frac{RC}{\tau}e^{-\frac{|t|}{\tau}}Sign[t]$$

• Thus

$$h(t) = \frac{1}{R}e^{-\frac{|t|}{\tau_e}}\left(1 + \frac{RC}{\tau}Sign[t]\right) \to \lim_{R \to \infty} h(t) = \frac{1}{R_n}e^{-\frac{|t|}{\tau_e}}Sign[t]$$

A numerical example is shown here:




## The optimum template

The filter template h(t) ≃ 1/R<sub>n</sub> e<sup>-|t|</sup>/<sub>\tau</sub> Sign[t].
 Multiplication by the data and integration delivers the time average of the data over a time ≃ τ after the charge arrival time (supposed to be

known) minus the average, again over a time  $\simeq \tau$ , before the arrival

- of the charge.

   As the arrival of the charge causes a step ( an exponential decaying over a time  $RC \gg \tau$ ), the above procedure will estimate the height of the step.
- Integrating longer than  $\tau$  will decrease the effect of voltage noise, that ramps up at high frequency, but will enhance that of current noise that can simulate a step if given the right amount of time.  $\tau$  is the optimal integration time





# Frequency conversion and narrow-band signals

#### Introduction: frequency conversion




- PSD of most disturbances is not white, thus frequency ranges where the noise is lower may allow high precision measurements otherwise made impossible by low SNR.
- Thus in many experiments, physicists need changing the frequency of a signal and moving it to frequencies where PSD of disturbances is lower. This is called frequency conversion.

AA 2020-2021 S. Vitale 14

#### Example 1: infrared detection



- There is a common problem in application of visible-infrared optics shared by astronomy, laboratory spectroscopy etc. We will use infrared astronomy as an example, but all considerations applies to the remaining applications too.
- In infrared astronomy the source signal, typically a star image from a telescope, is basically at 0 frequency. For instance the telescope may be pointed to the star and the light intensity on one pixel of the photodetector be recorded for some measurement time T. By subtracting the intensity signal measured when the telescope was pointing to the empty sky, one can measure the intensity due to the source. The signal in time looks then like a "box" function  $I(t) = I_0 \Pi(t/T)$



AA 2020-2021 S. Vitale 1

## Detecting a box signal



• The Fourier transform of a box is notoriously  $I(\omega) = I_o T Sinc(\omega T/2)$ 

• If the PSD of total intensity noise in the photo-detector is 
$$S_{II}(\omega)$$
, the minimum error on  $I_o$  is


$$\sigma_{I_o} = \left\{ \left( \frac{1}{2\pi} \right) \int_{-\infty}^{\infty} d\omega \left( T^2 \left[ \text{Sinc}(\omega T/2) \right]^2 / S_{II}(\omega) \right) \right\}^{-1/2}$$

- Most of the SNR is concentrated in the frequency range where the signal has the highest energy density  $|\omega| \le 2\pi/T$ .
- On the other hand the error decreases as

  1/T<sup>1/2</sup> forcing then to use long enough

  observation times, and then concentrating the

  signal at lower frequency
- Low frequencies are noisy! See next page.



Noise can be very "red", that is very intense at low frequency. Here below is shown just the contribution of the sky background. Add low-frequency electronic noise, mechanical drift etc.

#### The processing of infrared sky noise by chopping, nodding and filtering

R. Papoular

Section d'Astrophysique, Centre d'Etudes Nucléaires de Saclay, F-91191 Gif-sur-Yvette Cedex, France

Received June 22, accepted August 24, 1982

Summary. The available observations of sky fluctuations have been used to define their spectrum and space correlation properties. Using these, it was possible to follow the noise content throughout the different stages of IR signal processing, and thus determine the detection sensitivity and its depence on the system parameters. It was found that the ultimate sensitivity is set by the photon noise component, a limit which, with the current nodding technique, can only be reached under very stringent mechanical, optical and meteorological conditions. It is shown that, when these conditions are not perfectly matched, the actual sensitivity can be improved if the nodding rate is increased or if an array of several detectors is used. The gain is most significant in the mid-infrared and can be traded against a much larger gain in observation time.

Key words: sky noise - chopping - nodding - infrared





Fig. 1. Typical spectral power densities of background fluctuations

AA 2020-2021 S. Vitale

### Shifting the frequency of the signal



• A classical way out of this problem is the chopper. Light is collected through a rotatable mirror that can be tilted back and forth, by a large enough angle to switch from the star to empty sky. Tilting is repeated periodically so that the intensity signal becomes a square wave at the frequency  $\omega_0$  of the tilt.  $I_0$  becomes the amplitude of the wave.



• For such a signal, if the duration is T, we the know that the error on the estimate of I<sub>0</sub> is approximately

$$\sigma_{I_o} = \sqrt{2S_{II}(\omega_o)/T}$$

By picking the proper frequency, usually the highest compatible with the mechanics of the mirror, the error can be minimized



Proposal Calls

SOFIA Research FAOs

SOFIA Science Councils

Mission Schedule

Workshops

#### Information for Researchers

Home > Information for Researchers > Overview of SOFIA

#### 30FIA Telescope

#### **Overview of SOFIA**


The Stratospheric Observatory for Infrared Astronomy (SOFIA) is a 2.7 meter telescope (with an effective aperture of 2.5 m) carried aboard a Boeing 747-SP aircraft. It is the successor to the smaller Kuiper Airborne Observatory (KAO), which was operated by **NASA** 

SOFIA is a joint project of NASA and the Deutsches Zentrum für Luft- und Raumfahrt (DLR, the German Space Agency). Flight


Under an agreement with NASA, DLR (the German Aerospace Center) supplied the telescope for the SOFIA observatory, as well as operation support, in exchange for observation time aboard the SOFIA.

UNIVERSITÀ DEGLI STUDI

The SOFIA telescope consists of a parabolic 2.7m primary mirror and a hyperbolic secondary mirror in a bent Cassegrain configuration with two Nasmyth foci, the nominal IR focus and an additional visible light focus for guiding. The secondary mirror is attached to a chopping mechanism providing chop amplitudes of up to ± 5 arcmin at chop frequencies between 0 and 20 Hz, programmable by either a user supplied analogue or TTL curve or by the telescope control electronics. A flat tertiary mirror reflects the IR beam into the infrared Nasmyth focus, 300mm behind the instrument flange. If the fully reflecting tertiary is replaced with a dichroic mirror, the transmitted optical light is reflected by a second tertiary 289.2mm behind the dichroic and sent to the visible Nasmyth focus. There it is fed into the Focal Plane Imager (FPI), an optical focal plane guiding camera system. Independent of the FPI there are two other imaging and guiding cameras available: the Wide Field Imager (WFI) and the Fine Field Imager (FFI). Both of these cameras are attached to the front ring of the telescope.




## An example form laboratory spectroscopy. the chopper



Opto-switch






Light intensity signal modulates the amplitude of a square wave carrier

AA 2020-2021 S. Vitale 20

## A second example: measuring thermal forces on a free body

- The body is LISA Pathfinder test mass. Thermal gradient induce forces because of:
  - Larger momentum transferred by hottest molecules in the residual very low gas pressure (radiometric effect)
  - Infrared (black-body) radiation pressure becomes asymmetric
  - Gas molecules trapped on hot surfaces get off more easily than from colder surfaces

PHYSICAL REVIEW D 76, 102003 (2007) Hot X<sub>+</sub> face



S. Vitale AA 2020-2021


#### Thermal gradient forces


S. Vitale



• Forces (torques) are measured with a torsion pendulum, by looking at the pendulum rotation

• Gradients may be applied via a set of heaters







#### Thermal gradient forces



Applying a steady gradient and looking at the steady rotation of the pendulum suffers from the usual problem of low frequency noise






• Pendulum equivalent torque noise: a sweet spot around 2 mHz+ a 1/f<sup>2</sup> branch at low frequency going worse below 0.1 mHz

#### UNIVERSITÀ DEGLI STUD DI TRENTO

#### Thermal gradient forces

- The trick: make the gradient oscillating by switching heaters on and off
- Ideal would be 2 mHz (noise minimum). Achievable, limited by thermal relaxation time, 0.5 mHz. Torque noise  $\approx$ 6 fN m/ $\sqrt{\text{Hz}}$
- Resolution over 1 hour integration  $\simeq$  (6 fN m/ $\sqrt{\text{Hz}}$ ) / $\sqrt{3600}$ s =0.1 fN m



#### Frequency conversion and the mixer



- Thus in many experiments, one need to change (increase) the frequency of a signal.
- Linear systems *cannot* change signal frequency. To achieve frequency conversion you need some non-linear element. The most important example of such an element is the multiplier or *mixer*.
- The mixer is an ideal memory-less element that performs the product of two input signals like in the following scheme.

$$i_{1}(t) \longrightarrow b$$

$$i_{2}(t) \longrightarrow b$$

$$i_{2}(t) \longrightarrow b$$

$$i_{2}(t) \longrightarrow b$$

• The chopper is a mixer!


$$\frac{I(t)}{(1+\operatorname{Sign}[\operatorname{Sin}(\omega_{o}t)])/2} \times \longrightarrow o(t)$$
AA 2020-2021

S. Vitale

#### The more general narrow band signal



• Suppose you have two (slowly varying signals) a(t) and b(t). You may use two mixers to multiply them by the two phase of a "carrier" at frequency  $\omega_0$ , according to the following scheme:



- And generate a "narrow-band signal" at the "carrier frequency"  $\omega_o$
- a(t) is called the "in-phase" component of the signal and b(t) the "quadrature" component.


AA 2020-2021 S. Vitale 26

## AM radio

- The sound signal from a microphone modulates the amplitude of an electromagnetic carrier at frequency  $\omega_o$
- The electromagnetic signal s(t) is  $s(t) = s_o [1 + m(t)] Sin(\omega_o t + \phi)$
- $s_o$  and  $\phi$  are constants. Max(|m(t)|) is called the modulation depth
- Notice that the signal can be re-written as  $s(t) = s_o \left[ 1 + m(t) \right] Cos(\phi) Sin(\omega_o t) + s_o \left[ 1 + m(t) \right] Sin(\phi) Cos(\omega_o t)$
- Thus the in phase and quadrature

components are
$$a(t) = s_o [1 + m(t)] Cos(\phi)$$

$$b(t) = s_o [1 + m(t)] Sin(\phi)$$



AA 2020-2021

S. Vitale

#### FM Radio



Modulating signal

• The sound signal modulates the phase of an electromagnetic carrier

$$s(t) = s_o Sin(\omega_o t + \phi(t)) \equiv s_o Sin(\phi(t))$$

• The instantaneous frequency is

$$\omega(t) = \dot{\varphi}(t) = \omega_o + \dot{\varphi}(t)$$

And the modulation depth is

$$\operatorname{Max}\left(\left|\dot{\phi}(t)\right|\right)/\omega_{o}$$

• Also this signal can be written in the general form

$$s(t) = s_o Cos[\phi(t)]Sin(\omega_o t) + s_o Sin[\phi(t)]Cos(\omega_o t)$$

So that

$$a(t) = s_o Cos[\phi(t)]$$
$$b(t) = s_o Sin[\phi(t)]$$