在不使用 NetApp Docker 映像的情况下□行 Ansible 攻略手册

Active IQ Digital Advisor

netapp-manishc, Reenu Jojo
July 13, 2021

This PDF was generated from https://docs.netapp.com/zh-cn/active-iq/task_execute_ansible_playbook_without_docker.html on July 23, 2021. Always check docs.netapp.com for the latest.

目□

在不使用 NetApp Docker 映像的情况下□行 Ansible 攻略手册 1

在不使用 NetApp Docker 映像的情况下□行 Ansible 攻略手册

□□

1. 安装 "Python" 和 。
2. 使用 * pip* 安装所需的 Python □件包：

```
$ pip install netapp-lib requests paramiko

Installing collected packages: netapp-lib, requests, paramiko
Successfully installed netapp-lib-2020.3.12 requests-2.23.0 paramiko-
2.7.2
```

3. 使用 * 可□星系 * 命令安装 NetApp Ansible □料集：

```
To install the collection only for the current user
$ ansible-galaxy collection install netapp.ontap

To do a more universal installation,
$ ansible-galaxy collection install netapp.ontap -p
/usr/share/ansible/collections

$ chmod -R +rw /usr/share/ansible/collections
```

有□ Ansible galxy 命令的□□信息，□参□ "Ansible GALAXY 文□" 有□ NetApp Ansible □料集的□□信息，□参□ 。

4. 使用 * Ansible 攻略手册 * 命令□行 Ansible 攻略手册：

```
$ cd <downloaded_playbook_path>
$ ansible-playbook na_ontap_pb_upgrade_firmware.yml

Enter your ONTAP admin username: ****
Enter the password for your ONTAP admin user: ****
Enter the base URL to the firmware package (using HTTP is recommended):
http://<web-server>/path/
PLAY [ONTAP Firmware Upgrade]
*****************************************************************
```

> 如果有一□集群使用不同的登□凭据，□必□在□个集群上□行 Ansible 攻略手册。不需要更改清□文件，因□ Ansible 攻略手册会跳□登□失□的集群。

有□ * 安全攻略手册 * 命令的□□信息，□参□ "Ansible 攻略手册文□" 要在□□模式（□□行）下□行 Ansible 攻略手册，□参□ 。

□行攻略手册后，□参□ "固件安装□□" 用于□行后的□明。

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.