拡張の概要

HCI

Ann-Marie Grissino, Michael Wallis, Dave Bagwell, amitha, Aksel Davis
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/concept_hcc_expandoverview.html on July 01, 2021. Always check docs.netapp.com for the latest.

目次

拡張の概要 1

拡張の概要

NetApp HCI システムは、 NetApp Hybrid Cloud Control を使用して拡張できます。ストレージリソースとコンピューティングリソースは、個別に拡張することも、同時に拡張することもできます。

> 新規およびスペアの H610S ストレージノードには、既存の Element ソフトウェアバージョンのストレージクラスタに基づいて追加のインストール要件がある場合があります。詳細については、ネットアップサポートにお問い合わせください。

NetApp HCI シャーシにノードを設置したら、 NetApp Hybrid Cloud Control を使用して、新しいリソースを使用するように NetApp HCI を設定します。NetApp HCI は既存のネットワーク設定を検出し、既存のネットワークと VLAN （存在する場合）内に設定オプションを提供します。

> インストール環境を拡張したあとに新しいアセットが構成に自動的に追加されなかった場合は、アセットを手動で追加しなければならないことがあります。を参照してください "管理ノードの概要"。

NetApp HCI は、 VMware Enhanced vMotion Compatibility （ EVC ）を使用して、 vSphere クラスタに CPU 世代が異なる複数のコンピューティングノードがある場合の vMotion を可能にします。拡張に EVC が必要な場合、 NetApp HCI は可能な場合は自動的に EVC を有効にします。

次の場合は、 vSphere クライアントで EVC の設定を手動で変更しなければならないことがあります。

- 既存のコンピューティングノードの CPU 世代が追加するコンピューティングノードよりも新しい。
- 制御用 vCenter インスタンスで必要な EVC レベルがサポートされていない。
- 追加するコンピューティングノードの CPU 世代が制御用 vCenter インスタンスの EVC 設定よりも古い。

> NetApp Deployment Engine で NetApp HCI のコンピューティングリソースまたはストレージリソースを拡張する場合は、既存の NetApp HCI コンピューティングノードを管理する vCenter インスタンスに接続してください。

詳細については、こちらをご覧ください

- "NetApp HCI コンピューティングリソースを展開します"
- "NetApp HCI ストレージリソースを展開します"
- "NetApp HCI のストレージリソースとコンピューティングリソースも同時に拡張します 時間"
- "NetApp HCI のリソースページ"
- "vCenter Server 向け NetApp Element プラグイン"

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.