を使用して、 NetApp HCI システムの vSphere コンポーネントをアップグレードします vCenter Server 向け Element プラグイン HCI

dbag-personal, Ann-Marie Grissino, Dave Bagwell, Aksel Davis
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/task_hci_upgrade_all_vsphere.html on July 01, 2021. Always check docs.netapp.com for the latest.

目次

を使用して、 NetApp HCI システムの vSphere コンポーネントをアップグレードします vCenter Server 向け Element プラグイン 1

を使用して、 NetApp HCI システムの vSphere コンポーネントをアップグレードします vCenter Server 向け Element プラグイン

NetApp HCI 環境の VMware vSphere コンポーネントをアップグレードするときは、Element Plug-in for vCenter Server についていくつかの追加の手順を実行する必要があります。

手順

1. vCSA のアップグレード "クリア" プラグインの QoSSIOC 設定（ * NetApp Element Configuration > QoSSIOC Settings * ）。[**QoSSIOC Status**] フィールドには、プロセスの完了後に「 Not Configured 」と表示されます。
2. vCSA と Windows のアップグレード "登録解除します" 登録ユーティリティを使用してプラグインを関連付けられている vCenter Server からプラグインを削除します。
3. "vCenter Server 、 ESXi 、 VM 、その他の VMware コンポーネントを含む vSphere をアップグレードします"。

> 用のコンピューティングノードの ESXi をアップグレードする場合 "2 ノードクラスタ" では、一度に 1 つのコンピューティングノードのみをアップグレードして、一時的に 1 つの監視ノードのみが使用不能になり、クラスタクォーラムを維持できるようにします。

4. "登録" vCenter で Element Plug-in for vCenter Server を再度実行します。
5. "クラスタを追加" プラグインを使用する。
6. "QoSSIOC を設定します" プラグインを使用する。
7. "QoSSIOC を有効にします" プラグインで制御されているすべてのデータストアが対象です。

詳細については、こちらをご覧ください

- "vCenter Server 向け NetApp Element プラグイン"
- "NetApp HCI のリソースページ"
- "NetApp HCI 2 ノードストレージクラスタテクニカルレポート"

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.