構成を確認し、導入します

HCI

Michael Wallis, Aksel Davis, Dave Bagwell
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/task_nde_review_deploy.html on July 01, 2021. Always check docs.netapp.com for the latest.

目次

構成を確認し、導入します 1
詳細については、こちらをご覧ください 2

構成を確認し、導入します

導入を開始する前に、指定した情報を確認できます。続行する前に、誤った情報や不完全な情報を修正することもできます。

> 導入時、管理ノードのインストールプロセスでは、 Element ストレージクラスタに「 NetApp-HCI - 」で始まる名前のボリュームが作成されます。また、「 tenant_ 」で始まる名前の SolidFire アカウントも作成されます。これらのボリュームやアカウントは削除しないでください。削除すると、管理機能が失われます。

手順

1. オプション：「 * Download * 」アイコンをクリックして、インストール情報を CSV 形式でダウンロードします。このファイルを保存し、あとで設定情報として参照できます。

   > 将来のインストールで必要になった場合は、 NetApp Deployment Engine の * インストールプロファイル * ページで、 CSV ファイルをインストールプロファイルとしてインポートできます。

2. 各セクションを展開し、情報を確認します。すべてのセクションを一度に展開するには、 * すべて展開 * をクリックします。
3. オプション：表示されているセクションの情報を変更するには、次の手順を実行します。
   a. 対応するセクションの * 編集 * をクリックします。
   b. 必要な変更を行います。
   c. [* Review （レビュー）] ページが表示されるまで [* Continue （続行）] をクリックします。以前の設定は各ページに保存されます。
   d. 手順 2 と 3 を繰り返して、必要なその他の変更を行います。
4. ネットアップがホストしている SolidFire Active IQ サーバにクラスタの統計情報とサポート情報を送信しないようにする場合は、最後のチェックボックスをオフにします。

   これにより、 NetApp HCI のリアルタイムの健常性診断の監視機能が無効になります。この機能を無効にすると、ネットアップによる NetApp HCI のプロアクティブなサポートと監視が行われなくなるため、本番環境が影響を受ける前に問題を検出して解決できなくなります。

5. すべての情報が正しい場合は、 * 導入の開始 * をクリックします。

   ダイアログボックスが表示されます。最終セットアッププロセスでネットワーク接続に問題が発生したり、電源が切断されたりした場合、またはブラウザセッションが切断された場合は、ダイアログに表示された URL をコピーして、最後のセットアップの進捗ページを参照できます。

6. ダイアログ内の情報を確認し、 ［ * クリップボードにコピー * ］ をクリックして URL をクリップボードにコピーします。
7. URL をコンピュータ上のテキストファイルに保存します。
8. 展開を続行する準備ができたら、 * OK * をクリックします。

   導入が開始され、進捗状況ページが表示されます。導入が完了するまでは、ブラウザウィンドウを閉じたり進捗状況ページから移動したりしないでください。何らかの理由でブラウザセッションが切断された場

合は、前の手順でコピーした　URL　を参照して（および表示されるセキュリティ警告を受け入れて）、最後のセットアップの進捗状況ページへのアクセスを再確立できます。

> 導入に失敗した場合は、エラーメッセージのテキストを保存してネットアップサポートにお問い合わせください。

導入が完了すると、コンピューティングノードが複数回リブートしてからサービスを開始できるようになることがあります。

[vSphere の起動 *] をクリックして、 NetApp HCI の使用を開始します。

> vSphere 6.7 を使用する NetApp HCI 環境では、このリンクをクリックすると、 HTML5 vSphere Web インターフェイスが起動します。vSphere 6.5 を使用する環境では、このリンクをクリックすると Adobe Flash vSphere Web インターフェイスが起動します。

詳細については、こちらをご覧ください

- "vCenter Server 向け NetApp Element プラグイン"
- "NetApp HCI のリソースページ"
- "SolidFire および Element ソフトウェアのドキュメント"

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.