インベントリを選択します

HCI

Michael Wallis, Aksel Davis, Dave Bagwell
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/task_nde_select_inventory.html on July 01, 2021. Always check docs.netapp.com for the latest.

目次

インベントリを選択します 1
詳細については、こちらをご覧ください 2

インベントリを選択します

NetApp Deployment Engine は、「 * インベントリ」ページで利用可能なコンピューティングノードとストレージノードを自動的に検出し、すべての NetApp HCI リソースを選択して導入環境に追加できるようにします。導入の要件を満たしていないノードは選択できず、問題がエラーとして示されます。ノードの行のエラーにカーソルを合わせると、説明が表示されます。Inventory ページでノードインベントリを選択すると、NetApp Deployment Engine をホストしているストレージノードが自動的に選択され、選択を解除することはできません。

インベントリの検出が正しく機能するためには、ジャンボフレームを有効にする必要がありますインベントリにノードがまったく表示されない場合や、一部のノードしか表示されない場合は、 NetApp HCI ノードに使用されているスイッチポート（すべての SFP+ / SFP28 インターフェイス）にジャンボフレームが設定されていることを確認します。

手順

1. [* Inventory] ページで、使用可能なノードのリストを確認します。

   システムがインベントリを検出できない場合は、エラーが表示されます。エラーを修正してから続行してください。IP アドレスの割り当てに DHCP を使用するシステムの場合は、ストレージリソースとコンピューティングリソースがすぐにインベントリに表示されないことがあります。

2. オプション：リソースがすぐにインベントリに表示されない場合、またはエラーに対処してインベントリを更新する必要がある場合は、 [* インベントリの更新 *] をクリックします。インベントリを複数回更新しなければならない場合があります。
3. オプション：ノードタイプなどのノード属性でインベントリをフィルタリングするには、次の手順を実行します。
   a. [計算ノード *] または [ストレージノード *] リストのヘッダーで [* フィルタ *] をクリックします。
   b. ドロップダウンリストから条件を選択します。
   c. ドロップダウンリストの下に、条件を満たす情報を入力します。
   d. [フィルタを追加（ Add Filter ）] をクリックします
   e. アクティブなフィルタの横にある **X** をクリックして個々のフィルタをクリアするか、フィルタのリストの上にある **X** をクリックしてすべてのフィルタをクリアします。
4. システムに付属しているすべてのコンピューティングノードを * コンピューティングノード * リストから選択します。

   導入を進めるには、少なくとも 2 つのコンピューティングノードを選択する必要があります。

5. システムに付属しているすべてのストレージノードを * ストレージノード * リストから選択します。

   導入を進めるには、少なくとも 2 つのストレージノードを選択する必要があります。

6. オプション：ストレージノードの選択ボックスにフラグが設定されている場合、そのストレージノードはストレージクラスタの総容量の 33% を超えています。次の手順を実行します。
   - フラグが設定されたストレージノードの選択ボックスをオフにします。
   - ストレージクラスタの容量がノード間でより均等に分散されるように、追加のストレージノードを選

択します。

7. [* Continue （続行）] をクリックします

詳細については、こちらをご覧ください

- "vCenter Server 向け NetApp Element プラグイン"
- "NetApp HCI のリソースページ"
- "SolidFire および Element ソフトウェアのドキュメント"

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.