Adding NetApp Support Site accounts to Cloud Manager

Cloud Manager 3.7

Ben Cammett
January 03, 2020

This PDF was generated from https://docs.netapp.com/us-en/occm37/task_adding_nss_accounts.html on October 18, 2020. Always check docs.netapp.com for the latest.

Table of Contents

Adding NetApp Support Site accounts to Cloud Manager 1

Adding NetApp Support Site accounts to Cloud Manager

Adding your NetApp Support Site account to Cloud Manager is required to deploy a BYOL system. It's also required to register pay-as-you-go systems and to upgrade ONTAP software.

Watch the following video to learn how to add NetApp Support Site accounts to Cloud Manager. Or scroll down to read the steps.

Steps

1. If you don't have a NetApp Support Site account yet, register for one.
2. In the upper right of the Cloud Manager console, click the Settings icon, and select **Cloud Provider & Support Accounts**.



3. Click **Add New Account** and select **NetApp Support Site**.
4. Specify a name for the account and then enter the user name and password.
    - The account must be a customer-level account (not a guest or temp account).

- If you plan to deploy BYOL systems:
  - The account must be authorized to access the serial numbers of the BYOL systems.
  - If you purchased a secure BYOL subscription, then a secure NSS account is required.

5. Click **Create Account.**

What's next?

Users can now select the account when creating new Cloud Volumes ONTAP systems and when registering existing systems.

- Launching Cloud Volumes ONTAP in AWS
- Launching Cloud Volumes ONTAP in Azure
- Registering pay-as-you-go systems
- Learn how Cloud Manager manages license files

Copyright Information

Copyright © 2020 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.