迁移到REST API

ONTAP Automation

NetApp
July 18, 2022

This PDF was generated from https://docs.netapp.com/zh-cn/ontap-automation/migrate/overview.html on July 18, 2022. Always check docs.netapp.com for the latest.

目录

迁移到REST API 1
概述 1
ONTAPI 到 REST API 映射 1
性能计数器 1
有关迁移到ONTAP REST API的博客 8

迁移到REST API

概述

NetApp首次在ONTAP 9.6中推出了REST API。自此之后、API不断扩展和成熟。现在、在自动化管理ONTAP 部署时、它是早期ONTAPI的首选战略替代方案。

如果您使用的是ONTAPI、建议您开始迁移到ONTAP REST API。本节介绍可用资源、并重点介绍支持迁移的有用功能和工具。

ONTAPI 到 REST API 映射

ONTAP REST API在大多数领域都包含与ONTAPI等效的功能。NetApp提供的文档介绍了从ONTAPI调用到等效REST API调用的映射。

API映射文档取决于ONTAP 版本：

- "ONTAP 9.8"
- "ONTAP 9.9.1"
- "ONTAP 9.10.1"
- "ONTAP 9.11.1"

性能计数器

通过ONTAP 计数器管理器、ONTAP 用户可以访问性能计数器信息并导出许多不同的ONTAP 性能计数器指标。

在ONTAP 9.11.1之前的版本中、对全套ONTAP 计数器管理器对象的访问仅限于ONTAP 命令行界面和ONTAPI接口。

从ONTAP 9.11.1开始、ONTAP 用户可以使用ONTAP REST API访问计数器管理器对象段。将自动化脚本从ONTAPI迁移到ONTAP REST API的用户需要了解如何向ONTAPI提供性能计数器数据与如何向REST API提供数据之间的差异。

请参见 "ONTAP 9.11.1 ONTAPI到REST计数器管理器映射" 有关ONTAP 9.11.1中REST API可用的一组ONTAP计数器的文档、以及有关ONTAPI和REST API使用量之间的计数器差异的信息。

使用ONTAPI访问性能计数器

在ONTAPI使用时、性能计数器数据会分组到对象中。例如、在具有四个磁盘的节点中、磁盘性能计数器数据会分组为一个对象。系统中的每个物理磁盘都代表该对象的一个实例、您可以使用ONTAPI访问单个磁盘实例的各个性能计数器。

使用ONTAP REST API访问性能计数器

使用ONTAP REST API、您可以通过表(例如、`disk`)访问计数器管理器对象。这意味着、每个计数器管理器对

象都表示为自己的表、而该计数器管理器对象的实例(例如系统中的各个磁盘)则可作为该表中的一行进行访问。每行都包含该实例的多个性能计数器。您可以将实例的单个性能计数器作为该表行中的一个字段来访问。

在以下示例中、`host_adapter` counter manager对象以表格式表示、用于说明如何使用ONTAP REST API访问每个性能计数器。系统中有多个主机适配器、每个主机适配器都有自己的性能计数器：

Instance name	**REST**计数器					
host_adapter_1	总读取操作数	total_write_ops	bytes_read	bytes_written	max_link_data_rate	RSCN_count
host_adapter_2	总读取操作数	total_write_ops	bytes_read	bytes_written	max_link_data_rate	RSCN_count
host_adapter_3.	总读取操作数	total_write_ops	bytes_read	bytes_written	max_link_data_rate	RSCN_count

使用**REST API**示例了解此结构

使用以下REST API示例帮助了解计数器管理器表的结构。这些示例还向您展示了如何使用REST API发现可用的端点、并使用它们深入了解系统的性能。这些示例将浏览`host_adapter` counter manager对象、并逐步显示有关该对象及其包含的计数器值的更详细信息。如果您在系统上尝试这些示例、请务必在所示位置用方括号<>提供相关信息的值。

发现可用的性能计数器表

您可以使用此REST API调用来发现可以查询的所有计数器管理器表：

请求示例：

```
curl -X GET -u admin:<PASSWORD> -k
'https://<ONTAP_IP_ADDRESS>/api/cluster/counter/tables'
```

示例响应(截断以缩短时间):


```
{
  "records": [
    {
      "name": "copy_manager",
      "_links": {
        "self": {
          "href": "/api/cluster/counter/tables/copy_manager"
        }
      }
    },
    {
      "name": "copy_manager:constituent",
      "_links": {
        "self": {
          "href": "/api/cluster/counter/tables/copy_manager%3Aconstituent"
        }
      }
    },
    {
      "name": "disk",
      "_links": {
        "self": {
          "href": "/api/cluster/counter/tables/disk"
        }
      }
    },
    {
      "name": "host_adapter",
      "_links": {
        "self": {
          "href": "/api/cluster/counter/tables/host_adapter"
        }
      }
    }
    ...
  ],
  "num_records": 68,
  "_links": {
    "self": {
      "href": "/api/cluster/counter/tables"
    }
  }
}
```

查询单个性能计数器表

您可以使用此REST API调用查看一个特定表(计数器管理器对象)的问题描述 和元数据。输出说明了该表的用途、并说明了该表中每个性能计数器记录的信息类型。在此示例中、我们查询`host_adapter`表：

请求示例：

```
curl -X GET -u admin:<PASSWORD> -k
'https://<ONTAP_IP_ADDRESS>/api/cluster/counter/tables/host_adapter'
```

示例响应：


```
{
  "name": "host_adapter",
  "description": "The host_adapter table reports activity on the Fibre
Channel, Serial Attached SCSI, and parallel SCSI Host Adapters the storage
system uses to connect to disks and tape drives.",
  "counter_schemas": [
    {
      "name": "bytes_read",
      "description": "Bytes read via Host Adapter",
      "type": "rate",
      "unit": "per_sec"
    },
    {
      "name": "bytes_written",
      "description": "Bytes written via Host Adapter",
      "type": "rate",
      "unit": "per_sec"
    },
    {
      "name": "max_link_data_rate",
      "description": "Max link data rate in Kilobytes per second for Host
Adapter",
      "type": "raw",
      "unit": "kb_per_sec"
    },
    {
      "name": "node.name",
      "description": "System node name",
      "type": "string",
      "unit": "none"
    },
    {
      "name": "rscn_count",
      "description": "Number of RSCN(s) received by the FC HBA",
      "type": "raw",
```

```
      "unit": "none"
    },
    {
      "name": "total_read_ops",
      "description": "Total number of reads on Host Adapter",
      "type": "rate",
      "unit": "per_sec"
    },
    {
      "name": "total_write_ops",
      "description": "Total number of writes on Host Adapter",
      "type": "rate",
      "unit": "per_sec"
    }
  ],
  "_links": {
    "self": {
      "href": "/api/cluster/counter/tables/host_adapter"
    }
  }
}
```


查看性能计数器表中的行

您可以使用此REST API调用查看表中的行、该调用会告知您存在哪些计数器管理器对象实例：

请求示例：

```
curl -X GET -u admin:<PASSWORD> -k
'https://<ONTAP_IP_ADDRESS>/api/cluster/counter/tables/host_adapter/rows'
```

示例响应：


```
{
  "records": [
    {
      "id": "power-01:0b",
      "_links": {
        "self": {
          "href": "/api/cluster/counter/tables/host_adapter/rows/power-
01%3A0b"
        }
      }
    },
    {
      "id": "power-01:0c",
```

```
      "_links": {
        "self": {
          "href": "/api/cluster/counter/tables/host_adapter/rows/power-
01%3A0c"
        }
      }
    },
    {
      "id": "power-01:0d",
      "_links": {
        "self": {
          "href": "/api/cluster/counter/tables/host_adapter/rows/power-
01%3A0d"
        }
      }
    },
    {
      "id": "power-01:0e",
      "_links": {
        "self": {
          "href": "/api/cluster/counter/tables/host_adapter/rows/power-
01%3A0e"
        }
      }
    }
  ],
  "num_records": 4,
  "_links": {
    "self": {
      "href": "/api/cluster/counter/tables/host_adapter/rows"
    }
  }
}
```


查询特定的计数器管理器实例

您可以使用此REST API调用查看表中特定计数器管理器实例的性能计数器值。在此示例中、我们请求提供系统中某个电源的性能计数器信息：

请求示例：

```
curl -X GET -u admin:<PASSWORD> -k
'https://<ONTAP_IP_ADDRESS>/api/cluster/counter/tables/host_adapter/rows/p
ower-01:0b'
```

示例响应：


```
{
  "counter_table": {
    "name": "host_adapter"
  },
  "id": "power-01:0b",
  "properties": [
    {
      "name": "node.name",
      "value": "power-01"
    }
  ],
  "counters": [
    {
      "name": "total_read_ops",
      "value": 3600516
    },
    {
      "name": "total_write_ops",
      "value": 3591536
    },
    {
      "name": "bytes_read",
      "value": 86354320000
    },
    {
      "name": "bytes_written",
      "value": 480863081920
    },
    {
      "name": "max_link_data_rate",
      "value": 375000
    },
    {
      "name": "rscn_count",
      "value": 0
    }
  ],
  "_links": {
    "self": {
      "href": "/api/cluster/counter/tables/host_adapter/rows/power-01:0b"
    }
  }
}
```

有关迁移到ONTAP REST API的博客

有几篇博客文章可帮助您更好地了解如何从ONTAPI迁移到ONTAP REST API。

NetApp支持通过映射文档从专有的ONTAPI迁移到ONTAP REST API。

"netapp.io/2020/12/17/ontapi-rest-mapping"

有几种技术可帮助您基于REST API实现ONTAP 自动化环境转型。

"www.netapp.com/blog/transform-automation-ontap-rest-api"

NetApp提供了一个工具、可帮助客户和合作伙伴过渡到ONTAP REST API。

"netapp.io/2022/21/Sovering-from-ontapizapi-using-ontapi-use-reporting-tool"

版权信息

版权所有©2022 NetApp、Inc.。保留所有权利。Printed in the U.S.版权所涵盖的本文档的任何部分不得以任何形式或任何手段复制、包括影印、录制、 磁带或存储在电子检索系统中—未经版权所有者事先书面许可。

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

本软件由NetApp按"原样"提供、不含任何明示或默示担保、包括但不限于适销性和特定用途适用性的默示担保、特此声明不承担任何责任。IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice.NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp.The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S.patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

商标信息

NetApp、NetApp标识和中列出的标记 http://www.netapp.com/TM 是NetApp、Inc.的商标。其他公司和产品名称可能是其各自所有者的商标。