对连接问题进行故障排除（SG6000）

StorageGRID

NetApp
June 10, 2022

This PDF was generated from https://docs.netapp.com/zh-cn/storagegrid-116/sg6000/unable-to-connect-to-appliance.html on June 10, 2022. Always check docs.netapp.com for the latest.

目录

对连接问题进行故障排除（ SG6000 ） 1
无法连接到设备 1
扩展架未显示在设备安装程序中 2

对连接问题进行故障排除（ SG6000 ）

如果您在 StorageGRID 设备安装期间遇到连接问题，应执行列出的更正操作步骤。

无法连接到设备

如果无法连接到设备，则可能存在网络问题描述 ，或者硬件安装可能未成功完成。

步骤

1. 如果无法连接到 SANtricity 系统管理器：
   a. 尝试使用管理网络上任一存储控制器的 IP 地址对设备执行 ping 操作，以查看 SANtricity System Manager： + ` * ping *Storage_Controller_IP**`
   b. 如果 ping 未收到任何响应，请确认您使用的 IP 地址正确无误。

      使用任一存储控制器上的管理端口 1 的 IP 地址。

   c. 如果 IP 地址正确，请检查设备布线和网络设置。

      如果无法解决问题描述 问题，请联系技术支持。

   d. 如果 ping 成功，请打开 Web 浏览器。
   e. 输入 SANtricity 系统管理器的 URL： + ` * https://*Storage_Controller_IP**`

      此时将显示 SANtricity 系统管理器的登录页面。

2. 如果无法连接到 SG6000-CN 控制器：
   a. 尝试使用 SG6000-CN 控制器的 IP 地址对设备执行 ping 操作： + ` * ping *SG6000-CN_Controller_IP**`
   b. 如果 ping 未收到任何响应，请确认您使用的 IP 地址正确无误。

      您可以使用网格网络，管理网络或客户端网络上设备的 IP 地址。

   c. 如果 IP 地址正确，请检查设备布线， SFP 收发器和网络设置。
   d. 如果可以物理访问 SG6000-CN ，则可以使用与永久链路本地 IP `169.254.0.1` 的直接连接来检查控制器网络配置，并在必要时进行更新。有关详细说明，请参见中的步骤 2 访问 StorageGRID 设备安装程序。

      如果无法解决问题描述 问题，请联系技术支持。

   e. 如果 ping 成功，请打开 Web 浏览器。
   f. 输入 StorageGRID 设备安装程序的 URL： + ` * https://*SG6000-CN_Controller_IP*:8443*`

      此时将显示主页页面。

扩展架未显示在设备安装程序中

如果您为SG6060或SG6060X安装了扩展架、但这些扩展架未显示在StorageGRID 设备安装程序中、则应验证这些磁盘架是否已完全安装并打开电源。

您可以通过在 StorageGRID 设备安装程序中查看以下信息来验证扩展架是否已连接到设备：

- 主页 * 页面包含一条有关扩展架的消息。



- * 高级 * > * RAID 模式 * 页面可通过驱动器数量指示设备是否包含扩展架。例如，在以下屏幕截图中，显示了两个 SSD 和 178 个 HDD 。包含两个扩展架的 SG6060 总共包含 180 个驱动器。

Configure RAID Mode

This appliance contains the following drives.

Type	Size	Number of drives
SSD	800 GB	2
HDD	11.8 TB	178

如果 StorageGRID 设备安装程序页面未指示存在扩展架，请遵循此操作步骤 。

步骤

1. 请验证 所有必需的缆线均已牢固连接。
2. 验证您是否已安装 已打开扩展架电源。
3. 如果您需要有关解决问题描述 的帮助，请联系技术支持。

版权信息

版权所有©2022 NetApp、Inc.。保留所有权利。Printed in the U.S.版权所涵盖的本文档的任何部分不得以任何形式或任何手段复制、包括影印、录制、 磁带或存储在电子检索系统中—未经版权所有者事先书面许可。

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

本软件由NetApp按"原样"提供、不含任何明示或默示担保、包括但不限于适销性和特定用途适用性的默示担保、特此声明不承担任何责任。IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice.NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp.The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S.patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

商标信息

NetApp、NetApp标识和中列出的标记 http://www.netapp.com/TM 是NetApp、Inc.的商标。其他公司和产品名称可能是其各自所有者的商标。