疑難排解連線問題（SG6000）

StorageGRID

NetApp
May 03, 2022

This PDF was generated from https://docs.netapp.com/zh-tw/storagegrid-116/sg6000/unable-to-connect-to-appliance.html on May 03, 2022. Always check docs.netapp.com for the latest.

目錄

疑難排解連線問題（SG6000） 1
無法連線至應用裝置 1
應用裝置安裝程式不會顯示擴充櫃 2

疑難排解連線問題（SG6000）

如果StorageGRID 在安裝過程中遇到連線問題、您應該執行列出的修正行動步驟。

無法連線至應用裝置

如果您無法連線至應用裝置、可能是網路問題、或是硬體安裝未成功完成。

步驟

1. 如果您無法連線SANtricity 到《系統管理程式》：
   a. 請嘗試使用管理網路上任一儲存控制器的IP位址來ping應用裝置SANtricity 、以利執行《系統管理程式：+》、「* ping *Storage_Controller_IP**」
   b. 如果ping沒有回應、請確認您使用的是正確的IP位址。

      在任一儲存控制器上使用管理連接埠1的IP位址。

   c. 如果IP位址正確、請檢查設備纜線和網路設定。

      如果仍無法解決問題、請聯絡技術支援部門。

   d. 如果ping成功、請開啟網頁瀏覽器。
   e. 輸入SANtricity URL for the URL for the EtrySystem Manager:+* `https://Storage_Controller_IP*`

      畫面會出現「登入SANtricity 頁面、以供使用。

2. 如果您無法連線至SG6000-CN-控制器：
   a. 嘗試使用SG6000-CN*控制器的IP位址ping應用裝置：+「* ping *SG6000-CN_Controller_IP**」
   b. 如果ping沒有回應、請確認您使用的是正確的IP位址。

      您可以在Grid Network、管理網路或用戶端網路上使用應用裝置的IP位址。

   c. 如果IP位址正確、請檢查設備纜線、SFP收發器和網路設定。
   d. 如果可以實體存取SG6000-CN,您可以使用直接連線至永久連結本機IP「169.254.0.1」來檢查控制器網路組態並視需要更新。如需詳細指示、請參閱中的步驟2 存取StorageGRID 產品安裝程式。

      如果仍無法解決問題、請聯絡技術支援部門。

   e. 如果ping成功、請開啟網頁瀏覽器。
   f. 輸入StorageGRID URL for the URL for the EASEUREAppliance Installer:+* `https://SG6000-CN_Controller_IP:8443*`

      隨即顯示首頁。

應用裝置安裝程式不會顯示擴充櫃

如果您已安裝SG6060的擴充櫃、但StorageGRID 未出現在《Some應用程式安裝程式」中、您應該確認磁碟櫃已完全安裝並開啟電源。

您可以在StorageGRID 《NetApp應用裝置安裝程式：

- 「首頁」頁面包含擴充櫃的相關訊息。



- 「進階>* RAID模式*」頁面會依磁碟機數量指出設備是否包含擴充櫃。例如、下列螢幕擷取畫面會顯示兩個SSD和178個HDD。SG6060配備兩個擴充櫃、總共可容納180個磁碟機。



Type	Size	Number of drives
SSD	800 GB	2
HDD	11.8 TB	178

如果StorageGRID 「無法」顯示擴充櫃存在、請遵循此程序。

步驟

1. 請確認 所有必要的纜線都已穩固連接。
2. 請確認您擁有 已開啟擴充櫃電源。
3. 如果您需要解決問題的協助、請聯絡技術支援部門。

Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.