Wireless Energy Harvesting for the Internet of Things

Software Used: NetSim Standard v13.0 (32/64-bit), Visual Studio 2019

Project Download Link:

https://github.com/NetSim-

TETCOS/Energy Harvesting in IOT v13 0/archive/refs/heads/main.zip

Follow the instructions specified in the following link to download and setup the Project in NetSim:

https://support.tetcos.com/en/support/solutions/articles/14000128666-downloading-and-setting-upnetsim-file-exchange-projects

Introduction:

Among different energy harvesting methods, such as vibration, light, and thermal energy extraction, wireless energy harvesting (WEH) has proven to be one of the most promising solutions by virtue of its simplicity, ease of implementation, and availability. This recent technology trend in energy harvesting provides a fundamental method to prolong battery longevity. While harvesting from the environmental sources is dependent on the presence of the corresponding energy source, RF energy harvesting provides key benefits in terms of being wireless, readily available in the form of transmitted energy (TV/radio broadcasters, mobile base stations, and handheld radios), low cost, and small form factor implementation.

A WEH-enabled sensor device usually consists of an antenna, a transceiver, a WEH unit, a power management unit (PMU), a sensor/processor unit, and possibly an onboard battery. The available harvested power, *PH*, is given by a Friis equation and is directly proportional to the transmitted power, *PT*, path loss, *PL*, transmitter antenna gain, *GT*, receiver antenna gain, *GR*, power conversion efficiency of the converter, *PCEH*, and the square of the wavelength, I, and is inversely proportional to the square of the communication distance, *r*, between the source and the device.


The communication energy consists of *ELS* (listening energy), *ERX* (receiver energy), and *ETX* (transmitter energy). The computation energy includes *EPR* (processing energy) and *ESN* (sensing energy). To capture the energy distribution among the aforementioned energy consumers, weighting coefficients aLS > aTX > aRX > aPR > aSN are assigned to them. The total average energy consumption ED = aLS ELS + aTX ETX + aRX ERX + aPR EPR + aSN ESN. *EB* is the total energy stored in the battery, and *EH* is the available harvested energy per active duty cycle. We assume constant energy consumptions for receiver, processor, and sensor. However, the energy consumption of the transmitter (*ETX*) is directly proportional to rij , where rij is the distance between the originating device j and the sink node i (in ring topology) or the sink node/sensor device (in multihop topology). The harvested energy *EH* is inversely proportional to rij (here j is the sink node and rij = rji).

IEEE Ref Paper:

Wireless Energy Harvesting for the Internet of Things P. Kamalinejad C. Mahapatra; Z. Sheng; S. Mirabbasi; V. C. M. Leung; Y. L. Guan *IEEE* COMMUNICATIONS MAGAZINE · JUNE 2015

The code given below is for an example implementation of WEH whereby energy is harvested based on the received signal power. The Steps to be followed for Implementation in NetSim are:

1. Open the Source codes in Visual Studio by going to Your work-> Workspace Options and Clicking on **Open code** button as shown below:




Expand BatteryModel Project and double click on the BatteryModel.h file to open it.
 The following changes(highlighted in red) were done to the code:
 _declspec(dllexport) void battery_animation();
 _declspec(dllexport) void battery_metrics(PMETRICSWRITER metricsWriter);
 _declspec(dllexport) double battery_get_remaining_energy(ptrBATTERY battery);
 _declspec(dllexport) int battery_energy_harvesting(ptrBATTERY battery, double eh_energy);
 _declspec(dllexport) double battery_get_consumed_energy(ptrBATTERY battery, int mode);
 Now double click on the BatteryModel.c file to open the file. The following

4. Expand ZigBee project and double click on the ChangeRadioState.c file to open it. At the end of ChangeRadioState.c file the following lines of code are added:

```
#define EH FRACTION 0.1
   #EH FRACTION is the fraction of the received signal energy that can be
   // captured and harvested by the sensor.
   int calculate eh(NETSIM ID dev1, NETSIM ID dev2)
   {
         double rx_pwr = GET_RX_POWER_mw(dev1, dev2, pstruEventDetails-
   >dEventTime);
         double eh_energy= EH_FRACTION *
         rx_pwr; ptrBATTERY battery =
         WSN_PHY(dev2)->battery; if(battery)
         battery energy harvesting(battery, eh energy);
   }
5. The function call shown in red is added to 802_15_4.c file
   case UPDATE_MEDIUM:
      {
         double dtime=pstruEventDetails->dEventTime;
         NETSIM_ID nLink_Id, nConnectionID, nConnectionPortID,
         nLoop; NETSIM ID nTransmitterID;
         nTransmitterID = pstruEventDetails->nDeviceId;
         ZIGBEE CHANGERADIOSTATE(nTransmitterID,
         WSN PHY(nTransmitterID)-
      >nRadioState, RX ON IDLE);
         if(WSN_PHY(nTransmitterID)->nRadioState !=
                RX OFF) WSN MAC(nTransmitterID)-
                >nNodeStatus = IDLE;
                nLink Id = fn NetSim Stack GetConnectedDevice(pstruEventDetails-
      >nDeviceId,pstruEventDetails-
                >nInterfaceId,&nConnectionID,&nConnectionPortID);
                for(nLoop=1; nLoop<=NETWORK-
                >ppstruNetSimLinks[nLink Id-1]-
      >puniDevList.pstruMP2MP.nConnectedDeviceCount; nLoop++)
                NETSIM ID ncon = NETWORK->ppstruNetSimLinks[nLink Id-1]-
      >puniDevList.pstruMP2MP.anDevIds[nLoop-
                11: if(ncon != pstruEventDetails-
                >nDeviceId)
         calculate eh(nTransmitterID, nLoop);
      WSN PHY(ncon)->dTotalReceivedPower -=
      GET_RX_POWER_mw(nTransmitterID,ncon,pstruEventDetails-
      >dEventTime);
         if(WSN_PHY(ncon)->dTotalReceivedPower < WSN_PHY(ncon)-
      >dReceiverSensivity)
         WSN_PHY(ncon)->dTotalReceivedPower = 0;
                                         }
      This completes the code modifications for energy
                      harvesting.
```

6. Right click on the Solution in the solution explorer and select Rebuild.




7. Upon successful build modified libZigBee.dll and BatteryModel.dll file gets automatically updated in the directory containing NetSim binaries.


COMPARATIVE ANALYSIS:

1. Create a network scenario in IoT with say 16 sensors, a 6LoWPAN Gateway, a Router and a Wired Node as shown below. The WSN_Energy_Harvesting_Workspace also comes with a sample configuration that is already saved. To open this example, go to Your Work and click on the WSN_Energy_Harvesting_Example that is present under the list of experiments.


1.



2.	Configure traffic in the network by setting a few applications between some of the sensor nodes to the Wired Node using the Application Icon, as shown below:




3. Disable Energy Harvesting in all Sensor nodes by setting the EnergyHarvesting parameter to OFF in the Interface(ZigBee) Properties of the sensor nodes as shown below:



4. Run Simulation for say 100 seconds and save the simulation results. In NetSim Simulation Results Window, the Battery model table provides detailed metrics related to energy consumed by each sensor node. The column Remaining energy can be used to compare simulations with and without energy harvesting code modification.

WITH ENERGY HARVESTNG

Now re-run the network simulation for 100 seconds and save the simulation results.
You can use the table remaining energy column present in the Battery model table
which is part of NetSim Simulation Results window to compare simulations with and
without wireless energy harvesting.



Now on comparing the custom IOT metrics we can observe that Energy Harvesting increases sensors' working capability. Simulations can be performed for different values of EH Fraction which may vary as per the efficiency of the Energy Harvesting unit.