
Netra Patel

30092878



Flow Chart I.

Initialize:

TRISA = 0x00

ANSELA-0x80

LATA-0x80

ANSELB- 0x00

TRISB= 0xFF

Static u32 u32 Counter=0.

E (RBS=1)

No

LATA ++

Do nothing

Flow chart 2. Initialize: TRISA EOXOO ANSELAZONO LATA=0x80 AMSELBE OXOD TRISBE OXFE startic uzz 132 Previous; 432 (mad Something to bitmask inputs

if (current 1 = Previous) u32 Previous= u32 Currente,