Software Dependencies

PiPlanter uses many different software packages to function. Run all of the following commands to ensure all of the software installs properly.

```
$ apt-get install python-imaging python-imaging-tk python-pip mencoder python-dev
git apache2 mysql-server php5 php5-mysql python-mysqldb python-serial php5-gd
$ pip install tweepy apscheduler spidev wiringpi pillow
$ wget https://gdata-python-client.googlecode.com/files/gdata-2.0.18.tar.gz
$ tar -xzvf gdata-2.0.18.tar.gz
$ cd qdata-2.0.18/
$ sudo python setup.py install
$ wget https://youtube-upload.googlecode.com/files/youtube-upload-0.7.2.tgz
$ tar -xzvf youtube-upload-0.7.2.tgz
$ cd youtube-upload-0.7.2/
$ sudo python setup.py install
$ mkdir /srv/www/lib/
$ cd /srv/www/lib/
$ wget http://www.pchart.net/release/pChart2.1.3.tar.gz
$ tar -xzvf pChart2.1.3.tar.gz
$ mv pChart2.1.3 pChart
```

You'll need to enable SPI on your Pi in order to use the MCP3008 ADC. Do this by running the following commands:

Edit your config file

\$ sudo nano /etc/modprobe.d/raspi-blacklist.conf

Comment out the spi-bcm2708 line so it looks like this:

#blacklist spi-bcm2708

Then run this to make it more permanent.

\$ sudo modprobe spi-bcm2708

And finally reboot your Pi with:

\$ sudo reboot