## **SAMBA**

## **Install SAMBA**

sudo apt-get install samba

## **Create SAMBA user and group**

sudo adduser piusr

sudo adduser piadm

sudo groupadd samba

sudo groupadd sambaadm

sudo usermod -a -G samba piusr

sudo usermod -a -G sambaadm piadm

sudo smbpasswd -a piusr

sudo smbpasswd -a piadm

## Modify the SAMBA config

```
sudo nano /etc/samba/smb.conf
        [BIO]
        comment = BIO MCC_DAQ_HATS Folder Share
        path = /BIO
        browseable = yes
        writable = no
        read only = yes
        guest_ok = yes
        valid users = @samba
        force group = samba
        [BIOADM]
        comment = BIO Folder Share as full permission
        path = /BIO
        browseable = yes
        writable = yes
        guest_ok = yes
        valid users = @sambaadm
        force group = samba
```

```
sudo chown piusr:piusr /BIO
sudo chown piadm:piadm /BIO
sudo setfacl -R -m g:samba:rwx /BIO
sudo setfacl -R -m g:sambaadm:rwx /BIO
```

```
sudo systemetl enable smbd nmbd
sudo systemetl restart smbd nmbd
```