LT01
LAPTOP
GENERIC

USB [F TYPE A]	HDMI [F TYPE A]
USB [F TYPE A]	LAN [RJ-45]
USB [F TYPE C]	
POWER	AUDIO [F 3.5mm]

VCBT01P

L
R

WORK_TABLE

LT02
LAPTOP
GENERIC

USB [F TYPE A]	HDMI [F TYPE A]
USB [F TYPE A]	LAN [RJ-45]
USB [F TYPE C]	
POWER	AUDIO [F 3.5mm]

VCBT02P

L
R

WORK_TABLE

LT03
LAPTOP
GENERIC

USB [F TYPE A]	HDMI [F TYPE A]
USB [F TYPE A]	LAN [RJ-45]
USB [F TYPE C]	
POWER	AUDIO [F 3.5mm]

VCBT03P

L
R

WORK_TABLE

PI
Raspberry Pi
Pi 4 Model B

USB [F TYPE A]	LAN [RJ-45]
USB [F TYPE A]	HDMI [F TYPE A]
USB [F TYPE A]	HDMI [F TYPE A]
	USB [F TYPE A]
	AUDIO [F 3.5mm]
POWER	

VCBT04P
AVH02U

R

TBC

NS01
NETWORK SWITCH
CISCO SG1100D-08HP

LAN [RJ-45 F]	LAN [RJ-45 F]
LAN [RJ-45 F]	LAN [RJ-45 F]
LAN [RJ-45 F]	LAN [RJ-45 F]
POWER	

VCBT05P
VCBT06P
VCBT07P

WORK_TABLE

AX01
AUDIO MIXER
YAMAHA QL1

LAN [RJ-45]	AUDIO [F XLR]
	L
	AUDIO [F XLR]
POWER	R

AS01P
AS02P
AS03P

AUDIO_RACK

AVM01
AV MONITOR
GENERIC

HDMI [F TYPE A]	
INFRA RED [LED RX]	AUDIO [F 3.5mm]
POWER	

L
R

WORK_TABLE

DT
MEDIA SERVER
GENERIC

USB [F TYPE A]	HDMI [F TYPE A]
USB [F TYPE A]	USB [F TYPE C]
LAN [RJ-45]	
POWER	AUDIO [F 3.5mm]

AVH01U

L
R

FLOOR

APS01
SUBWOOFER
ADAM SUB10

AUDIO [F XLR]	
POWER	

FLOOR

AA01
AUDIO AMPLIFIER
KRAMER 914

AUDIO [5 POLE CS]	AUDIO 70V [4 POLE CS]
POWER	CONTROL [2 POLE CS]

AS04P
AS05P

AUDIO_RACK

NR01
ROUTER
NETGEAR AC1200

LAN [RJ-45]	LAN [RJ-45]
LAN [RJ-45 F]	
POWER	

VCBT08P

WORK_TABLE

VP01
PROJECTOR
EPSON EB-PU2010B

HDMI [F TYPE A]	
LAN [RJ-45]	
POWER	

TRUSS

AMS01
PASSIVE SPEAKER
MACKIE CR4

AUDIO [F XLR]

SPK_STAND

AMS02
PASSIVE SPEAKER
MACKIE CR4

AUDIO [F XLR]

SPK_STAND

?
LIGHTING CONSOLE
MA3 COMMAND WING

LAN [RJ-45]	LAN [RJ-45]
POWER	

TABLE