
clear_pulse = 1
IDLE
BUSY = 0
DONE = 0
ERROR = 0
rst = 1
start_pulse = 1
CHECK
BUSY = 1
DONE = 0
ERROR = 0
Validate Config & Data
validation_ok = 1
RUN
BUSY = 1
DONE = 0
ERROR = 0
CORE_EN = 1
compute_done = 1
DONE
BUSY = 0
DONE = 1
ERROR = 0
validation_ok = 0
clear_pulse = 1
ERROR
BUSY = 0
DONE = 0
ERROR = 1
ERROR_CODE valid
compute_error = 1