

Pump Maintenance Guide

Weekly

Inspect bearings.

Check lubrication.

Inspect seals.

Monthly

Measure vibration.

Check shaft alignment.

Inspect impeller.

Failure Indicators

Pressure loss

Flow reduction

High vibration

High temperature