

Visionary Firmware Update

3D Compact Systems June 2021



Content



- Introduction
- <u>Preparation</u>
- Install or update SOPAS ET
- Install SDD
- Start
- <u>Update</u>
- <u>Select files</u>
- Finish firmware update
- <u>Install new device description</u>
- Go online

3D Compact Systems - SICK AG < 2 >

Introduction



- This document will guide you through the firmware update process.
- We highly recommend to use the latest firmware versions for your Visionary device in order to enable the latest device features.
- Make sure to save your device configuration as *.sopas file before you update your Visionary device.
 - For that, simply import/export the *.sopas file to/from the device via SOPAS
 - NOTE: When re-importing *.sopas after a firmware update please refer to the separate documentation for this case
- Disclaimer:

The device configuration may be lost after an update.

The graphical user interface may change after an update.

The latest firmware may support only the latest SOPAS ET version.

< 3 > 3D Compact Systems - SICK AG

Preparation



- Install the latest version of SOPAS ET, e.g. 2021.1 or higher
 - SOPAS ET is included in the Supporting material or available on www.sick.com
- Be sure that your power connection works properly and is well connected to the device
- Connect the Visionary device with your PC:
 - Connection via Ethernet
 - Connection proved e.g. by receiving 3D data

Prepare the .spk update package

3D Compact Systems - SICK AG < 4 >


Install SOPAS ET



- SOPAS ET is included in the Supporting material or available on www.sick.com
- Go to Downloads/Software



Filter by Category. Configuration software & Software type: Sopas ET



- SOPAS Engineering Tool 2021.1 (or higher)
- Accept Terms & Conditions and download the software



Name: SOPAS Engineering Tool

Version: 2021.1 (4.5.0)

Software category: Configuration software

Size: 274.11 MB

Product family: MZT8 VIA, MZC1 VIA, MZCG VIA, GM32, ...

Details | Add to wish list | Download

3D Compact Systems - SICK AG < 5 >

INSTALL SDD

(IF NOT ALREADY DONE)



- After a successful connection the driver might be missing.
- Click on No driver installed



• Choose *Device upload*




3D Compact Systems - SICK AG < 6 >

Start



- Precondition: Device is online.
- If not, please check:
 - Physical connection
 - IP address
 - SDD version (uninstall and upload form device again)
 - Always start device first, then SOPAS ET (to ensure that the communication interface is active)



3D Compact Systems - SICK AG < 7 >


Update



• Device must be highlighted:



• Select Download firmware:



3D Compact Systems - SICK AG < 8 >


Select Files



• Select a *.spk file



• Start Update



3D Compact Systems - SICK AG < 9 >


Select Files





- Confirm Service level with password
- Password: CUST_SERV

• Wait ...

... until download succeeds








3D Compact Systems - SICK AG < 10 >

Finish update



Close Firmware Download dialog



Choose Finish



3D Compact Systems - SICK AG < 11 >

Install new Device description



- After a successful connection the driver might be missing.
- Click on No driver installed



• Choose *Device upload*



3D Compact Systems - SICK AG < 12 >


Go Online



Click *Offline* to go online



• Choose *Read parameters*



Success!



3D Compact Systems - SICK AG < 13 >



Thank you for your attention.

3D Compact Systems techsupport0905@sick.de

