## Adding an element

Adding an element post-constructor is easier than writing a new netlist file.

## 1. Adding to existing nodes

Say, we want to add an additional resistor to a simple voltage divider.

```
circuit = Circuit('circuits/voltage_divider.txt');
circuit.list

ans =
    'Vin 1 0 DC 5
    R1 1 2 1000
    R2 2 0 3000
```

If we want to add an element between any existing nodes, the process is very simple. We create the element and add it.

```
R = Resistor('Rx',2,0,2000);
```

Be careful not to run the add function more than once, if this is not intended.

```
circuit.add(R)
circuit.list

ans =
    'Vin 1 0 DC 5
    R1 1 2 1000
    R2 2 0 3000
    Rx 2 0 2000
    '
```

## 2. Adding onto a wire

If instead we want to add an element onto a single node, the process is slightly more complicated. When -1 is used as a nodal connection, it means that the node has yet to be created, so in this case, the resistor  $R_x$  will go onto the wire between  $R_1$  and  $R_2$ .

```
R = Resistor('Rx',2,-1,2000);
```

We can then add it to the circuit object using the add function. This will prompt the user to resolve any connection conflicts by choosing where to reconnect surrounding element.

```
circuit.add(R)
```

## circuit.list

```
ans =
    'Vin 1 0 DC 5
    R1 1 2 1000
    R2 3 0 3000
    Rx 2 3 2000
```

The circuit can now be manipulated as if it was created with a netlist.

```
ELAB.simplify(circuit);
circuit.list
```

```
ans =
'Vin -1 0 DC 5
Req1 -1 0 6000
```