




Pointer Visualisations



Pointer visualisations are designed to provide information regarding the pointer for the load/store instructions `LDR`, `LDRB`, `STR`, `STRB`. The visualisation can be viewed by using the button `Show Pointer` that automatically appears when needed, or by using the keyboard shortcut `Shortcut+Alt+P` if the visualisation has been disabled via the [settings panel](#).

`Shortcut` is `Ctrl` for Windows and Linux, and `Cmd` for Mac OS X.

The following information is provided in the pointer visualisations:

Item	Description
Pointer name	The register name <code>R0-R14</code> used as the pointer
Base address	The value of the pointer without the offset
Offset	The offset value to be added the pointer
Base + Offset	The <code>base+offset</code> value of the pointer
Value used	The value loaded from/stored to memory
Pre-post/indexing disabled	Pointer remains unchanged after execution
Pre-indexing enabled	Pointer is set to <code>base+offset</code> before being used
Post-indexing enabled	Pointer is set to <code>base+offset</code> after being used
Instruction summary	Provides an overview of how the load/store operation takes place